

Help Menu

The commands are described under the [Help Menu](#).

Methods of the Source

_Methods of the Source

The *Source* provides:

- The *methods* listed in the table of contents to the left.
- The [Methods of the Material Flow Objects](#).
- The [Methods of All Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
contentsList	[]			([Contents:table]) -> any
createAttr				(NameOfUserDefinedAttribute:string, DataType:string) -> boolean
createIcon				([IconName:string, Width:integer, Height:integer]) -> integer
deleteAttr				(NameOfUserDefinedAttribute:string) -> boolean

Name of the method Identifier and data type of the parameter you enter Data type of the return value

Name	Value	Inherited	Watchable	Signature
moveToFolder				(Folder:object) -> object
MU	VOID			([Index:integer: =1]) -> object
MUPart	VOID			([Index:integer: =1]) -> object

Name of the method Identifier and data type of the parameter you enter Default value Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

An example of the **Syntax** line of the individual methods might look like this:

```
<Path>.openDialog([CallOpenControl:boolean:=false]) → boolean
```

- The expression *<Path>* designates the path of the object to which the *method* applies.
- The signature of the method, consisting of the identifier and the data type of the parameter, is listed in parentheses. The expression *(Parameter:string)*, for example, designates a parameter of data type *string*. Instead of a constant value, you can also use a variable of the required type or a *method* that returns the required data type.

Note

Make sure to enter the parentheses for expressions within parentheses (...). Not entering them may lead to unexpected results and open the *Debugger*.

Optional parameters are listed within brackets. The expression *[,Parameter:boolean]*, for example, means that you can, but do not have to enter the *boolean* parameter.

If a parameter has a default value, the signature shows the default value after the parameter, `:= false` in the example above.

If the *method* has a return value, the signature shows its data type after the arrow `->`, `→ boolean` in the example above.

creationTable [SimTalk] - Source

Returns the **Creation Table** of the *Source* designated by <Path> and writes it into a table.

Type

Method

Syntax

```
<Path>.creationTable(CreationTable:table)
```

Parameter

The parameter *CreationTable* of data type *table* either designates a local variable, a table cell of data type *table*, or the path to a *DataTable*.

Example

```
MySource.creationTable(myEvaluationTable)  
MySource.creationTable(MyDataTable[2,8])
```

SimTalk

[CreationTableActive \[SimTalk\]](#)

See also

[Creation Table \[Source\]](#)

getCurrentOrderTableRow [SimTalk]

Returns the row number of the table according to which the *Source* designated by <Path> currently produces parts.

Remarks

getCurrentOrderTableRow only returns the table row for **MU Selection > Sequence Cyclical**, **Sequence**, **Random**, and **Percentage**, which produce parts according to a *DataTable*.

In all other cases the return value always is 0.

Syntax

```
<Path>.getCurrentOrderTableRow -> integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MySource.getCurrentOrderTableRow
```

See also

[MU selection \[drop-down list\] > Sequence Cyclical \[MU selection\]](#)

[Sequence \[MU selection\]](#)

[Random \[MU selection\]](#)

[Percentage \[MU selection\]](#)

orderParts [SimTalk] - Source

Orders parts from the *Source* designated by <Path>.

Type

Method

Syntax

```
<Path>.orderParts(PartType:object, Amount:integer, Destination:object[,  
Name:string])
```

Parameters

You can specify the following parameters:

- The parameter *PartType* of data type *object* designates the path to the part type that is going to be ordered.
- The parameter *Amount* of data type *integer* designates the amount of parts that is going to be ordered.
- The parameter *Destination* of data type *object* designates the object that orders the parts. The destination can be any material flow object.

If the *Destination* is a **Supermarket**, *Plant Simulation* increases the counter of the amount of the remaining ordered parts, compare the column **Waiting** in the **Configuration Table** of the *Store*.

- The optional parameter *Name* of data type *string* designates the name of the part type that is going to be ordered. If you do not enter anything, *Plant Simulation* uses the name of the object which you entered as the *PartType*.

Examples

```
MySource.orderParts(.UserObjects.MyPart, 12, MyStation, "MyPart")
```

```
param partName:string, minStock:integer, maxStock:integer,  
currentStock:integer, orderedParts:integer  
  
var amount:integer := maxStock-currentStock-orderedParts  
if amount > 0 then  
    Source.orderParts(@, amount, ?, partName)  
end
```

SimTalk

orderParts [SimTalk] - Store

See also

[MU selection \[drop-down list\]](#) > [Order Controlled \[MU selection\]](#)

[Configuration \[button\]](#)

Read-Only Attributes of the Source

Read-Only Attributes of the Source

The *Source* provides:

- The [_Read-Only Attributes of All Objects](#).
- The [Read-Only Attributes of the Material Flow Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
NumPartsSinceSetup	0			-> integer
NumPred	1			-> integer
NumSucc	3			-> integer

Name of the read-only attribute Current value of the read-only attribute Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

To query the value of a *read-only attribute*, you might, for example, type:

```
print MySource.UUID
```