

See also

[MU selection \[drop-down list\]](#) > [Order Controlled \[MU selection\]](#)

[Configuration \[button\]](#)

Read-Only Attributes of the Source

Read-Only Attributes of the Source

The *Source* provides:

- The [_Read-Only Attributes of All Objects](#).
- The [Read-Only Attributes of the Material Flow Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
NumPartsSinceSetup	0			-> integer
NumPred	1			-> integer
NumSucc	3			-> integer

Name of the read-only attribute Current value of the read-only attribute Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

To query the value of a *read-only attribute*, you might, for example, type:

```
print MySource.UUID
```

CurrentBatchNumber [SimTalk]

Returns the batch number of the part that was created last if the attribute *GenerateAsBatch* is activated (`true`). Returns the number of created parts if *GenerateAsBatch* is not is activated (`false`).

Type

Read-only attribute

Syntax

```
<Path>.CurrentBatchNumber -> integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MySource.CurrentBatchNumber
```

See also

[Generate as Batch \[check box\]](#)

[GenerateAsBatch \[SimTalk\]](#)

Attributes of the Source

_Attributes of the Source

The *Source* provides:

- The *attributes* listed in the table of contents to the left.
- The [Attributes of All Objects](#).
- The [Attributes of the Material Flow Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.