

## Help Menu

The commands are described under the [Help Menu](#).

## Methods of the Track

## Methods of the Track

The *Track* provides:

- The *method* **getRouteLength [SimTalk] - Track.**
- The **\_Methods of Curved Objects.**
- The **Methods of the Material Flow Objects.**
- The **Methods of All Objects.**

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.



| Name         | Value | Inherited | Watchable | Signature                                                       |
|--------------|-------|-----------|-----------|-----------------------------------------------------------------|
| contentsList | []    |           |           | ([Contents:table]) -> any                                       |
| createAttr   |       |           |           | (NameOfUserDefinedAttribute:string, DataType:string) -> boolean |
| createIcon   |       |           |           | ([IconName:string, Width:integer, Height:integer]) -> integer   |
| deleteAttr   |       |           |           | (NameOfUserDefinedAttribute:string) -> boolean                  |

Name of the method

Identifier and data type of the parameter you enter

Data type of the return value



The screenshot shows the .Models.Model.Station window. The table lists the following methods:

| Name         | Value | Inherited | Watchable | Signature                      |
|--------------|-------|-----------|-----------|--------------------------------|
| moveToFolder |       |           |           | (Folder:object) -> object      |
| MU           | VOID  |           |           | ([Index:integer:=1]) -> object |
| MUPart       | VOID  |           |           | ([Index:integer:=1]) -> object |

Below the table, the following labels are provided:

- Name of the method
- Identifier and data type of the parameter you enter
- Default value
- Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected **Class [general description]**.

- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

An example of the **Syntax** line of the individual methods might look like this:

```
<Path>.openDialog([CallOpenControl:boolean:=false]) → boolean
```

- The expression *<Path>* designates the path of the object to which the *method* applies.
- The signature of the method, consisting of the identifier and the data type of the parameter, is listed in parentheses. The expression *(Parameter:string)*, for example, designates a parameter of data type *string*. Instead of a constant value, you can also use a variable of the required type or a *method* that returns the required data type.

#### Note

Make sure to enter the parentheses for expressions within parentheses (...). Not entering them may lead to unexpected results and open the *Debugger*.

Optional parameters are listed within brackets. The expression *[,Parameter:boolean]*, for example, means that you can, but do not have to enter the *boolean* parameter.

If a parameter has a default value, the signature shows the default value after the parameter, `:= false` in the example above.

If the *method* has a return value, the signature shows its data type after the arrow `->`, `→ boolean` in the example above.

## getRouteLength [SimTalk] - Track

Returns the shortest route from the *Track* designated by <Path> to the target and returns the length of this route.

### Remarks

The destination can either be a material flow object, which can be reached directly via *Connectors*, or a destination, which you typed into a sensor.

#### Note

As the route is intended for *Transporters*, *Plant Simulation* only takes objects of type *Track* and *TwoLaneTrack* into consideration when computing the route.

### Type

### Method

### Syntax

```
<Path>.getRouteLength(Target:path[, Backwards:boolean, Position:length,  
ObjectsAlongRoute:table, RouteWeightingAttribute:string]) → length
```

### Parameters

You can specify the following parameters:

- The parameter *Target* of data type *object* designates the target.
- The optional parameter *Backwards* of data type *boolean* designates the direction in which *Plant Simulation* looks for a route. *True* stands for backward, *false* stands for forward, which is the default setting.
- The optional parameter *Position* of data type *length* designates the position on the *Track* at which the search starts. If you do not specify the parameter, *Plant Simulation* starts searching at the end of the *Track* if you search forward, or it starts searching at the beginning if you search backward. This is particularly important if the *Destination* is a sensor, which is located on the *Track* itself.
- The optional parameter *ObjectsAlongRoute* of data type *table* writes the objects along the route into the specified table.
- The optional parameter *RouteWeightingAttribute* of data type *string* sets the name of the attribute for the route weighting attribute for automatic routing. If the parameter is not passed, *Plant Simulation* does not weight the lengths of the routes.

Return Value

The return value has the data type *length*.

Is -1 if *Plant Simulation* did not find a route.

Example

```
print Track5.getRouteLength(Track26)
```

SimTalk

[Destination \[SimTalk\] - sensors](#)

[RouteWeightingAttr \[SimTalk\] - Transporter](#)

Read-Only Attributes of the Track

Read-Only Attributes of the Track

The *Track* provides:

- The *read-only attribute* [OccupiedLength \[SimTalk\] - Track](#).
- The [\\_Read-Only Attributes of All Objects](#).
- The [Read-Only Attributes of the Material Flow Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

