

Help Menu

The commands are described under the [Help Menu](#).

Methods of the AGVPool

_Methods of the AGVPool

The *AGVPool* provides:

- The *methods* listed in the table of contents to the left.
- The [Methods of All Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
contentsList	[]			([Contents:table]) -> any
createAttr				(NameOfUserDefinedAttribute:string, DataType:string) -> boolean
createIcon				(IconName:string, Width:integer, Height:integer) -> integer
deleteAttr				(NameOfUserDefinedAttribute:string) -> boolean

Name of the method Identifier and data type of the parameter you enter Data type of the return value

Name	Value	Inherited	Watchable	Signature
moveToFolder				(Folder:object) -> object
MU	VOID			([Index:integer:=1]) -> object
MUPart	VOID			([Index:integer:=1]) -> object

Name of the method Identifier and data type of the parameter you enter Default value Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

An example of the **Syntax** line of the individual methods might look like this:

```
<Path>.openDialog([CallOpenControl:boolean:=false]) → boolean
```

- The expression *<Path>* designates the path of the object to which the *method* applies.
- The signature of the method, consisting of the identifier and the data type of the parameter, is listed in parentheses. The expression *(Parameter:string)*, for example, designates a parameter of data type *string*. Instead of a constant value, you can also use a variable of the required type or a *method* that returns the required data type.

Note

Make sure to enter the parentheses for expressions within parentheses (...). Not entering them may lead to unexpected results and open the *Debugger*.

Optional parameters are listed within brackets. The expression *[,Parameter:boolean]*, for example, means that you can, but do not have to enter the *boolean* parameter.

If a parameter has a default value, the signature shows the default value after the parameter, *:= false* in the example above.

If the *method* has a return value, the signature shows its data type after the arrow *->*, *→ boolean* in the example above.

getAssignedAGV [SimTalk]

Returns the AGV designated by the number in the *AGVPool* designated by <Path>.

Type

Method

Syntax

```
<Path>.getAssignedAGV(No:integer) -> object
```

Parameter

The parameter *No* of data type *integer* designates the number of the AGV that is assigned.

Return Value

The return value has the data type *object*.

Example

```
print MyAGVPool.getAssignedAGV(2)  
-- might, for example, return .UserObjects.MyAGV:2
```

See also

[Assigned AGVs \[AGVPool\]](#)

getAssignedAGVsTable [SimTalk]

Returns the table containing the assigned AGVs of the *AGVPool* designated by <Path>.

Type

Method

Syntax

```
<Path>.getAssignedAGVsTable([AssignedAGVs:table]) -> any
```

Parameter

The optional parameter *AssignedAGVs* of data type *table* designates the name of the table into which the AGVs will be written.

If you do not specify the optional parameter, *Plant Simulation* returns an *array* with the assigned automated guided vehicles (AGVs).

Return Value

The return value has the data type *any*.

Examples

```
MyAGVPool.getAssignedAGVsTable(myAssignedAGVsTable) // writes the AGVs into  
the specified table
```

```
MyAGVPool.getAssignedAGVsTable // writes the AGVs to an array
```

See also

[Assigned AGVs \[AGVPool\]](#)

getIdleAGV [SimTalk]

Returns an AGV of the AGVPool designated by <Path> for which the attribute *IsIdle* has the value true.

Remarks

getIdleAGV also sets the attribute *IsIdle* of the returned AGV to false. You yourself are responsible to set *IsIdle* to true again if the AGV is to be available again, normally when the AGV has reached the end of the route.

Type

Method

Syntax

```
<Path>.getIdleAGV → object
```

Return Value

The return value has the data type *object*.

VOID if no idle AGV is available.

Example

```
waituntil AGVPool.NumIdleAGVs > 0  
var AGV := AGVPool.getIdleAGV
```

SimTalk

[IsIdle \[SimTalk\] - Transporter](#)

[NumIdleAGVs \[SimTalk\]](#)

See also

[Fine-position an AGV](#)

Read-Only Attributes of the AGVPool

_Read-Only Attributes of the AGVPool

The *AGVPool* provides: