

Read-Only Attributes of the Broker

_Read-Only Attributes of the Broker

The *Broker* provides:

- The *read-only attributes* listed in the table of contents to the left.
- The [_Read-Only Attributes of All Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
NumPartsSinceSetup	0			-> integer
NumPred	1			-> integer
NumSucc	3			-> integer

Name of the read-only attribute Current value of the read-only attribute Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

To query the value of a *read-only attribute*, you might, for example, type:

```
print MyBroker.OpenCapacity
```

AdministeredExporters [SimTalk]

Returns all *Exporters/Workers* which are registered with the *Broker* designated by <Path>.

Remarks

The array does not contain all *Exporters/Workers* that may be reached via the *Broker*-hierarchy, but only those that are registered directly with the *Broker*.

Type

Read-only attribute

Syntax

```
<Path>.AdministeredExporters → array
```

Return Value

The return value has the data type *array*.

Examples

```
print MyBroker.AdministeredExporters
```

```
var t :object[] := MyBroker.AdministeredExporters
```

See also

[Exporters \[Broker\]](#)

MediatedCapacity [SimTalk] - Broker

Returns the capacity which the *Broker* designated by <Path> brokered.

Type

Read-only attribute

Syntax

```
<Path>.MediatedCapacity → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyBroker.MediatedCapacity
```

See also

[Tab Statistics \[Broker\]](#)

OpenCapacity [SimTalk]

Returns the total amount of open capacities which the *Broker* designated by <Path> could not fulfill.

Type

Read-only attribute

Syntax

```
<Path>.OpenCapacity → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyBroker.OpenCapacity
```

See also

[Tab Statistics \[Broker\]](#)

OpenRequests [SimTalk]

Returns the actual number of open requests which the *Broker* designated by <Path> manages.

Type

Read-only attribute

Syntax

```
<Path>.OpenRequests → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyBroker.OpenRequests
```

See also

[Tab Statistics \[Broker\]](#)

SatisfiedRequests [SimTalk]

Returns the number requests which the *Broker* designated by <Path> fulfilled.

Type

Read-only attribute

Syntax

```
<Path>.SatisfiedRequests → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyBroker.SatisfiedRequests
```

See also

[Tab Statistics \[Broker\]](#)

StatMediatedCapacity [SimTalk]

Returns the total amount of brokered capacities which the *Broker* designated by <Path> manages.

Type

Read-only attribute

Syntax

```
<Path>.StatMediatedCapacity → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyBroker.StatMediatedCapacity
```

See also

[Tab Statistics \[Broker\]](#)

Statistics report, [Broker Statistics \[described\]](#)

StatMediationTime [SimTalk]

Returns the sum of the times which the *Broker* designated by <Path> required to meet all satisfied requests.

Remarks

This is the time during which the *importer/importers* were waiting for the services.

Type

Read-only attribute

Syntax

```
<Path>.StatMediationTime → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyBroker.StatMediationTime
```

See also

Statistics report, [Broker Statistics \[described\]](#)

StatMediationTimeDelta [SimTalk]

Returns the standard deviation of the medium procurement time which the *Broker* designated by <Path> required to meet all satisfied requests.

Type

Read-only attribute

Syntax

```
<Path>.StatMediationTimeDelta → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyBroker.StatMediationTimeDelta
```

See also

Statistics report, [Broker Statistics \[described\]](#)

StatMediationTimeMu [SimTalk]

Returns the medium duration of the time which the *Broker* designated by <Path> required to meet a single request.

Type

Read-only attribute

Syntax

```
<Path>.StatMediationTimeMu → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyBroker.StatMediationTimeMu
```

See also

Statistics report, [Broker Statistics \[described\]](#)

StatOpenCapacity [SimTalk]

Returns the total amount of open capacities which the *Broker* designated by <Path> manages.

Type

Read-only attribute

Syntax

```
<Path>.StatOpenCapacity → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyBroker.StatOpenCapacity
```

See also

[Tab Statistics \[Broker\]](#)

Statistics report, [Broker Statistics \[described\]](#)

StatOpenRequests [SimTalk]

Returns the total number of open requests which the *Broker* designated by <Path> manages.

Type

Read-only attribute

Syntax

```
<Path>.StatOpenRequests → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyBroker.StatOpenRequests
```

See also

[Tab Statistics \[Broker\]](#)

Statistics report, [Broker Statistics \[described\]](#)

StatSatisfiedRequests [SimTalk]

Returns the total number of requests which the *Broker* designated by <Path> satisfied.

Type

Read-only attribute

Syntax

```
<Path>.StatSatisfiedRequests → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyBroker.StatSatisfiedRequests
```

See also

[Tab Statistics \[Broker\]](#)

Statistics report, [Broker Statistics \[described\]](#)

StatStayTime [SimTalk]

Returns the sum of the times during which *Exporters/Workers* stayed at *importers*.

Remarks

These are the times during which the services managed by the *Broker* designated by <Path> were brokered.

Type

Read-only attribute

Syntax

```
<Path>.StatStayTime → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyBroker.StatStayTime
```

See also

Statistics report, [Broker Statistics \[described\]](#)

StatStayTimeDelta [SimTalk]

Returns the standard deviation of the time during which *Exporters/Workers* stayed at *importers* who are managed by the *Broker* designated by <Path>.

Type

Read-only attribute

Syntax

```
<Path>.StatStayTimeDelta → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyBroker.StatStayTimeDelta
```

See also

Statistics report, [Broker Statistics \[described\]](#)

StatStayTimeMu [SimTalk]

Returns the medium duration of the time during which *Exporters/Workers* stayed at a single *importer* who is managed by the *Broker* designated by <Path>.

Type

Read-only attribute

Syntax

```
<Path>.StatStayTimeMu → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyBroker.StatStayTimeMu
```

See also

Statistics report, [Broker Statistics \[described\]](#)

Attributes of the Broker

_Attributes of the Broker

The *Broker* provides:

- The *attributes* listed in the table of contents to the left.
- The [Attributes of All Objects](#).
- The [Attributes of the Material Flow Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.