

hasService [SimTalk]

Returns if the *Exporter/Worker* designated by <Path> supports the designated service (true) or not (false).

Type

Method

Syntax

```
<Path>.hasService(ServiceName:string) → boolean
```

Parameter

The parameter *ServiceName* of data type *string* designates the name of the service.

Return Value

The return value has the data type *boolean*.

Example

```
MyExporter.hasService("drill")
```

SimTalk

[Services \[SimTalk\] - Exporter](#)

See also

[Services \[Exporter\]](#)

[Exported Services \[Exporter\]](#)

[Exported Services \[Worker\]](#)

Read-Only Attributes of the Exporter

Read-Only Attributes of the Exporter

The *Exporter* provides:

- The *read-only attributes* listed in the table of contents to the left.
- The [_Read-Only Attributes of All Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
NumPartsSinceSetup	0			-> integer
NumPred	1			-> integer
NumSucc	3			-> integer

Name of the read-only attribute Current value of the read-only attribute Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected **Class** [general description].
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected **Instance** [general description].

To query the value of a *read-only attribute*, you might, for example, type:

```
print .Resources.myExporter:2.AvailableForMediation
```

AvailableForMediation [SimTalk] - Exporter

Returns if the *Exporter* designated by <Path> can be brokered (true) or not (false).

Type

Read-only attribute

Syntax

```
<Path>.AvailableForMediation → boolean
```

Watchable

The read-only attribute is [watchable](#).

Return Value

The return value has the data type *boolean*.

true if the *Exporter* is not failed, not paused, and has available capacity.

Example

```
print .UserObjects.MyExporter:2.AvailableForMediation
```

FreeCapacity [SimTalk]

Returns the capacity which the *Exporter* designated by <Path> can provide at the moment.

Type

Read-only attribute

Syntax

```
<Path>.FreeCapacity → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.FreeCapacity
```

See also

[Tab Statistics \[Exporter\]](#)

MediatedCapacity [SimTalk] - Exporter

Returns the capacity which the *Exporter* designated by <Path> brokers at the moment.

Type

Read-only attribute

Syntax

```
<Path>.MediatedCapacity → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.MediatedCapacity
```

See also

[Tab Statistics \[Exporter\]](#)

StatExporterFailedCount [SimTalk]

Returns how often the *Exporter* designated by <Path> was failed.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterFailedCount → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.StatExporterFailedCount
```

StatExporterFailedDelta [SimTalk]

Returns the standard deviation of the failure time of the *Exporter* designated by <Path> from the mean value.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterFailedDelta → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatExporterFailedDelta
```

StatExporterFailedMu [SimTalk]

Returns the mean duration of a failure of the *Exporter* designated by <Path>.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterFailedMu → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatExporterFailedDelta
```


StatExporterFailedPortion [SimTalk]

Returns the ratio of the times during which the *Exporter* designated by <Path> was failed to the statistics collection period of the *Exporter*.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterFailedPortion → real
```

Return Value

The return value has the data type *real*.

Example

```
print MyExporter.StatExporterFailedPortion
```

See also

[Tab Statistics \[Exporter\]](#)

[Tab Statistics \[Worker\]](#)

Statistics report, [Service Statistics — States — Capacities and States of the Exporters](#)

StatExporterFailedTime [SimTalk]

Returns the total time during which the *Exporter* designated by <Path> was failed.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterFailedTime → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatExporterFailedTime
```

StatExporterOperationalPortion [SimTalk]

Returns the ratio of the working time of the *Exporter* designated by <Path> to the statistics collection period of the *Exporter*.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterOperationalPortion → real
```

Return Value

The return value has the data type *real*.

Note

As the *Exporter* computes the values that apply to the state **working**, it only provides the read-only attributes *StatExporterOperationalPortion* and *StatExporterOperationalTime*.

Example

```
print MyExporter.StatExporterOperationalPortion
```

SimTalk

StatExporterOperationalTime

See also

[Tab Statistics](#) of the *Exporter*

Statistics report, [Service Statistics — States — Capacities and States of the Exporters](#)

StatExporterOperationalTime [SimTalk]

Returns the total time taken up by working processes of the *Exporter* designated by <Path>.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterOperationalTime → time
```

Return Value

The return value has the data type *time*.

Note

As the *Exporter* computes the values that apply to the state **working**, it only provides the read-only attributes *StatExporterOperationalPortion* and *StatExporterOperationalTime*.

Example

```
print MyExporter.StatExporterOperationalTime
```

SimTalk

StatExporterOperationalPortion [SimTalk]

StatExporterPausedCount [SimTalk]

Returns how often the *Exporter* designated by <Path> was paused.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterPausedCount → time
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.StatExporterPausedCount
```

StatExporterPausedDelta [SimTalk]

Returns the standard deviation of the paused time of the *Exporter* designated by <Path> from the mean value.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterPausedDelta → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatExporterPausedDelta
```

StatExporterPausedMu [SimTalk]

Returns the mean duration of a pause of the *Exporter* designated by <Path>.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterPausedMu → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatExporterPausedMu
```

StatExporterPausedPortion [SimTalk]

Returns the ratio of the paused time of the *Exporter* designated by <Path> to the statistics collection period of the *Exporter*.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterPausedPortion → real
```

Return Value

The return value has the data type *real*.

Example

```
print MyExporter.StatExporterPausedPortion
```

See also

[Tab Statistics \[Exporter\]](#)

[Tab Statistics \[Worker\]](#)

Statistics report, [Service Statistics — States — Capacities and States of the Exporters](#)

StatExporterPausedTime [SimTalk]

Returns the total time during which the *Exporter* designated by <Path> was paused.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterPausedTime → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatExporterPausedTime
```

StatExporterUnplannedCount [SimTalk]

Returns how often the *Exporter* designated by <Path> was not planned to work.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterUnplannedCount → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.StatExporterUnplannedCount
```

StatExporterUnplannedDelta [SimTalk]

Returns the standard deviation of the unplanned time of the *Exporter* designated by <Path> from the mean value.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterUnplannedDelta → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatExporterUnplannedDelta
```

StatExporterUnplannedMu [SimTalk]

Returns the mean duration of the unplanned time of the *Exporter* designated by <Path>.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterUnplannedMu → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatExporterUnplannedMu
```

StatExporterUnplannedPortion [SimTalk]

Returns the ratio of the unplanned time to the statistics collection period of the *Exporter* designated by <Path>.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterUnplannedPortion → real
```

Return Value

The return value has the data type *real*.

Example

```
print MyExporter.StatExporterUnplannedPortion
```

See also

[Tab Statistics \[Exporter\]](#)

[Tab Statistics \[Worker\]](#)

Statistics report, [Service Statistics — States — Capacities and States of the Exporters](#)

StatExporterUnplannedTime [SimTalk]

Returns the total time during which the *Exporter* designated by <Path> was not planned to work.

Type

Read-only attribute

Syntax

```
<Path>.StatExporterUnplannedTime → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatExporterUnplannedTime
```

StatMaxFreeCapacity [SimTalk]

Returns the maximum capacity which the *Exporter* designated by <Path> can provide.

Type

Read-only attribute

Syntax

```
<Path>.StatMaxFreeCapacity → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.StatMaxFreeCapacity
```

See also

[Tab Statistics \[Exporter\]](#)

Statistics report, [Service Statistics — States — Capacities and States of the Exporters](#)

StatMaxMediatedCapacity [SimTalk]

Returns the maximum occupied capacity of the *Exporter* designated by <Path>.

Type

Read-only attribute

Syntax

```
<Path>.StatMaxMediatedCapacity → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.StatMaxMediatedCapacity
```

See also

[Tab Statistics \[Exporter\]](#)

Statistics report, [Service Statistics — States — Capacities and States of the Exporters](#)

StatMinFreeCapacity [SimTalk]

Returns the minimum capacity which *Exporter* designated by <Path> can provide.

Type

Read-only attribute

Syntax

```
<Path>.StatMinFreeCapacity → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.StatMinFreeCapacity
```

See also

[Tab Statistics \[Exporter\]](#)

Statistics report, [Service Statistics — States — Capacities and States of the Exporters](#)

StatMinMediatedCapacity [SimTalk]

Returns the minimum occupied capacity of the *Exporter* designated by <Path>.

Type

Read-only attribute

Syntax

```
<Path>.StatMinMediatedCapacity → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.StatMinMediatedCapacity
```

See also

[Tab Statistics \[Exporter\]](#)

Statistics report, [Service Statistics — States — Capacities and States of the Exporters](#)

StatServicesFailedCount [SimTalk] - Exporter

Returns how often the services of the *Exporter* designated by <Path> were failed.

Remarks

The *Exporter* only collects failure times for the services if you activate *FailServices*.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesFailedCount → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.StatServicesFailedCount
```

SimTalk

[FailServices \[SimTalk\]](#)

StatServicesFailedPortion [SimTalk] - Exporter

Returns the portion of the failed times of the services of the overall statistics time of the *Exporter* designated by <Path>, weighted with the capacity.

Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

Note

The *Exporter* only collects failure times for the services if you activate *FailServices*.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesFailedPortion → real
```

Return Value

The return value has the data type *real*.

Example

```
print MyExporter.StatServicesFailedPortion
```

SimTalk

[FailServices \[SimTalk\]](#)

See also

[Tab Statistics \[Exporter\]](#)

Statistics report, [Service Statistics — States — Time Portions of the Exporters](#)

StatServicesFailedTime [SimTalk] - Exporter

Returns the total time during which services of the *Exporter* designated by <Path> were failed.

Remarks

The *Exporter* only collects failure times for the services if you activate *FailServices*.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesFailedTime → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatServicesFailedTime
```

SimTalk

[FailServices \[SimTalk\]](#)

StatServicesRepairingCount [SimTalk] - Exporter

Returns how often the services of the *Exporter* designated by <Path> worked on repairs.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesRepairingCount → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.StatServicesRepairingCount
```

StatServicesRepairingPortion [SimTalk] - Exporter

Returns the portion of the repairing time of the *services* of the overall statistics time of the *Exporter* designated by <Path>, weighted with the capacity.

Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesRepairingPortion → real
```

Return Value

The return value has the data type *real*.

Example

```
print MyExporter.StatServicesRepairingPortion
```

See also

[Tab Statistics \[Exporter\]](#)

Statistics report, [Service Statistics — States — Time Portions of the Exporters](#)

StatServicesRepairingTime [SimTalk] - Exporter

Returns the total time which the *services* of the *Exporter* designated by <Path> spent for repairs.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesRepairingTime → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatServicesRepairingTime
```


StatServicesSetupCount [SimTalk] - Exporter

Returns how often the services of the *Exporter* designated by <Path> were setting the station up.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesSetupCount → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.StatServicesSetupCount
```

StatServicesSetupPortion [SimTalk] - Exporter

Returns the portion of the set-up time of the services of the overall statistics time of the *Exporter* designated by <Path>, weighted with the capacity.

Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

Note

If a station changes to the state **failed** and/or **unplanned** or **paused** and if then services for setting-up or processing are brokered, the services remain brokered. The set-up time and the processing time for the services thus continues while the station is failed.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesSetupPortion → real
```

Return Value

The return value has the data type *real*.

Example

```
print MyExporter.StatServicesSetupPortion
```

See also

[Tab Statistics \[Exporter\]](#)

Statistics report, [Service Statistics — States — Time Portions of the Exporters](#)

StatServicesSetupTime [SimTalk] - Exporter

Returns the total time the services of the *Exporter* designated by <Path> were setting the station up.

Remarks

Note

If a station changes to the state **failed** and/or **unplanned** or **paused** and if then services for setting-up or processing are brokered, the services remain brokered. The set-up time and the processing time for the services thus continues while the station is failed.

Note

If a station changes to the state **failed** and services for setting-up or processing are brokered for this station, the services remain assigned. For this reason the set-up time and the processing time for the services carry on running while the station is failed. To avoid this, activate [FailServices \[SimTalk\]](#).

Type

Read-only attribute

Syntax

```
<Path>.StatServicesSetupTime → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatServicesSetupTime
```

SimTalk

[FailServices \[SimTalk\]](#)

StatServicesWaitingImpCount [SimTalk] - Exporter

Returns how often the *services* of the *Exporter* designated by <Path> waited for an *importer*.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesWaitingImpCount → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.StatServicesWaitingImpCount
```

StatServicesWaitingImpPortion [SimTalk] - Exporter

Returns the portion of the overall statistics time which the *services* of the *Exporter* designated by <Path> spent waiting for an *importer*, weighted with the capacity.

Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesWaitingImpPortion → real
```

Return Value

The return value has the data type *real*.

Example

```
print MyExporter.StatServicesWaitingImpPortion
```

See also

[Tab Statistics \[Exporter\]](#) of the *Exporter*

Statistics report, [Service Statistics — States — Time Portions of the Exporters](#)

StatServicesWaitingImpTime [SimTalk] - Exporter

Returns the total waiting time of the *services* of the *Exporter* designated by <Path> for an *importer*.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesWaitingImpTime → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatServicesWaitingImpTime
```

StatServicesWaitingMUCount [SimTalk] - Exporter

Returns how often the *services* of the *Exporter* designated by <Path> spent waiting for a *MU* at the *importer*.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesWaitingMUCount → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.StatServicesWaitingMUCount
```

StatServicesWaitingMUPortion [SimTalk] - Exporter

Returns the waiting portion for a *MU* at the *importer* of the *services* of the overall statistics time of the *Exporter* designated by <Path>, weighted with the capacity.

Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesWaitingMUPortion → real
```

Return Value

The return value has the data type *real*.

Example

```
print MyExporter.StatServicesWaitingMUPortion
```

See also

[Tab Statistics \[Exporter\]](#)

Statistics report, [Service Statistics — States — Time Portions of the Exporters](#)

StatServicesWaitingMUTime [SimTalk] - Exporter

Returns the total time the *services* of the *Exporter* designated by <Path> were waiting at the *importer* for a *MU*.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesWaitingMUTime → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatServicesWaitingMUTime
```

StatServicesWaitingPortion [SimTalk] - Exporter

Returns the portion of the waiting time of the services of the overall statistics time of the *Exporter* designated by <Path>, weighted with the capacity.

Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

Note

The value of *StatServicesWaitingPortion* is the sum of *StatServicesWaitingImpPortion* and *StatServicesWaitingMUPortion*.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesWaitingPortion → time
```

Return Value

The return value has the data type *real*.

Example

```
print MyExporter.StatServicesWaitingPortion
```

SimTalk

[StatServicesWaitingImpPortion \[SimTalk\] - Exporter](#)

[StatServicesWaitingMUPortion \[SimTalk\] - Exporter](#)

StatServicesWaitingTime [SimTalk] - Exporter

Returns the time which the *services* of the *Exporter* designated by <Path> were waiting in relation to the statistics collection period, weighted with the capacity.

Remarks

The value of *StatServicesWaitingTime* is the sum of *StatServicesWaitingImpTime* and *StatServicesWaitingMUTime*.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesWaitingTime → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatServicesWaitingTime
```

SimTalk

[StatServicesWaitingImpTime \[SimTalk\] - Exporter](#)

[StatServicesWaitingMUTime \[SimTalk\] - Exporter](#)

StatServicesWorkingCount [SimTalk] - Exporter

Returns the number of working processes which the *services* of the *Exporter* designated by <Path> provided.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesWorkingCount → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.StatServicesWorkingCount
```

StatServicesWorkingPortion [SimTalk] - Exporter

Returns the portion of the working time of the *services* of the overall statistics time of the *Exporter* designated by <Path>, weighted with the capacity.

Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

Note

If a station changes to the state **failed** and/or **unplanned** or **paused** and if then services for setting-up or processing are brokered, the services remain brokered. The set-up time and the processing time for the services thus continues while the station is failed.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesWorkingPortion → real
```

Return Value

The return value has the data type *real*.

Example

```
print MyExporter.StatServicesWorkingPortion
```

See also

[Tab Statistics \[Exporter\]](#)

Statistics report, [Service Statistics — States — Time Portions of the Exporters](#)

StatServicesWorkingTime [SimTalk] - Exporter

Returns the time taken up by working processes of the *services* of the *Exporter* designated by <Path>.

Remarks

If a station changes to the state **failed** and/or **unplanned** or **paused** and if then services for setting-up or processing are brokered, the services remain brokered. The set-up time and the processing time for the services thus continues while the station is failed. To avoid this, activate *FailServices*.

Type

Read-only attribute

Syntax

```
<Path>.StatServicesWorkingTime → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyExporter.StatServicesWorkingTime
```

SimTalk

[FailServices \[SimTalk\]](#)

StatSumFreeCapacity [SimTalk]

Returns the sum of the free capacity of the *Exporter* designated by <Path>.

Type

Read-only attribute

Syntax

```
<Path>.StatSumFreeCapacity → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.StatSumFreeCapacity
```

See also

[Tab Statistics \[Exporter\]](#)

Statistics report, [Service Statistics — States — Capacities and States of the Exporters](#)

StatSumMediatedCapacity [SimTalk]

Returns the sum of the brokered capacity of the *Exporter* designated by <Path>.

Type

Read-only attribute

Syntax

```
<Path>.StatSumMediatedCapacity → integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyExporter.StatSumMediatedCapacity
```

See also

[Tab Statistics \[Exporter\]](#)

Statistics report, [Service Statistics — States — Capacities and States of the Exporters](#)

Attributes of the Exporter

Attributes of the Exporter

The *Exporter* provides:

- The *attributes* listed in the table of contents to the left.
- The [Attributes of All Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.