

- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

To query the value of a *read-only attribute*, you might, for example, type:

```
print MyFootPath.UUID
```

Attributes of the FootPath

_Attributes of the FootPath

The *FootPath* provides:

- The *attributes* listed in the table of contents to the left.
- The [Attributes of All Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
MoveToFolderCtrl	VOID	✓		method
MTTR	0.0000			time
Name	"Station"	✓	*	string

Name of the attribute Current value of the attribute Data type of the assignment value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

You can set the value of an attribute and you can get its value, either with the check boxes, the text boxes and drop-down lists in the dialog windows or by assigning values to the respective attributes.

- To **set the value** of an attribute, you might, for example, type:

```
MyFootPath.length := 5
```

- To **get the value** of an attribute, you might, for example, type:

```
print MyFootPath.length  
posit := Station.Cont.XPos
```

Length [SimTalk] - FootPath

Sets the physical **Length** of the *Footpath* designated by <Path>.

Remarks

A *Worker* enters the *FootPath* at position 0 and exits it after covering the length you specify.

Type

Attribute

Syntax

```
<Path>.Length: length
```

Assignment Value

You can assign a value of data type *length*.

Note

In *SimTalk* 2.0 you can specify the length units m, mm, km, cm, yd, ft, and in.

Type in the unit directly after the values, without a separating blank space, for example 10m or 10.2m.

You can specify the unit for *floating point values* and for *integer values*.

Example

```
MyFootPath.Length := 44m
```

See also

Length [text box] - FootPath

Width [SimTalk] - FootPath

Sets the **Width** of the *Footpath* designated by <Path>.

Type

Attribute

Syntax

```
<Path>.Width:length
```

Assignment Value

You can assign a value of data type *length*.

Note

In *SimTalk* 2.0 you can specify the length units m, mm, km, cm, yd, ft, and in.

Type in the unit directly after the values, without a separating blank space, for example 10m or 10.2m.

You can specify the unit for *floating point values* and for *integer values*.

Example

```
MyFootPath.Width := 2 // meters
```

See also

[Width \[text box\] - FootPath](#)

WorkerPool

WorkerPool

Use the object *WorkerPool* for modeling the lounge or the staff room of your plant.

Image

