

addObject [SimTalk] - LockoutZone

Adds a single object to the *LockoutZone* designated by <Path>.

Type

Method

Syntax

```
<Path>.addObject(NameOfObject:path) → boolean
```

Parameter

The parameter *NameOfObject* of data type *path* designates the name of the object you want to add.

Return Value

The return value has the data type *boolean*.

Example

```
MyLockoutZone.addObject(MyParallelStation)
```

SimTalk

[Objects \[SimTalk\] - LockoutZone](#)

See also

[Tab Objects](#)

Read-Only Attributes of the LockoutZone

Read-Only Attributes of the LockoutZone

The *LockoutZone* provides:

- The *read-only attributes* listed in the table of contents to the left.
- The [_Read-Only Attributes of All Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute*

corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
NumPartsSinceSetup	0			-> integer
NumPred	1			-> integer
NumSucc	3			-> integer

Name of the read-only attribute Current value of the read-only attribute Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected **Class [general description]**.
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected **Instance [general description]**.

To query the value of a *read-only attribute*, you might, for example, type:

```
print MyLockoutZone.StatStoppedCount
```

StatStoppedCount [SimTalk] - LockoutZone

Returns how often the *LockoutZone* designated by <Path> stopped the assigned stations.

Type

Read-only attribute

Syntax

```
<Path>.StatStoppedCount → integer
```

Watchable

The read-only attribute is [watchable](#).

Return Value

The return value has the data type *integer*.

Example

```
print MyLockoutZone.StatStoppedCount
```

See also

[Tab Statistics \[LockoutZone\]](#)

StatStoppedDelta [SimTalk] - LockoutZone

Returns the standard deviation of the time during which the *LockoutZone* designated by <Path> stopped the processing operations of the assigned stations.

Type

Read-only attribute

Syntax

```
<Path>.StatStoppedDelta → time
```

Watchable

The read-only attribute is [watchable](#).

Return Value

The return value has the data type *time*.

Example

```
print MyLockoutZone.StatStoppedDelta
```

See also

[Tab Statistics \[LockoutZone\]](#)

StatStoppedIntervalDelta [SimTalk]

Returns the standard deviation of the intervals during which the *LockoutZone* designated by <Path> stopped the processing operations of the assigned stations.

Type

Read-only attribute

Syntax

```
<Path>.StatStoppedIntervalDelta → time
```

Watchable

The read-only attribute is [watchable](#).

Return Value

The return value has the data type *time*.

Example

```
print MyLockoutZone.StatStoppedIntervalDelta
```

See also

[Tab Statistics \[LockoutZone\]](#)

StatStoppedIntervalMu [SimTalk]

Returns the mean time of the intervals during which the *LockoutZone* designated by <Path> stopped the processing operations of the assigned stations.

Type

Read-only attribute

Syntax

```
<Path>.StatStoppedIntervalMu → time
```

Watchable

The read-only attribute is [watchable](#).

Return Value

The return value has the data type *time*.

Example

```
print MyLockoutZone.StatStoppedIntervalMu
```

See also

[Tab Statistics \[LockoutZone\]](#)

StatStoppedIntervalTime [SimTalk]

Returns the total time of the intervals during which the *LockoutZone* designated by <Path> stopped the processing operations of the assigned stations.

Type

Read-only attribute

Syntax

```
<Path>.StatStoppedIntervalTime → time
```

Return Value

The return value has the data type *time*.

Example

```
print MyLockoutZone.StatStoppedIntervalTime
```

See also

[Tab Statistics \[LockoutZone\]](#)

StatStoppedMu [SimTalk] - LockoutZone

Returns the mean time during which the *LockoutZone* designated by <Path> stopped the processing operations of the assigned stations.

Type

Read-only attribute

Syntax

```
<Path>.StatStoppedMu → time
```

Watchable

The read-only attribute is [watchable](#).

Return Value

The return value has the data type *time*.

Example

```
print MyLockoutZone.StatStoppedMu
```

See also

[Tab Statistics \[LockoutZone\]](#)

StatStoppedPortion [SimTalk] - LockoutZone

Returns the portion of the statistics collection period during which the stations were stopped by the *LockoutZone* designated by <Path>.

Type

Read-only attribute

Syntax

```
<Path>.StatStoppedPortion → real
```

Watchable

The read-only attribute is **watchable**.

Return Value

The return value has the data type *real*.

Example

```
print MyLockoutZone.StatStoppedPortion
```

See also

[Tab Statistics \[LockoutZone\]](#)

StatStoppedTime [SimTalk]

Returns the total time during which the *LockoutZone* designated by <Path> stopped the processing operations of the assigned stations.

Type

Read-only attribute

Syntax

```
<Path>.StatStoppedTime → time
```

Watchable

The read-only attribute is [watchable](#).

Return Value

The return value has the data type *time*.

Example

```
print MyLockoutZone.StatStoppedTime
```

See also

[Tab Statistics \[LockoutZone\]](#)

Attributes of the LockoutZone

_Attributes of the LockoutZone

The *LockoutZone* provides:

- The *attributes* listed in the table of contents to the left.
- The [Attributes of All Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.