

getRouteLength [SimTalk] - Marker

Returns the route length of the *Marker* designated by <Path> to the specified destination.

Type

Method

Syntax

```
<Path>.getRouteLength(ToMarker:path[, byref ObjectsAlongRoute:object[],  
RouteWeightingAttribute:string]) → length
```

Parameters

You can specify the following parameters:

- The parameter *ToMarker* of data type *path* designates the destination object.
- The optional parameter *ObjectsAlongRoute* designates an *array* of data type *object* into which the *Marker* enters the objects along the route to the destination.
- The optional parameter *RouteWeightingAttribute* of data type *string* designates the name of the **Route Weighting Attribute** for automatic routing. If the parameter is not passed, *Plant Simulation* does not weight the lengths of the routes.

Return Value

The return value has the data type *length*.

If the destination is not reachable, *Plant Simulation* returns the value -1.

Example

```
print Marker1.getRouteLength(Marker2)
```

Read-Only Attributes of the Marker

Read-Only Attributes of the Marker

The *Marker* provides the [_Read-Only Attributes of All Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
NumPartsSinceSetup	0			-> integer
NumPred	1			-> integer
NumSucc	3			-> integer

Name of the read-only attribute Current value of the read-only attribute Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected **Class** [general description].
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected **Instance** [general description].

To query the value of a *read-only attribute*, you might, for example, type:

```
print MyMarker.UUID
```

Attributes of the Marker

_Attributes of the Marker

The *Marker* provides:

- The *attributes* listed in the table of contents to the left.
- The **Attributes of All Objects**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.