

```
str_to_time("10:00:00.0") // 10
hours
endDateAndTime := MyShiftCalendar.schedule(startDateAndTime, Duration,
"forward") // Monday 12:00
```

See also

[Schedule Date and Time to Start or Finish the Production Process](#)

Read-Only Attributes of the ShiftCalendar

_Read-Only Attributes of the ShiftCalendar

The *ShiftCalendar* provides:

- The *read-only attributes* listed in the table of contents to the left.
- The [Read-Only Attributes of All Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
NumPartsSinceSetup	0			-> integer
NumPred	1			-> integer
NumSucc	3			-> integer

Name of the read-only attribute Current value of the read-only attribute Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

To query the value of a *read-only attribute*, you might, for example, type:

```
print MyShiftCalendar.Unplanned
```

GetCurrShift [SimTalk]

Returns the name of the shift of the *ShiftCalendar* designated by <Path> that is currently active.

Remarks

This is the name you typed into the column **Shift** on the **tab Shift Times**.

Type

Read-only attribute

Syntax

```
<Path>.GetCurrShift → string
```

Watchable

The read-only attribute is [watchable](#).

Return Value

The return value has the data type *string*.

Example

```
shift := root.MyShiftCalendar.GetCurrShift
```

See also

[Tab Shift Times](#)

[Shift \[ShiftCalendar\]](#)

Pause [SimTalk] - ShiftCalendar

Returns if the *ShiftCalendar* designated by <Path> is **paused** (true) or not (false).

Type

Read-only attribute

Syntax

```
<Path>.Pause → boolean
```

Watchable

The read-only attribute is **watchable**.

Return Value

The return value has the data type *boolean*.

Example

```
print MyShiftCalendar.Pause
```

See also

[Paused \[state, material flow objects\]](#)

Unplanned [SimTalk] - ShiftCalendar

Returns, if the *ShiftCalendar* designated by <Path> is **unplanned** (true) or not (false).

Type

Read-only attribute

Syntax

```
<Path>.Unplanned → boolean
```

Watchable

The read-only attribute is **watchable**.

Return Value

The return value has the data type *boolean*.

Example

```
print MyShiftCalendar.Unplanned
```

See also

[Unplanned \[state, material flow objects\]](#)

Attributes of the ShiftCalendar

_Attributes of the ShiftCalendar

The *ShiftCalendar* provides:

- The *attributes* listed in the table of contents to the left.
- The [Attributes of All Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.