

Examples

```
MyWorkerPool.setWorkersToCreateTable(MyWorkersToCreateTable)
```

```
var rt: table // read the Workers to Create
table
MyWorkerPool.getWorkersToCreateTableRow(rt) // set the new amount
rt [2,1]:= AmountOfWorkers // name of a Variable
// assign the Workers to
Create table
// to the WorkerPool
MyWorkerPool.setWorkersToCreateTable(rt)
```

SimTalk

[getWorkersToCreateTable \[SimTalk\]](#)

[getWorkersToCreateTableRow \[SimTalk\] - WorkerPool](#)

See also

[Workers to Create](#)

[Tab Scope](#)

[Home Location](#)

[The Relative Path](#)

[Relational Operators](#)

Read-Only Attributes of the WorkerPool

Read-Only Attributes of the WorkerPool

The *WorkerPool* provides these read-only attributes:

- The *read-only attributes* listed in the table of contents to the left.
- The [_Read-Only Attributes of All Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
NumPartsSinceSetup	0			-> integer
NumPred	1			-> integer
NumSucc	3			-> integer

Name of the read-only attribute Current value of the read-only attribute Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected **Class** [general description].
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected **Instance** [general description].

To query the value of a *read-only attribute*, you might, for example, type:

```
print MyWorkerPool.StatAverageTraveledDistance
```

NumAssignedWorkers [SimTalk]

Returns the amount of *Workers* which the *WorkerPool* designated by <Path> assigned.

Type

Read-only attribute

Syntax

```
<Path>.NumAssignedWorkers -> integer
```

Return Value

The return value has the data type *integer*.

Example

```
print MyWorkerPool.NumAssignedWorkers
```

SimTalk

[getAssignedWorkersTable \[SimTalk\]](#)

[getAssignedWorker \[SimTalk\]](#)

NumIdleWorkers [SimTalk]

Returns the number of *Workers* in the *WorkerPool* designated by <Path> who are idle, i.e., not working.

Type

Read-only attribute

Syntax

```
<Path>.NumIdleWorkers -> integer
```

Watchable

The attribute is [watchable](#).

Return Value

The return value has the data type *integer*.

Example

```
waituntil WorkerPool.NumIdleWorkers > 0  
var worker:object := WorkerPool.getIdleWorker
```

SimTalk

[IsIdle \[SimTalk\] - Worker](#)

[getIdleWorker \[SimTalk\]](#)

StatAverageTraveledDistance [SimTalk] - WorkerPool

Returns the average distance in meters which the *Worker* traveled from the *WorkerPool* designated by <Path> to the *Workplaces* attached to the stations and between the *stations*.

Type

Read-only attribute

Syntax

```
<Path>.StatAverageTraveledDistance → length
```

Return Value

The return value has the data type *length*.

Example

```
print MyWorkerPool.StatAverageTraveledDistance
```

Attributes of the WorkerPool

_Attributes of the WorkerPool

The *WorkerPool* provides:

- The *attributes* listed in the table of contents to the left.
- The [Attributes of All Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
MoveToFolderCtrl	VOID	✓		method
MTTR	0.0000			time
Name	"Station"	✓	*	string

Name of the attribute Current value of the attribute Data type of the assignment value