

Help Menu

The commands are described under the [Help Menu](#).

Methods of the Workplace

_Methods of the Workplace

The *Workplace* provides:

- The *methods* listed in the table of contents to the left.
- The [Methods of All Objects](#).
- The [Methods of the Material Flow Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
contentsList	[]			([Contents:table]) -> any
createAttr				(NameOfUserDefinedAttribute:string, DataType:string) -> boolean
createIcon				([IconName:string, Width:integer, Height:integer]) -> integer
deleteAttr				(NameOfUserDefinedAttribute:string) -> boolean

Name of the method Identifier and data type of the parameter you enter Data type of the return value

Name	Value	Inherited	Watchable	Signature
moveToFolder				(Folder:object) -> object
MU	VOID			([Index:integer: =1]) -> object
MUPart	VOID			([Index:integer: =1]) -> object

Name of the method Identifier and data type of the parameter you enter Default value Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

An example of the **Syntax** line of the individual methods might look like this:

```
<Path>.openDialog([CallOpenControl:boolean:=false]) → boolean
```

- The expression *<Path>* designates the path of the object to which the *method* applies.
- The signature of the method, consisting of the identifier and the data type of the parameter, is listed in parentheses. The expression *(Parameter:string)*, for example, designates a parameter of data type *string*. Instead of a constant value, you can also use a variable of the required type or a *method* that returns the required data type.

Note

Make sure to enter the parentheses for expressions within parentheses (...). Not entering them may lead to unexpected results and open the *Debugger*.

Optional parameters are listed within brackets. The expression *[,Parameter:boolean]*, for example, means that you can, but do not have to enter the *boolean* parameter.

If a parameter has a default value, the signature shows the default value after the parameter, *:= false* in the example above.

If the *method* has a return value, the signature shows its data type after the arrow *->*, *→ boolean* in the example above.

contentsList [SimTalk] - Workplace

Returns an *array* containing the entire contents, i.e., all *Workers* located in the **Contents List** of the *Workplace* designated by <Path>.

Syntax

```
<Path>.contentsList([ContentsList:table]) → any
```

Parameter

The optional parameter *ContentsList* of data type *table* designates the name of the table (a *DataTable* or a local variable) into which the method writes the values. *Plant Simulation* automatically generates the format of this table, and deletes any existing format and contents of the table.

Return Value

The return value has the data type *any*.

Example

```
workplace2.contentsList(MyContentsList)  
print workplace2.contentsList
```

See also

[Contents \[material flow objects\]](#)

[Contents \[Workplace\]](#)

getRouteCoordinates [SimTalk]

Returns the 3D-coordinates of the waypoints of the route which a *Worker* would have to cover to get from the *Workplace* designated by <Path> to another *Workplace* or to the *WorkerPool*.

Type

Method

Syntax

```
<Path>.getRouteCoordinates(ToWorkplace:path[,  
FreelyWithinArea:boolean:=false]) → array
```

Parameters

You can specify the following parameters:

- The parameter *ToWorkplace* of data type *path* designates the *Workplace* which is the destination *Workplace* of the route.
- The optional parameter *FreelyWithinArea* of data type *boolean* sets if the *Worker* gets to the *Workplace* by walking freely within the area or not.

Specify `false` or do not specify the parameter to compute the waypoints of the route between the two *Workplaces* via *Footpaths* which are connected with *Connectors*.

Specify `true` to compute the waypoints of the route in the area, i.e., the route of the *Worker*, who is walking freely within the area, would take.

Default Value of the Parameter

The default value is `false`.

Return Value

The return value is a two-dimensional *array*.

It contains the **X-Coordinate**, the **Y-Coordinate**, and the **Z-Coordinate** of the waypoints.

Example

```
var coords:any := Workplace1.getRouteCoordinates(Workplace2)
print coords // outputs [[6.59, -6.0, 0.0] [6.60, -7.40, 0.0] [9.40, -7.40,
0.0] [13.690, -6.0, 0.0]]
```

getRouteLength [SimTalk] - Workplace

Returns the length of the route which a *Worker* would have to cover to get from the *Workplace* designated by <Path> to another *Workplace* or to the *WorkerPool*.

Type

Method

Syntax

```
<Path>.getRouteLength(ToWorkplace:path[, FreelyWithinArea:boolean:=false])
→ length
```

Parameters

You can specify the following parameters:

- The parameter *ToWorkplace* of data type *path* designates the *Workplace* which is the destination *Workplace*.
- The optional parameter *FreelyWithinArea* of data type *boolean* sets if the *Worker* gets to the *Workplace* by walking freely within the area or not.

Accept the default value `false` or do not specify the parameter to compute the route length between the two *Workplaces* via *Footpaths* which are connected with *Connectors*.

Specify `true` to compute the route length in the area, i.e., the route of the *Worker*, who is walking freely within the area, would take.

Default Value of the Parameter

The default value is `false`.

Return Value

The return value has the data type *length*.

Is -1 if *Plant Simulation* did not find a route.

```
var len:length := Workplace1.getRouteLength(Workplace2)
```

Read-Only Attributes of the Workplace

Read-Only Attributes of the Workplace

The *Workplace* provides the [_Read-Only Attributes of All Objects](#).