

getRouteLength [SimTalk] - Workplace

Returns the length of the route which a *Worker* would have to cover to get from the *Workplace* designated by <Path> to another *Workplace* or to the *WorkerPool*.

Type

Method

Syntax

```
<Path>.getRouteLength(ToWorkplace:path[, FreelyWithinArea:boolean:=false])  
→ length
```

Parameters

You can specify the following parameters:

- The parameter *ToWorkplace* of data type *path* designates the *Workplace* which is the destination *Workplace*.
- The optional parameter *FreelyWithinArea* of data type *boolean* sets if the *Worker* gets to the *Workplace* by walking freely within the area or not.

Accept the default value `false` or do not specify the parameter to compute the route length between the two *Workplaces* via *Footpaths* which are connected with *Connectors*.

Specify `true` to compute the route length in the area, i.e., the route of the *Worker*, who is walking freely within the area, would take.

Default Value of the Parameter

The default value is `false`.

Return Value

The return value has the data type *length*.

Is -1 if *Plant Simulation* did not find a route.

```
var len:length := Workplace1.getRouteLength(Workplace2)
```

Read-Only Attributes of the Workplace

Read-Only Attributes of the Workplace

The *Workplace* provides the [_Read-Only Attributes of All Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
NumPartsSinceSetup	0			-> integer
NumPred	1			-> integer
NumSucc	3			-> integer

Name of the read-only attribute Current value of the read-only attribute Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

To query the value of a *read-only attribute*, you might, for example, type:

```
print MyWorkplace.UUID
```

Attributes of the Workplace

_Attributes of the Workplace

The *Workplace* provides:

- The *attributes* listed in the table of contents to the left.
- The [Attributes of All Objects](#).
- The [Attributes of the Material Flow Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.