

Help Menu

The commands are described under the [Help Menu](#).

Methods of the Comment

_Methods of the Comment

The *Comment* provides:

- The *methods* listed in the table of contents to the left.
- The [Methods of All Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
contentsList	[]			((Contents:table)) -> any
createAttr				(NameOfUserDefinedAttribute:string, DataType:string) -> boolean
createIcon				(IconName:string, Width:integer, Height:integer) -> integer
deleteAttr				(NameOfUserDefinedAttribute:string) -> boolean

Name of the method Identifier and data type of the parameter you enter Data type of the return value

Name	Value	Inherited	Watchable	Signature
moveToFolder				(Folder:object) -> object
MU	VOID			([Index:integer:=1]) -> object
MUPart	VOID			([Index:integer:=1]) -> object

Name of the method Identifier and data type of the parameter you enter Default value Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

An example of the **Syntax** line of the individual methods might look like this:

```
<Path>.openDialog([CallOpenControl:boolean:=false]) → boolean
```

- The expression *<Path>* designates the path of the object to which the *method* applies.
- The signature of the method, consisting of the identifier and the data type of the parameter, is listed in parentheses. The expression *(Parameter:string)*, for example, designates a parameter of data type *string*. Instead of a constant value, you can also use a variable of the required type or a *method* that returns the required data type.

Note

Make sure to enter the parentheses for expressions within parentheses (...). Not entering them may lead to unexpected results and open the *Debugger*.

Optional parameters are listed within brackets. The expression *[,Parameter:boolean]*, for example, means that you can, but do not have to enter the *boolean* parameter.

If a parameter has a default value, the signature shows the default value after the parameter, `:= false` in the example above.

If the *method* has a return value, the signature shows its data type after the arrow `->`, `→ boolean` in the example above.

appendToContent [SimTalk]

Appends the passed text to the existing text on the tab **Comment** which the *Comment* designated by <Path> shows.

Type

Method

Remarks

Plant Simulation requests memory in larger blocks from the operating system so that memory does not have to be increased with each call. This makes putting a message together from many text blocks faster.

Syntax

```
<Path>.appendToContent(Text:string)
```

Parameter

The parameter *Text* of data type *string* designates the text which you want to add.

Example

```
MyComment.appendToContent("my added text")
```

See also

[Tab Comment \[Comment\]](#)

openComment [SimTalk]

Opens a window that only shows the comment you entered into the *Comment* designated by <Path> without any formatting options.



Type

Method

Syntax

```
<Path>.openComment → boolean
```

Return Value

The return value has the data type *boolean*.

Example

```
MyComment.openComment
```

See also

[Tab Comment \[Comment\]](#)

Read-Only Attributes of the Comment

Read-Only Attributes of the Comment

The *Comment* provides the [_Read-Only Attributes of All Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.