

openComment [SimTalk]

Opens a window that only shows the comment you entered into the *Comment* designated by <Path> without any formatting options.



Type

Method

Syntax

```
<Path>.openComment → boolean
```

Return Value

The return value has the data type *boolean*.

Example

```
MyComment.openComment
```

See also

[Tab Comment \[Comment\]](#)

Read-Only Attributes of the Comment

Read-Only Attributes of the Comment

The *Comment* provides the [_Read-Only Attributes of All Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
NumPartsSinceSetup	0			-> integer
NumPred	1			-> integer
NumSucc	3			-> integer

Name of the read-only attribute Current value of the read-only attribute Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected **Class** [general description].
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected **Instance** [general description].

To query the value of a *read-only attribute*, you might, for example, type:

```
print MyComment.UUID
```

Attributes of the Comment

_Attributes of the Comment

The *Comment* provides:

- The *attributes* listed in the table of contents to the left.
- The **Attributes of All Objects**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.