

putPieceCostsIntoTable [SimTalk]

Writes the **Piece costs**, which the *CostAnalyzer* designated by <Path> computed, into the specified *DataTable*.

	string 0	money[€] 1	money[€] 2	money[€] 3	money[€] 4	integer 5	integer 6
	MU Type	Piece costs	Material costs	Accrued costs	General costs	Throughput	Work in process
1	Part	8.32	8.00	0.17	0.15	10650	6
2							

Type

Method

Syntax

```
<Path>.putPieceCostsIntoTable(DataTable:table)
```

Parameter

The parameter *DataTable* of data type *table* designates the *DataTable* into which *Plant Simulation* writes the piece costs.

Example

```
CostAnalyzer.putPieceCostsIntoTable(MyPieceCosts)
```

SimTalk

[getPieceCostsTable \[SimTalk\]](#)

See also

[Costs Shown in the Costs Report](#)

Read-Only Attributes of the CostAnalyzer

Read-Only Attributes of the CostAnalyzer

The *CostAnalyzer* provides the [_Read-Only Attributes of All Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
NumPartsSinceSetup	0			-> integer
NumPred	1			-> integer
NumSucc	3			-> integer

Name of the read-only attribute Current value of the read-only attribute Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

To query the value of a *read-only attribute*, you might, for example, type:

```
print MyCostAnalyzer.UUID
```

Attributes of the CostAnalyzer

Attributes of the CostAnalyzer

The *CostAnalyzer* provides:

- The *attribute* **CollectData**.
- The **Attributes of All Objects**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.