

Help Menu

The commands are described under the [Help Menu](#).

Methods of the Display

_Methods of the Display

The *Display* provides:

- The *methods* listed in the table of contents to the left.
- The [Methods of All Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
contentsList	[]			([Contents:table]) -> any
createAttr				(NameOfUserDefinedAttribute:string, DataType:string) -> boolean
createIcon				(IconName:string, Width:integer, Height:integer) -> integer
deleteAttr				(NameOfUserDefinedAttribute:string) -> boolean

Name of the method
 Identifier and data type of the parameter you enter
 Data type of the return value

Name	Value	Inherited	Watchable	Signature
moveToFolder				(Folder:object) -> object
MU	VOID			([Index:integer:=1]) -> object
MUPart	VOID			([Index:integer:=1]) -> object

Name of the method
 Identifier and data type of the parameter you enter
 Default value
 Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

An example of the **Syntax** line of the individual methods might look like this:

```
<Path>.openDialog([CallOpenControl:boolean:=false]) → boolean
```

- The expression *<Path>* designates the path of the object to which the *method* applies.
- The signature of the method, consisting of the identifier and the data type of the parameter, is listed in parentheses. The expression *(Parameter:string)*, for example, designates a parameter of data type *string*. Instead of a constant value, you can also use a variable of the required type or a *method* that returns the required data type.

Note

Make sure to enter the parentheses for expressions within parentheses (...). Not entering them may lead to unexpected results and open the *Debugger*.

Optional parameters are listed within brackets. The expression *[,Parameter:boolean]*, for example, means that you can, but do not have to enter the *boolean* parameter.

If a parameter has a default value, the signature shows the default value after the parameter, *:= false* in the example above.

If the *method* has a return value, the signature shows its data type after the arrow *->*, *→ boolean* in the example above.

resetMinMax [SimTalk]

Deletes the minimum and maximum values that the *Display* designated by <Path> shows and sets them back to their default values.

Type

Method

Syntax

```
<Path>.resetMinMax
```

Example

```
print MyDisplay.resetMinMax
```

See also

[Reset Values \[button\]](#)

update [SimTalk] - Display

Updates the value that the *Display* designated by <Path> shows after a certain time has elapsed.

Remarks

update is only useful in conjunction with **Sample** mode. You can use the method *update* to force the *Display* to display a current value, for example after you changed the input value.

To be compatible with previous versions of *Plant Simulation*, you can specify the parameter *Time* of data type *time*.

Method

Type

Method

Syntax

```
<Path>.update
```

Example

```
MyDisplay.update
```

See also

[Interval \[text box\] - Display](#)

Read-Only Attributes of the Display

_Read-Only Attributes of the Display

The *Display* provides:

- The *read-only attributes* listed in the table of contents to the left.
- The [_Read-Only Attributes of All Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.