

show [SimTalk]

Shows the *HtmlReport* designated by <Path> as an HTML page.

Type

Method

Syntax

```
<Path>.show([Anchor:string])
```

Parameter

The optional parameter *Anchor* of data type *string* designates the anchor to which *Plant Simulation* navigates when it opens the HTML page.

Example

```
MyHtmlReport.show("DrainStat")  
// jumps to the anchor defined by:  
// << <a id="DrainStat"> </a> >>  
// on the tab Content
```

SimTalk

[close \[SimTalk\] - HtmlReport](#)

See also

[Show Report](#)

Read-Only Attributes of the HtmlReport

Read-Only Attributes of the HtmlReport

The *HtmlReport* provides the [_Read-Only Attributes of All Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
NumPartsSinceSetup	0			-> integer
NumPred	1			-> integer
NumSucc	3			-> integer

Name of the read-only attribute Current value of the read-only attribute Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected **Class** [general description].
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected **Instance** [general description].

To query the value of a *read-only attribute*, you might, for example, type:

```
print MyHtmlReport.UUID
```

Attributes of the HtmlReport

_Attributes of the HtmlReport

The *HtmlReport* provides:

- The *attributes* listed in the table of contents to the left.
- The **Attributes of All Objects**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.