

Help Menu

The commands are described under the [Help Menu](#).

Methods of the SankeyDiagram

Methods of the SankeyDiagram

The *SankeyDiagram* provides the methods listed in the table of contents for accessing it.

The *SankeyDiagram* provides:

- The *methods* listed in the table of contents to the left.
- The **Methods of All Objects**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window **Show Attributes and Methods**. The figure below illustrates the information using the example of the object *Station*.

The screenshot shows the .Models.Model.Station window with the 'deleteAttr' method selected. The signature is: (NameOfUserDefinedAttribute:string) -> boolean. Red boxes highlight the parameter name and its data type, and the return type.

Name	Value	Inherited	Watchable	Signature
contentsList	[]			([Contents:table]) -> any
createAttr				(NameOfUserDefinedAttribute:string, DataType:string) -> boolean
createIcon				([IconName:string, Width:integer, Height:integer]) -> integer
deleteAttr				(NameOfUserDefinedAttribute:string) -> boolean

Annotations below the table:

- Name of the method
- Identifier and data type of the parameter you enter
- Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

An example of the **Syntax** line of the individual methods might look like this:

```
<Path>.openDialog([CallOpenControl:boolean:=false]) → boolean
```

- The expression *<Path>* designates the path of the object to which the *method* applies.
- The signature of the method, consisting of the identifier and the data type of the parameter, is listed in parentheses. The expression *(Parameter:string)*, for example, designates a parameter of data type *string*. Instead of a constant value, you can also use a variable of the required type or a *method* that returns the required data type.

Note

Make sure to enter the parentheses for expressions within parentheses (...). Not entering them may lead to unexpected results and open the *Debugger*.

Optional parameters are listed within brackets. The expression *[,Parameter:boolean]*, for example, means that you can, but do not have to enter the *boolean* parameter.

If a parameter has a default value, the signature shows the default value after the parameter, *:= false* in the example above.

If the *method* has a return value, the signature shows its data type after the arrow *->*, *→ boolean* in the example above.

getPartFlowData [SimTalk]

Writes the flows that the *SankeyDiagram* designated by <Path> collected during the simulation to the designated *DataTable*.

Remarks

The *SankeyDiagram* collects the number of the parts which move between point-oriented objects or along length-oriented objects. It does not consider the direction nor the sequence of the movements of the parts, and they cannot be traced back from the returned data.

Type

Method

Syntax

```
<Path>.getPartFlowData(DataTable:table)
```

Parameter

The parameter *DataTable* of data type *table* designates the table into which *Plant Simulation* writes the data of the flows.

Example

```
MySankeyDiagram.getPartFlowData(MyDataTable)
```

update [SimTalk] - SankeyDiagram

Refreshes the displayed *SankeyDiagram* designated by <Path> with the current values.

Type

Method

Syntax

```
<Path>.update
```

Example

```
MySankeyDiagram.update
```

See also

[Update \[in Frame\]](#)

Read-Only Attributes of the SankeyDiagram

Read-Only Attributes of the SankeyDiagram

The *SankeyDiagram* provides the [_Read-Only Attributes of All Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

