

RENOZ PIN: 1981

600 Ah

1 / 2

03 SET BATTERY LIMITS

BATTERY MODE - 4-MODULE EXAMPLE

Battery Mode **Lithium**

Batt Capacity **N x 100 Ah**

MAX A CHARGE / DISCHARGE

Lower of N x 50 A or the inverter limit.

50 A/module = 0.5C. BMS limits take priority.

Activate Battery: over-discharge recovery.

04 SET GRID CHARGE

GRID / GENERATOR CHARGE

Grid Charge **Site operating plan**

Grid Start **10% (reference)**

Grid Charge A **Max A Charge**

Set TOU charge periods + targets.

Grid Start is unused on some Deye models.

05 SET BMS / SOC LIMITS

BMS / SOC

Lithium Mode **00**

Shutdown **7%**

Low Batt **10%**

Restart **12%**

Operating SoC: minimum 10% | maximum 100%

06 APPLY THE SITE SETUP

Battery settings above stay the same

GRID / BACKUP

TOU: set reserve, charge times and targets.

Grid Charge: enable where planned.

Grid Start: unused on some models.

Test backup loads with grid disconnected.

OFF-GRID

Loads supplied from LOAD / backup output.

Grid Charge OFF if there is no grid source.

TOU active? Select Gen Charge periods.

Test low-SoC recovery with backup loads.

GENERATOR (IF FITTED)

GEN Port Use: Generator Input + rated power.

Gen Charge ON; site Gen Start and Gen A.

Gen A: spare capacity after running loads.

Gen Signal: compatible auto-start only.

Test start / charge / stop; Gen Force OFF.

AC PV: match the Micro Inv / AC-couple mode; test full-battery curtailment. GEN port has one role at a time.

No BMS data: check CAN / ports / addresses before charging. Generator on GRID / parallel: use model-specific setup.

07 SAVE / HANDOVER

☐ Physical count + capacity match.

☐ Live BMS data; no comms alarm.

☐ Save each screen with the tick.

☐ Record site, model + firmware.