

01 SET UP THE MASTER BATTERY

RENOZ PIN: 1981

PROTOCOL: Deye

Protocol Settings

Select Protocol

☐ MUST
 ☐ DONNERGY
 ☐ JOHNRAY

☐ SOFAR
 ☒ Deye
 ☐ Sorotec

☐ Aiswei
 ☐ Voltronic
 ☐ WAET

BACK

NEXT

ADDRESS / PARALLEL BATTERIES

Networking and Configuration

Do not adjust settings while this battery is communicating with an inverter

Select Protocol

☐ SOL-ARK
 ☐ Schneider
 ☐ Victron

☐ SRNE
 ☐ SMA
 ☐ Pylontech

Select battery address

1

Total number of parallel batteries(01-50)

7

BACK

NEXT

Before BMS changes: module breakers and inverter DC isolator OFF; no active inverter communication.

Protocol: Deye. Master only; re-open to verify.
Master LCD > Settings > Protocol Settings

Select Battery Address: master 1; slaves 2, 3, ...

Total number of parallel batteries: N + 1. Example: 6 packs = 7 shown.

CAN: master X2 to SP PRO; master X3 unused. Use the correct SP PRO CAN cable.

Temperature probe: beside the top battery module.

02 CONNECT AND SET UP SP LINK

Settings passcode: 74 (default)

Connection password: **Selectronic SP PRO** (default)

Connect > Configure SP PRO > passcode 74

Quick Start

Unit Application

Off Grid

Powerchain Plan

Disabled

Battery Type

BMS Pylontech

24 cells)

AC Source Power

[0.1 - 15.0 kW]

6.0

kW

SoC Control

Enabled

Battery Capacity

[20 - 60000 Ah]

600

30.7kWh

Capacity shown: 6 modules = 600 Ah. Application and AC source power are site-specific. Use site credentials if changed.

03 SET BATTERY SHUTDOWN

SP LINK > Configuration Settings > Inverter

DC Shutdown

Battery 0% Load

[39.6 - 48.0 V]

50.0

Battery 100% Load

[39.6 - 48.0 V]

49.5

Recovery Voltage

[45.6 - 52.8 V]

52.0

SoC Shutdown

Enabled

Shutdown SoC

[0 - 100 %]

10

04 CHECK BATTERY DATA

LIVE BMS COMMUNICATION

RENOZ: Deye > SP LINK: BMS Pylontech

☐ BMS SoC, battery voltage and charge/current limits are live.

BATTERY CAPACITY

☐ SP LINK capacity = **N x 100 Ah**. N counts physical modules across all towers. The BMS N + 1 count does not add a battery.

Check communication on the installed firmware. Screens are annotated references; layout and displayed ranges may vary.

NEXT: battery protection and charging settings on page 2.

05 SET BATTERY PROTECTION

SP LINK > Configuration Settings > Battery

Inverter	Battery	Charger	AC Source	Solar Hybrid Control	System	Inputs / Outputs	Shunts	Expansion Card Wiring Diagram
Limits Max Charge Voltage [48.0 - 68.4 V] 57.0 Hi Battery Alert [54.0 - 68.4 V] 58.5 Hi Battery Alert Clear [54.0 - 68.4 V] 58.0 AC Coupled Trip AC Coupled Trip [48.0 - 72.0 V] 58.5 Over Target Charge Voltage Trip [0.0 - 25.0 %] 0.5 Over Target Charge Current Trip [0.0 - 25.0 %] 2.0 Trip Delay [0.2 - 20.0 s] 1.0								

BMS Charger Adjustment
Float Voltage Adjust
 [-20.0 - 0.0 %]

Current Target Scale
 [50.0 - 100.0 %]

Periodic Charging
Periodic Charge
 Charge to Float
 Charge Period
 [2 - 100 d]

 Off-grid: reduce generator run
Periodic Recharge When On Float
 Disabled
Recharge Period
 [2 - 100 d]

Soft Battery
 Disabled

Mid Point Monitoring
 Disabled
Mid Point Range
 [2 - 10 %]

Periodic Charge Request
 Disabled

SoC Setting
Peukert's Exponent
 [1.00 - 1.50]

Over Temp. Protection
Limit Charge above
 [35 - 70 °C]

Limit Rate
 [0 - 20 %]

06 SET CHARGING PROFILE

SP LINK > Configuration Settings > Charger

Inverter	Battery	Charger	AC Source	Solar Hybrid Control	System	Inputs / Outputs	Shunts	Expansion Card Wiring Diagram
Charge Settings Max. Charge Current (as % of Battery Capacity) [1.0 - 200.0 %] 50.0 Initial Return Voltage [45.6 V - Float V] 52.0 Initial Return SoC [0 - 99 %] 95								

Initial Stage
Voltage
 [48.0 - 60.0 V]

Current
 (as % of Max Chrg Current)
 [1 - 100 %]

Time
 [1 - 240 min]

Bulk Stage
Voltage
 [48.0 - 60.0 V]

Current
 (as % of Max Chrg Current)
 [1 - 100 %]

Time
 [1 - 240 min]

Absorption Stage
Voltage
 [48.0 - 62.4 V]

Current
 (as % of Max Chrg Current)
 [1 - 100 %]

Absorb-Float Transition
Net Change
 (as % of Battery Capacity)
 [0.1 - 5.0 %]

Change Time
 [1 - 240 min]

Max Time
 [1 - 240 min]

Float Stage
Voltage
 [48.0 - 60.0 V]

Current
 (as % of Max Chrg Current)
 [1 - 100 %]

Long Term Voltage
 [48.0 - 60.0 V]

Equalise Stage
Voltage
 [48.0 - 64.8 V]

Current
 (as % of Max Chrg Current)
 [1 - 100 %]

Time
 [0.1 - 24.0 hours]

CURRENT BASIS

Max 50% = 0.5C. Stage currents are % of Max Charge Current.

EQUALISE

60.0 V / 2% / 0.1 h placeholders. Periodic Charge: Charge to Float.

Green = revised value

FINISH: save site/configuration file.