

CrewmateA350 — User Manual

Contents

Getting Started

- Requirements
- Voice Modes
- Settings

Tutorial

- Assumptions
- Typical preflight timeline (example)
- Pushback and Engine Start
- Taxi
- Line-up & Takeoff
- Rejected Takeoff
- Acceleration
- Climb to 10,000 ft
- Descent Preparation
- 10k Descent
- Approach
- Landing
- After Landing
- Parking
- Securing the Aircraft

Voice Commands

- Preflight Timer
- Launching Flows by Voice
- Launching Checklists by Voice
- Gear
- Flaps
- Autopilot
- Flight Director
- Altimeter
- Missed Approach Altitude
- Lights
- Engine Anti-Ice
- Wing Anti-Ice
- Wipers
- Engines and APU
- Cabin and Doors
- Brakes
- Control Handover
- Takeoff and Go-Around

Ground Engineer

FMA Callouts

Checklist Responses

Cockpit Preparation

Before Start

After Start

Taxi

Departure Change

Line-Up

Approach

Landing

Parking

Securing the Aircraft

Tips & Troubleshooting

CrewmateA350 — User Manual

CrewmateA350 is a virtual First Officer companion for the **Airbus A350** in Microsoft Flight Simulator. It listens to your voice, responds with audio callouts, runs automated cockpit flows, and guides you through interactive checklists — just like a real crew member.

 Crewmate avatar

Getting Started

Requirements

- Install **an English** Windows speech recognition language pack (Settings → Time & language → Speech). Regional variants (e.g. US, UK, Australia, India) are supported — whichever English recognizer Windows exposes. If several English packs are installed, the active engine follows Windows' installed-recognizer order.
- **Set up Windows Speech Recognition once** before using the Voice Trainer. The trainer teaches Windows your voice, and Windows needs an existing speech profile to train. If the setup has never been run, there is no profile and training cannot start.
- To use the trainer app, set your Display Language to EN-US while training (you can change it back afterward).

Voice Modes

CrewmateA350 supports two voice recognition modes:

Mode	How it works
Continuous	The microphone is always listening. Speak naturally.
Push-to-Talk (PTT)	Not implemented yet.

Settings

Setting	What it does
Copilot	Which voice the FO speaks with (Jenny, Aria, Guy, Christopher).
Ground Eng.	The voice used by the ground engineer on the interphone.
Output Device	Where the FO's audio is played. Useful if you keep the sim on one device and voices on another.
Input Device	Which microphone the speech engine listens to.
Sound Volume	How loud the FO's audio is (0–200; above 100 amplifies).
Voice Sensitivity	How confident the engine must be before accepting a command (50–100). Lower is more tolerant and may accept the wrong command; higher is stricter.
Hold checklist on incorrect item	On: the FO repeats the challenge until the item is answered correctly. Off: the item is skipped and the checklist moves on.
Auto Ground lights control	On: the FO operates landing, taxi and strobe lights during the flows. Off: the lights are left to you.
5 minutes cool down (for engine shutoff)	On: the FO refuses to shut an engine down until five minutes have passed since landing, and says so. Off: engines can be shut down at any time.


Tutorial

Assumptions

This tutorial assumes you are parked at the gate with engines off. You are the Captain and PF (Pilot Flying); CrewMate acts as PM (Pilot Monitoring).

Typical preflight timeline (example)

- 50 min: Cockpit door and curtains opened.
- 48 min: PM starts preliminary cockpit preparation.
- 44 min: PM departs for external walkaround. PF starts cockpit preparation.




- 35 min: PM returns and starts cockpit preparation on the right-hand side.
- 25 min: PF conducts the departure briefing (enter takeoff data in the Takeoff Performance window, including the departure **Runway** — the FO reads it back on the LINE-UP checklist).
- 20 min: PF calls for the COCKPIT PREPARATION checklist.
- 5 min: PM closes the table, and a reminder to start the APU is shown.

- 1 min: CrewMate closes the cockpit door. PF and PM perform before start flow, after that PF calls for the BEFORE START checklist.

The before start flow takes TCAS out of standby and sets the transponder mode, then **leaves the SURV page open on the MCDU on purpose**. The ALT RPTG, ADS-B RPTG and ADS-B TRAFFIC pushbuttons on that page cannot be operated from outside the aircraft, so the FO cannot press them — set them yourself while the page is up.


The FO is outside between T-44 and T-35. While away on the walkaround the FO does not answer any command, and an **FO outside** indicator is shown. Ground engineer calls and the preflight timer still work, because the ground engineer is a different person on the interphone.



Before Start flow pattern

Pushback and Engine Start


- Announce each engine start (e.g., "Starting engine one").
- When ignition is set to NORMAL, PF and PM will start the AFTER START flow pattern. If anti-ice will be used, flaps may be left as required.
- On hand signal from ground personnel, call for the AFTER START checklist.



After Start flow pattern

Taxi


- PM announces when the cabin is ready.
- Check flight controls at a convenient time before or during taxi (this is done before arming the autobrake).
- Control check sequence: Full Up, Full Down, Neutral, Full Left, Full Right, Neutral, Rudder Full Left, Rudder Full Right, Neutral. The FO calls out each position as it is reached and waits for you.
- After the controls check, PM performs the TAXI flow pattern.
- After T.O. CONFIG pushbutton is pressed and a cabin report is received, PF calls for the TAXI checklist.



Taxi flow pattern

Line-up & Takeoff

- PF calls for the Line-up flow.
- When line-up clearance is received and the Line-up flow pattern is complete, PF calls for the LINE-UP checklist.
- When cleared for takeoff, announce "TAKEOFF."




Line-up flow pattern

Rejected Takeoff

- To reject, announce **"STOP"**. The FO then follows the FCOM tasksharing: **"reverse green"** once reverse is selected, then **"decel"** or **"no decel"**.
- Nothing is said about reverse if it is never selected — a low speed reject produces no reverse call at all.


Acceleration

- The After-Takeoff flow is triggered when flaps are retracted to zero.



Acceleration flow pattern

Climb to 10,000 ft



10,000 ft flow pattern


Descent Preparation

- PF should insert landing data in the Landing Performance window.
- **SEL LS** selects the LS pushbutton on the FO side during the descent flow. Deselect it for RNP AR approaches.

PF	
NAVIGATION CHARTS	
BAROMETRIC REFERENCE	PRESET
EFB/ECAM alerts	SYNCHRONIZE
LANDING CONDITIONS CONFIRM	
•If landing conditions changed:	
LANDING PERF DATA	COMPUTE
LANDING PERF DATA	
FMS	PREPARE
LDG ELEVN	CHECK
•If required (e.g. due to a NOTAM):	
RUNWAY SHIFT	ENTER
RWY COND/BRAKING ACTION	SELECT
•If BTV is used:	
ND MODE selector	PLAN
ND RANGE selector	ZOOM
RUNWAY	CHECK
RUNWAY EXIT	SELECT
BTV	ARM
RUNWAY LENGTH	CHECK
•If BRK MED is used:	
BRK MED	ARM

PF Descent preparation items

10k Descent



10k descent flow pattern

Approach


- After passing the transition level call for "set altimeters/QNH", complete the APPROACH checklist.
- The transition altitude and transition level calls are skipped when the altimeter has already been set, so setting standard early does not produce a redundant call later.

Landing

- When LDG CONF is set and a cabin report is received, call for the LANDING checklist.
- PF announces "Continue" at minima or "Go-around - flaps" as appropriate.

After Landing

- Disarming the ground spoilers will trigger the After-Landing flow.
- If anti-ice is used, flaps may remain at LDG CONF per procedure.




After landing flow pattern

Parking

- Turn off taxi lights when turning into the gate, or ask the PM to confirm.
- Shutting down the engines will trigger the Parking flow.
- After the Parking flow pattern completes, PF calls for the PARKING checklist.

Engine shutdown is held for five minutes after landing. With **5 minutes cool down** enabled, asking the FO to shut an engine down before the cooling period has elapsed is refused with "five minutes not passed". The countdown starts automatically at the 70 knot call.



Parking flow pattern

Securing the Aircraft

- After the last passenger leaves (if securing the aircraft), call for the SECURING THE AIRCRAFT checklist.
- The shutdown flow returns TCAS and the transponder to standby.

Voice Commands

Speak these phrases clearly during flight. The FO uses partial matching — you don't need to be word-perfect, but include the key phrase. **"Please" may be added before or after any command** ("please gear up", "gear up please").

Where a command takes a number, say it naturally: "two seven zero", "three hundred fifty", "one zero one three".

Preflight Timer

Say	What happens
"Let's prepare the aircraft" / "Let's prepare the flight" / "Let's set up the aircraft"	Starts the preflight countdown timer to help you track preparation time.

Launching Flows by Voice

Say	Flow launched
"Clear left" / "Clear on the left" / "Left side clear" / "Clear left side"	Clear Left flow
"Before start procedure"	Before Start flow
"Runway entry procedure" / "Clear to line up"	Before Takeoff flow
"Takeoff"	Takeoff flow
"Flight controls check"	Flight controls sequence, then Taxi flow
"Start engine two"	Starts engine 2 (single-engine taxi start)

Launching Checklists by Voice

Say	Checklist launched
"Cockpit preparation checklist"	COCKPIT PREPARATION
"Before start checklist"	BEFORE START
"After start checklist"	AFTER START
"Taxi checklist"	TAXI
"Departure change checklist"	DEPARTURE CHANGE
"Lineup checklist"	LINE-UP
"Approach checklist"	APPROACH
"Landing checklist"	LANDING
"Parking checklist"	PARKING
"Secure aircraft checklist"	SECURING THE AIRCRAFT
"Cancel checklist" / "Stop checklist" / "Abort checklist"	Aborts the active checklist

Gear

Say	What happens
"Gear down"	Lowers the landing gear. Speed must be at or below 255 knots.
"Gear up"	Raises the landing gear.

Flaps

The FO will confirm speed limits before moving flaps while airborne.

Say	Flap Setting	Max Speed
"Flaps zero"	Flaps 0 (retracted)	—
"Flaps one"	Flaps 1	255 kts (A350-900) / 260 kts (A350-1000)
"Flaps two"	Flaps 2	212 kts / 219 kts
"Flaps three"	Flaps 3	195 kts / 206 kts
"Flaps full"	Flaps Full	186 kts / 192 kts

Autopilot

Say	What happens
"Autopilot on"	Engages Autopilot 1.
"Autopilot off"	Disconnects the autopilot.
"Set speed ___" / "Pull speed ___"	Sets the commanded speed. "Knots" may be added.
"Pull speed"	Pulls the speed knob (selected speed).
"Manage speed"	Pushes the speed knob (managed speed).
"Set heading ___"	Sets the commanded heading.
"Pull heading ___"	Sets the heading and pulls the knob.
"Pull heading"	Pulls the heading knob (selected heading).
"Manage nav"	Pushes the heading knob (managed NAV).
"Set altitude ___"	Sets the commanded altitude in feet.
"Set flight level ___"	Sets the commanded altitude as a flight level.
"Altitude ___ pull" / "Flight level ___ pull"	Sets the altitude and pulls the knob.
"Altitude ___ manage" / "Flight level ___ manage"	Sets the altitude and pushes the knob.
"Altitude pull" / "Flight level pull"	Pulls the altitude knob.
"Altitude manage" / "Flight level manage"	Pushes the altitude knob.
"Press alt"	Pushes the level-off pushbutton.
"Arm approach"	Arms APPR.
"Arm localizer" / "Arm loc"	Arms LOC.
"Set runway track"	Sets the FCU heading to the landing runway track.

Flight Director

Say	What happens
"Flight director on"	Activates the Flight Director.
"Flight director off"	Deactivates the Flight Director.
"Flight director off bird on"	Deactivates FD and selects TRK/FPA on the autopilot.
"Bird on"	Selects TRK/FPA on the autopilot.
"Bird off"	Deselects TRK/FPA on the autopilot.

Altimeter

Say	What happens
"Set standard"	Sets STD on both sides. In the climb the FO calls "standard crosschecked, passing flight level __", then "now" as the level is reached.
"Set altimeters" / "Set QNH"	Sets the altimeters to the current QNH.

Missed Approach Altitude

Say	What happens
"Set go around altitude" / "Set missed approach altitude"	Uses the missed approach altitude from the Landing Plan window.
"Set go around altitude __ feet"	Sets an explicit altitude in feet.
"Set go around altitude flight level __"	Sets an explicit flight level.

The FO reads the altitude back — "go around altitude, four thousand, feet set".

Lights

Say	What happens
"Landing light on"	Turns on landing lights.
"Landing light off"	Turns off landing lights.
"Taxi light on"	Turns on nose taxi light.
"Taxi light off"	Turns off nose taxi light.
"Takeoff light on"	Turns on nose takeoff light.
"Strobe light on"	Turns on strobes.
"Strobe light auto"	Sets strobes to AUTO.
"Strobe light off"	Turns off strobes.

Engine Anti-Ice

Say	What happens
"Engine anti ice on"	Turns on engine anti-ice for both engines.
"Engine anti ice off"	Turns off engine anti-ice.

Wing Anti-Ice

Say	What happens
"Wing anti ice on"	Turns on wing anti-ice.
"Wing anti ice off"	Turns off wing anti-ice.

Wipers

Wipers are refused above 230 knots unless you are selecting OFF.

Say	What happens
"Wipers off"	Wipers off.
"Wipers slow"	Slow continuous.
"Wipers fast"	Fast continuous.
"Wipers slow intermittent"	Slow intermittent.
"Wipers medium intermittent"	Medium intermittent.
"Wipers fast intermittent"	Fast intermittent.

Engines and APU

Say	What happens
"Starting engine one" / "Starting engine number one" / "Starting one" / "Starting number one"	You announce the start; the FO acknowledges with "check".
"Starting engine two" / "Starting engine number two" / "Starting two" / "Starting number two"	You announce the start; the FO acknowledges with "check".
"Start engine two"	Starts engine 2 and runs the after start flow for it.
"Shutdown engine one"	Shuts down engine 1.
"Shutdown engine two"	Shuts down engine 2.
"Start the apu" / "Start apu"	Starts the APU.

Cabin and Doors

Say	What happens
"Cabin crew arm slides" / "Cabin crew arm slides and cross check"	Arms the door slides.
"Cabin crew disarm slides"	Disarms the door slides.

Say	What happens
"Seat belts on"	Seat belt signs on.
"Seat belts off"	Seat belt signs off.
"Seat belts auto"	Seat belt signs to AUTO.

Brakes

Say	What happens
"Brake check"	The FO answers "pressure zero".
"Brake fan on"	Turns the brake fans on, if the aircraft is fitted with them.
"Brake fan off"	Turns the brake fans off.

If the aircraft has no brake fans, the FO answers "are you sure?" instead.

Control Handover

Say	What happens
"You have control"	The FO answers "I have control".
"I have control"	The FO answers "you have control".

Takeoff and Go-Around

Say	What happens
"Takeoff"	Runs the Takeoff flow.
"Stop"	Rejected takeoff — the FO calls reverse green, then decel or no decel.
"Go around flaps"	Retracts one flap stage and re-arms the after takeoff flow.
"Continue"	Acknowledged at minima.

Ground Engineer

Call the ground engineer first — the rest are only answered once the interphone call has been made.

Say	What happens
"Ground from cockpit" / "Cockpit to ground"	The ground engineer answers "go ahead".
"Connect GPU" / "Connect ground power"	Connects ground power.
"Disconnect GPU" / "Disconnect ground power"	Disconnects ground power.
"Connect ASU" / "Connect air starter"	Connects the air starter unit.
"Disconnect ASU" / "Disconnect air starter"	Disconnects the air starter unit.
"Connect ACU" / "Connect air conditioning"	Connects the air conditioning unit.
"Disconnect ACU" / "Disconnect air conditioning"	Disconnects the air conditioning unit.
"Disconnect all" / "Disconnect all services"	Disconnects everything.

Say	What happens
"We are ready for pushback"	Requests pushback.

FMA Callouts

The FMA can be read out loud as the PF ("man toga, srs, runway, autothrust blue"). The FO recognises the standard thrust, vertical, lateral, approach and armed mode wording, including "man flex" with a flex temperature.

Checklist Responses

During a challenge/response checklist the FO reads each item and waits for your answer. **"Set and checked" is accepted for every item**, and items marked *auto* are verified silently without a spoken response.

Some items are also verified against the aircraft — if the switch is not actually set, the FO answers "are you sure?" and, depending on the **Hold checklist on incorrect item** setting, either repeats the challenge or moves on.

The answers that carry numbers — speeds, altimeter settings, minimums, the runway, fuel — are only understood **while a checklist is running**. They are readbacks, not commands: saying them at any other time does nothing.

Cockpit Preparation

Item	Say
Gear Pins and Covers	"removed"
Fuel Quantity	"fuel quantity ___ kilograms / pounds / tons", optionally "balanced". The short forms "tons" / "kilograms" / "pounds" also match.
Seat Belts	<i>auto</i> — checked against the seat belt switch
Barometric Reference	"altimeter ___ set" / "QNH ___ set" / "___ set" / "set" — the FO reads the setting back. inHg (2700–3100) and hPa (900–1100) are both understood.

Before Start

Item	Say
Parking Brake	"set" — verified against the parking brake
Takeoff Speeds and Thrust	"V1 ___ VR ___ V2 ___ flex ___" or "V1 ___ VR ___ V2 ___ toga" — all three speeds and the thrust setting must be said; the FO reads them back.
Slides	"armed" — verified against the door slides
Beacon	<i>auto</i> — checked against the beacon switch
Nose Wheel Disconnect Memo	"checked"

After Start

Item	Say
Anti Ice	"engines on" / "engines on wings on" / "off"
Flight Controls	"checked"
Ground Clearance	"received"

Taxi

Item	Say
Flap Settings	"config one plus f" / "config two" / "config three"
Radar	"on"

Departure Change

Item	Say
Runway and SID	"set and checked"
Flap Settings	"config one plus f" / "config two" / "config three"
Takeoff Speeds and Thrust	"V1 ___ VR ___ V2 ___ flex ___" or "V1 ___ VR ___ V2 ___ toga"
FCU ALT	"set"

Line-Up

Item	Say
Cabin Advisory	"secured" / "signaled"
Takeoff Runway	The runway, then "confirmed" — e.g. "zero nine left confirmed". "Left", "right", "center" and "centre" are understood; the FO reads the runway back.
Packs Settings	"on" / "on supplied by apu" / "off"

Approach

Item	Say
Barometric Reference	"altimeter ___ set" / "QNH ___ set" / "___ set" / "set" — the FO reads the setting back.
Minimums Reference	"baro ___ feet" or "radio ___ feet"
Runway Condition	"dry" / "wet" / "compacted snow" / "snow" / "slippery" / "standing water" / "slush" / "ice"
Auto Brake	"medium" / "BTV"

Landing

Run silently — the FO checks spoilers armed, flaps and gear down, and calls out anything that is not set.

Parking

Item	Say
Parking Brake or Chocks	"chocks in place" / "parking brake set"
Wing Lights	"off"

Securing the Aircraft

Item	Say
Exterior Lights	"off"
Ground Servicing	"off"
External Power	"off" / "on"
EFBs	"off"
Batteries	"off"

Tips & Troubleshooting

The FO isn't hearing me

- Check that your microphone is selected and working.
- Adjust the **Voice Sensitivity** setting.

The FO ignores everything I say before departure

- Between T-44 and T-35 on the preflight timer the FO is outside on the walkaround and does not answer. The **FO outside** indicator is shown while this is the case. Ground engineer calls still work.

The FO keeps repeating the challenge

- Your response didn't match the expected phrase. Listen to the challenge and use one of the phrases listed in [Checklist Responses](#) (voice matching can be tuned in settings).
- If a physical switch must be set first (e.g., parking brake), set it in the cockpit before responding.

The FO won't shut the engines down

- The **5 minutes cool down** setting holds engine shutdown until five minutes have passed since landing, and the FO says "five minutes not passed". Wait, or switch the setting off.

The Voice Trainer says training failed

- "Value does not fall within the expected range" means Windows has no speech profile for your account. Run Windows Speech Recognition setup once, then start the trainer again.
- The trainer also needs the Windows Display Language set to EN-US while it runs.

How do I stop a checklist mid-way?

- Say "**Cancel checklist**", "**Stop checklist**", or "**Abort checklist**" at any time.

Can I run flows and checklists manually without voice?

- Yes. Both can be triggered from the **Flows** and **Checklist** panels in the app UI.