Subaru Accesstuner Tuning Guide



Subaru Accesstuner Tuning Guide

Prepared by: Lance Lucas

12/10/2013

- Factory EMS and Hardware Overview
- Ignition Timing Control
 - Terminology Definitions
 - STi-Specific Considerations
 - Tuning Guidelines Ignition Timing
 - Advanced Tuning Strategies Ignition Timing
- Fuel Injection Control
 - Terminology Definitions
 - Calculations and Equations
 - Injector Characterization
 - Tuning Guidelines Fuel Injector Scale, Latency, etc.
- Mass Air Flow Measurement, Load Calculation and Fuel Trims
 - Terminology Definitions
 - Mass Air Flow MAF Sensor
 - Mass Air Flow Speed Density
 - Limiters
 - Disabling Learned Fuel Trims under Open Loop Operation
 - Tuning Guidelines Mass Air Flow Calibration
 - Tuning Guidelines Speed Density Calibration
- Open Loop Fuel Control
 - Terminology Definitions
 - Tuning Guidelines Primary Open Loop Fueling
- Boost Control
 - Terminology Definitions
 - Mechanical Concerns Boost Creep
 - Relevant Monitors
 - Tuning Guidelines Boost Targets
 - Tuning Guidelines Wastegate Duty Cycle
 - Tuning Guidelines Turbo Dynamics

Suggested Resources

COBB and Injector Dynamics Injector Characterization Data: http://help.injectordynamics.com/support/solutions/articles/4000009270-cobb-subaru

• These are Excel documents containing exact Injector Characterization data for the factory Subaru ECU for COBB and Injector Dyanmics branded fuel injectors. This data should serve as the starting point for calibration after an injector upgrade.

COBB Calibration & Tuning Guide Worksheet: http://cobb.box.com/SubaruTuningSpreadsheet

This is an Excel document that contains suggested starting values for many common hardware upgrades, such as popular fuel injectors,

MAP sensors, IAT sensors, etc. It also contains ways to estimate starting values when accurate data is not available from the manufacturer or when the current parts installed are unknown. The hosted file is updated as new information becomes available; please check for revisions from time to time.

COBB Protuner Support Page: http://www.cobbtuning.com/protuner-support/

 This page is maintained by COBB's Director of Protuning and includes web links for our Accesstuner Pro software builds, information about COBB-provide training options, links to various logos to use within your marketing materials, etc.

Factory EMS and Hardware Overview

Spark and ignition control is straightforward on modern turbocharged Subarus; crank and camshaft position are measured via reluctor and Hall-effect sensors, depending on model/year, and are then synchronized within the ECU, which operates four coil-on-pack ignitorless coils in a sequential firing order. Ignition system upgrades are rarely needed as the factory hardware has been proven shown itself to not only be durable but also capable of supporting roughly triple the factory power levels with no meaningful degradation to spark energy or combustion quality.

All turbocharged Subarus for USDM markets to-date (MY2002-MY2014) feature port injection, controlled a traditional 3 bar bypass fuel pressure regulator with manifold reference rate of 1:1. The factory fuel rails are in series configuration. A traditional in-tank hanger, located in the passenger side of the saddle-style fuel tank, handles fuel delivery from the tank. Like other Japanese vehicles, this assembly also contains a "siphon" system operated by the returning fuel flow to sump the driver's side fuel tank reserves. Fuel starvation during right hand turns is a known limitation of the design; many track vehicles and fast street cars use an auxiliary surge tank to alleviate this issue.

A PWM controller that is signaled by the ECU regulates fuel pump speed. The ECU can command three unique low-middle-high states, which are 33.3%, 66.6% and 100.0% from the factory but can be edited as necessary during fuel system calibration. Switching between states is primarily controlled via IPW or IDC thresholds and sometimes RPM breakpoints, model dependent. The pump is triggered to "high" for a period after startup and falls to "low" (assuming state thresholds have not been wildly altered) after the "startup" or "hot-start" periods end. The elaborate speed control is presumably used to promote pump life, decrease fuel heating and lessen FPR overrun (the factory FPR has a short spring and small orifice) during periods of low fuel demand.

Factory specified injectors vary, mostly along vehicle generation lines, though all are provided by Denso. The 2002-2005 WRX utilized ~440cc topfeed injectors (light blue). The 2004-2006 STI, 2005-2006 LGT and 2004-2005 FXT featured ~550cc sidefeed injectors (yellow). The 2007-2014 STI, 2006-2014 WRX, 2006-2013 FXT and 2007-2012 LGT use ~565cc topfeed injectors (dark blue), though the part numbers and body coloring may have changed across a few years. Uprated sidefeed injectors have proven to be particularly problematic; even the factory sidefeed injectors are known to have a high failure rate. Topfeed conversions are common practice, even for otherwise-stock vehicles.

Mass Air Flow is measured by a traditional Denso-provided integrated intake air temperature and hot-wire mass air flow meter. This is located in an "airbox" MAF housing from the factory or traditional "filter-on-a-stick" intake housing in the aftermarket. No post-compressor or post-IC temperature pickups are used unless the vehicle has been converted to use our custom Speed Density code, when an alternate IAT sensor is installed into the post-IC charge piping or intake manifold. Accurate Mass Air Flow measurement, meaning correct MAF recalibration following intake hardware changes, is exceptionally critical to accurate fuel calculations and delivery.

Our custom Speed Density code allows for computation of mass air flow and load (which are functions of one another in the Subaru ECU) based on the traditional *PV* = *nRT* and volumetric efficiency models. When using the Speed Density method for tuning, Mass Air Flow (and thus load) is calculated using a Volumetric Efficiency model that includes adjustable engine displacement, air temperature compensations, coolant temperature compensations and others. Assuming proper end-user input of critical items of said variables, the model is highly effective for very precise mass air flow estimation. This style of tuning is traditionally used by those whose power demands exceed that which a MAF housing of ~80mm or smaller internal diameter can provide, or those who require greatly customized turbocharger and intake tract configurations that do not allow for proper draw-through MAF or recirculating BPV positioning.

Open and Closed Loop operation is determined by various thresholds; open loop traditionally is enabled under higher load and "boost"; closed loop covers idle and cruising conditions. The closed loop system is inherently limited by the primary O2 sensor's location in the high-pressure pre-turbocharger exhaust piping without correlating EGBP pickup and compensation, thus its accuracy is largely limited to when intake manifold is under vacuum. Lambda target is determined in either mode by look-up tables and compensations that lead into a final fuel multiplier (Fuel-Air Equivalence Ratio) coefficient.

Boost control is also a simplistic yet effective system. The factory "2-port" boost control solenoid, which is plumbed via bleed style operation and is powered by the ECU via 12v PWM signal, operates on a 0-100% duty cycle scale using a closed loop boost targeting system. When energized, the solenoid is a low-pressure vent between the compressor nipple (boost reference) and the wastegate actuator, causing effective pressure at the actuator to decrease and boost to rise. A variety of restrictor pills are used within the boost control vacuum lines by the factory to fine-tune the system's responsiveness. A base wastegate duty cycle value is referenced, actual vs. target boost is evaluated, and corrections or "dynamics" are applied to correct for the boost error. This system is commonly upgraded to a plug-and-play "3-port" boost control solenoid with vacuum lines replumbed to operate the actuator in interrupt mode, where 100% wastegate duty cycle represents a complete blockage of boost reference to the wastegate actuator. The factory control system is highly scalable; it has proven effective for controlling small turbos making less than 15psi and 200whp all the way up to full motorsports vehicles running in excess of 30psi and 600whp. More detail about the factory system is available a thorough document entitled "How Subaru's Factory Boost Control System Works" by Christian Krahenbuhl.

Ignition advance, and total applied timing, is calculated and controlled by a somewhat complex strategy within the factory ECUs logic. With some basic knowledge and a clear understanding of the various tables and monitors involved, however, the system is not only very accurate, it is exceptionally easy to tune. Here are the basic formulas for how total ignition advance is calculated:

- Total Ignition Timing (all 2.5L): Primary Ignition + (Dynamic Advance * DAM) + Feedback Knock Correction + Fine Knock Learning + Compensations
- Total Ignition Timing (only 2.0L): Primary Ignition + (Dynamic Advance * (DAM/16)) + Feedback Knock Correction + Fine Knock Learning + Compensations

Terminology Definitions

- Total Ignition Timing: The total ignition timing value, in crank angle degrees relative to top dead center before or after the beginning of the
 power cycle. Positive values represent ignition "advance" or BTDC ignition events; negative values represent ignition "retard" or ATDC
 ignition events. Negative values are typically not used on the Subaru EJ series engine. This monitor for this value on-vehicle is "Ignition
 Timing" within Accesstuner and Accessport logs; it is important to note the logged value is for Cylinder #1 specifically and actual timing
 for other cylinders may vary, depending on per-cylinder compensation tables and thresholds.
- Primary Ignition: This value is defined by a traditional 3D table with Load as the x-axis, RPM as the y-axis and degrees of ignition timing as the z-data. This is a "Real-time" tunable table for all ECUs and also appears under the Advance (Primary) submenu. Depending on the vehicle, alternate Primary Ignition tables based on the TGVs Open/Closed status will be referenced. It is generally advised to only adjust the TGVs Open ignition tables as these will be the ones used primarily as far as performance or aftermarket tuning needs; in the absence of additional data, the TGVs Closed tables can be assumed to have been well-tuned from the factory.

Assuming the Dynamic Advance (see below) tables have been tuned to a pre-determined level before beginning on-vehicle tuning, most ignition timing adjustment will be confined to the Primary Ignition table during the calibration process.

• Dynamic Advance (DA): This value represents a global addition to the base/primary ignition value and is the maximum DA value allowed. Unique logic within all current years of STi can cause potentially unstable ignition timing or undesired increases to overall current DA value being used. Depending on the year, the STi has one or more Dynamic Advance Max. Adder tables as well as one or more Dynamic Advance Max. Primary tables.

Because the DA value applied is multiplied against the DAM value, the general shape of the primary DA tables is by and large determined by the relative probability of inducing detonation under given conditions. When load is low, or RPM is high, the engine is more resistant to detonation. When load is high or RPM is low, knock is more likely. With this, the factory generally uses the most DA where torque is highest, in order to achieve the largest dependence and response to DAM changes. In general, the Dynamic Advance tables are "pre-tuned" based on calibrator's preference, then the Primary Ignition table is shaped around it as such to generate the total final Ignition Timing value. Spreadsheet programs such as Excel can be very useful for overlaying the Primary Ignition and Dynamic Advance tables to help visualize the total timing value requested as well as look for any anomalous or insane values.

See "STi-Specific Considerations" below for additional information specific to the STi models.

Dynamic Advance Multiplier (DAM): This value represents a global adjustment to the Dynamic Advance component ignition timing. In general, this value is determined by historical detonation/knock as well as the default mapping value. For the 2.5L ECU DAM is stated as a decimal ranging from 0 to 1. For the 2.0L ECU DAM is stated as an integer between 0 and 16. DAM will tend to vary the most immediately following a reflash or ECU Reset procedure. The starting value for DAM is an adjustable value within the Ignition Tables -> Advance (Dynamic) submenu. Various thresholds, including RPM and load, determine when DAM can or should be evaluated for potential increases or decreases.

One of the more critical DAM evaluation thresholds to observe is based on the current requested Dynamic Advance value. When Dynamic Advance requested is below the threshold value as determined by the Course Knock Learning (DAM) Modify (Min. Din. Adv. Map Value) table, DAM will not be evaluated. This can cause DAM to be "stuck" at too low or high of a value and a global timing error results.

- Feedback Knock Correction (FKC): This value represents a current real-time minor timing correction made by the ECU in response to a perceived noise. Feedback Knock Correction is the default correction used by the ECU. The ECU will "respond" with this monitor by immediately removing timing and then slowly decaying the value back to zero assuming no further noise is detected. The amount of timing removed and re-added per incremental change are both adjustable values within the Knock Control submenu. Various thresholds, including RPM and load, determine when Feedback Knock Correction can or should be evaluated for potential increases or decreases.
- Fine Knock Learning (FKL): This value represents minor learned corrections currently being applied by the ECU as a product of historical noise. These values are reset if the DAM value is changed; once DAM has stabilized, any learned corrections will be intermittently evaluated for sanity when certain thresholds/conditions are met. Fine Knock Learning is learned (and thus applied) for specific ranges defined by load and RPM; once a correction value has been learned into a particular range, it will be applied whenever the engine is operated within that range. The amount of timing removed and added per incremental change are both adjustable values within the Knock Control submenu. Various thresholds, including RPM and load, determine when Fine Knock Learning can or should be evaluated for potential increases or decreases. Fine Knock learning values can only be negative when DAM is at its maximum value; both negative and positive values can be observed when DAM is below 16 (2L) or 1 (2.5L).

The Fine Knock Learning table is used by the ECU to store learned Dynamic Advance information. The ECU populates it with adjustments to total timing in degrees. This table uses engine RPM for the y-axis and calculated load for the x-axis. The ECU can make positive or negative adjustments to ignition advance in this table. If the ECU determines the motor can be further optimized by running additional ignition advance for a given RPM and calculated load, then it will populate this table with positive values, but only when DAM is below 16 (2L) or 1 (2.5L). If the ECU determines correctable detonation has occurred for a given RPM and calculated load, then it will populate this table with negative values. This fine

adjustment allows for memorized corrections to prevent the need for a reactive knock correction response each time the engine is subjected to similar operating load/RPM conditions. This table, and any newly-learned corrections, can be refreshed while you are connected for live tuning with the by pressing the F5 key. The stored values within this table are helpful for fine-tuning of the Primary Ignition table based on the detonation threshold observed over time.

The learned values within this table are cleared whenever the ECU is reset as well as any time that Dynamic Advance Multiplier is adjusted.

- Knock Sum (where applicable): This is a somewhat arbitrary monitor and logging value that should only be analyzed under the specific conditions you wish to evaluate, such as during wide-open throttle (WOT) operation over a set RPM range. Some later ECUs can report Knock Sum on a per-cylinder level, some only on a global basis. It is useful to determine if a particular cylinder is especially prone to detonation in relation to the others; however it must be noted that Cylinders #1-3 lack knock detection accuracy due to their relative distance from the knock sensor. Cylinder #4 can be heard most reliably thanks to being located directly below the knock sensor, which has a difficult time perceiving real engine noise over the noisy boxer engine on the more distant cylinders. If a noise is perceived, this value will increment at all times, regardless of if the knock detection system is deemed to be accurate or not. It is not uncommon to see these values increment under even the most mundane conditions, such as idling or while operating the vehicle at slow speeds in a parking lot. It must be emphasized that this is simply an indicator that a noise of unknown source has been detected, which must still be evaluated by the ECU for source, sanity and plausibility (IE, is it likely that the engine is actually detonating and on which cylinders).
- Compensations: Within the framework above, this is a summation of various ignition timing compensations. Depending on the year and model, these exist on as per-cylinder corrections, per-gear adjustments, intake air temperature based adjustments, etc. Depending on how the compensation tables are calibrated and the conditions under which the vehicle is operated, these compensations can wildly alter total timing or conversely have a very small effect. We tend to use minute or zero compensation for "normal" operating conditions such as mild temperatures at sea level elevation on a fully warm but not overheating engine and then add compensations for when those types of conditions are at more extreme values, such as relatively cool or hot air temperatures, high elevations or when the engine is overheating.

STi-Specific Considerations

All current years of STi ECUs contain additional logic can cause potentially unstable ignition timing or undesired increases to overall current timing being applied. Depending on the year, the STi models have one or more "Dynamic Advance Max. Adder" tables as well as one or more "Dynamic Advance Max. Primary" tables.

The logic used for determining when the "Dynamic Advance Max. Adder" tables are active is not straightforward, which means that values from these tables can be arbitrarily added to total current timing at undesirable times. As such, it is recommended that all "Dynamic Advance Max. Adder" tables should NOT be populated with any timing values in order ensure consistent total ignition advance. This can be easily done by selecting the entire table(s), then pressing "E" and entering the number "0".

The "Dynamic Advance Max. Primary" tables will always be applied, but the conditions to determine which table is active are not the same across years. The 2007-2011 STi vary with the TGVs Open/Closed status, which is a known set of thresholds such as Requested Torque and RPM; the 2004-2006 STi vary with a more complex and ambiguous set of thresholds based on historical knock. As such, setting all "Dynamic Advance Max. Primary" tables to the same values will ensure a consistent Dynamic Advance value is applied under all conditions.

Tuning Guidelines – Ignition Timing

During the calibration process, with specific regards to timing, it is recommended practice to always log (at least) these monitors:

- 1. Dynamic Advance Multiplier
- 2. Feedback Knock Correction
- 3. Fine Knock Learning
- 4. Ignition Timing
- 5. Engine Speed
- 6. Calculated Load

Additionally, to expedite the calibration process and reduce variability, it is recommended to set the default DAM value to 1 or 16, for 2.5L and 2.0L, respectively, for your base starting value and then performing an ECU reflash. Once this has been done, you can be certain that any changes/reductions to DAM, FKC or FKL have been caused by a recently detected event.

Assuming DAM stabilizes at its maximum value following the reflash/reset, pay very close attention to FKC and FKL during the calibration process. Depending on the model and year, the minimum timing increment varies between roughly -1 and -2 degrees. The decrement values can be viewed, or adjusted in unique circumstances, under the Knock Control submenus. Single increments of corrections to FKC and FKL will be observed from time to time during the calibration process; please note that FKL is truly a "learned" value and will be applied under those Load/RPM conditions until it is reevaluated and potentially removed. Intermittent single increments, such as -1.40 for a 2008-2014 STI, are not uncommon, but if proven repeatable under WOT conditions, an adjustment to the Primary Ignition table should be considered. Any value larger than the single increment is nearly certainly an indication of prominent noise and calibration adjustments should be made.

1	Α	В	С	D	Е	F	G	Н	1	J	K	L	M
1	Time	Calculated	Dynamic	Engine Sp	Feedback	Fine Knoc	Ignition T	Manifold	Mass Airfl	Throttle P	Wastegate	Inj. Duty C	ycle
2	0.319	0.31	1	3532	0	0	49.5	-9.25	1.98	12.2	0	6.78	
3	0.639	0.44	1	3548	0	0	49.5	-7.77	2.16	15.3	0	8.33	
4	0.958	1.3	1	3571	0	0	35.5	0.65	2.92	100	38.43	21.33	
5	1.278	1.79	1	3593	0	0	27.5	5.31	3.26	100	52.16	32.2	
6	1.597	2.58	1	3656	0	0	16.5	13.03	3.6	100	52.16	50.69	
7	1.917	3.3	1	3745	0	0	15	19.45	3.86	100	46.27	67.11	
8	2.237	3.12	1	3819	0	0	15.5	18.44	3.74	100	48.63	63.54	
9	2.557	3.17	1	3915	0	0	15.5	18.6	3.86	100	52.94	65.15	
10	2.876	3.23	1	4000	0	0	15.5	19.34	3.9	100	53.33	68.27	
11	3.196	3.23	1	4096	0	0	16	19.49	3.86	100	53.33	69.9	
12	3.516	3.24	1	4176	-1.4	0	14.5	19.73	3.92	100	53.33	71.27	
13	3.835	3.24	1	4227	-1.4	0	14.5	19.83	3.98	100	53.33	72.13	
14	4.155	3.26	1	4328	-1.4	0	14.5	19.99	3.96	100	53.33	73.87	
15	4.475	0.23	1	4418	0	0	-20	-7.92	1.54	9	0	0	
16	4.794	0.17	1	3875	0	0	-20	-9.59	1.68	8.2	0	0	
17	5.113	0.17	1	3382	0	0	-20	-9.71	1.62	7.1	0	0	
18	5.433	0.19	1	2920	0	0	24	-9.79	1.56	5.9	0	0	
19	5.753	0.18	1	2499	0	0	24	-10.38	1.46	4.7	0	0	
20	6.073	0.21	1	2076	0	0	24	-10.19	1.48	4.7	0	0	
21	6.392	0.21	1	1665	0	0	21.5	-10.34	1.4	3.5	0	0	
22													

Ex: Data log demonstrating a single negative Feedback Knock Correction increment while performing a dyno calibration on a Stage2 2012 STi. This knock event was repeatable and only observed after raising ignition timing from a previous knock-free level while. Restoring the lower values eliminated the detonation. Note that the safety and power of the dyno tuning process allowed this operator to quickly abort a run once they observed anomalous operation.

If learned values persist within the FKL table, or DAM remains below its maximum value, fine-tuning can be difficult. The values within the Fine Knock Learning Table can be cleared using the "ECU Reset" function, which also returns DAM to its default value. Do note this will also clear all other learned trims such as A/F Learning #1 and DBW/TPS learning.

In general, the Subaru engine does not suffer from any extreme efficiency irregularities under full power, so a smooth timing curve free of unreasonable jumps or dips is usually desirable. Pay attention to the Ignition Timing monitor for large abrupt changes to timing and smooth the Primary Ignition table accordingly. Closely monitor torque changes.

Pay careful attention to the various ignition timing compensation tables, in particular the Ignition Timing Compensation (Intake Temperature) table. This can play an extremely large role on the timing values observed on the dyno, especially when dyno-room airflow causes an ambient vs. IAT temperature discrepancy. Conversely, it is important that the values in this table be appropriately set up to help reduce the potential for detonation as air temperatures rise. Other compensations, such as those for Per-Gear and Per-Cylinder adjustments, can be used advantageously to account for increased mechanical load to the vehicle or airflow imbalances within the engine. However, you MUST account for how the compensation will adjust timing as those variables reach more extreme states, such as a very hot afternoon or while accelerating at WOT in 6th g ear.

Advanced Tuning Strategies - Ignition Timing

Now that we have outlined the various tables, monitors and logic that encompass the ignition timing and knock control strategies, we must actually adjust the timing curve and various thresholds in order to maximize efficiency and power (at the minimum cylinder pressure levels necessary for each) while minimizing the likelihood for inducing detonation. In practice, the objective of ignition timing calibration is to find MBT (or MTBT), which is Minimum timing for Best Torque, Finding MBT can only be safely accomplished with a good loading chassis dyno that has the ability to load the vehicle and measure the torque output at the same time. Chassis dynos such as Mustang Dynamometer, Mainline DynoLog, DynoCom, Bosch, and Dyno Dynamics have this ability, as do some traditionally inertia-based dynos such as Dynojets that are now being upgraded to include Eddy Current retarders. You can start in the higher gears (lower engine RPM) and have the chassis dyno to hold the vehicle and give you the torque output of the vehicle at a RPM breakpoint on your ECU calibration. You can start out at very light (low TPS) loads holding the vehicle in one specific cell in the Primary Ignition table and slowly add ignition advance until the vehicle does not make any more torque or gets close to the knock threshold for the motor. One suggestion is that you increase ignition advance for each particular cell until you see that torque no longer increases with the additional ignition advance. Now back off 2-4 degrees of ignition advance to keep the calibration on the safe side. Once you find where the motor produces the maximum amount of torque with the least amount of ignition advance, this is MBT. Tuning for cruising and partial throttle MBT will take a very, very long time and is not suggested unless you are very experienced with the particular chassis dyno you are using and the engine you are tuning. OEM calibration teams have vast resources at their disposal for calibrating the engine under these conditions, so their work is to be trusted in lieu of more accurate data. It is critical, however, to ensure that the ignition timing curve is very well calibrated over the entire "boosted" range of the engine, which can be accomplished by beginning WOT tuning at the minimum mechanical boost pressure, methodically adjusting each load range for MBT as boost pressures are increased. Please take into account that once you exceed MBT (Minimum spark advance for Best Torque output); it is possible to make less power with more ignition advance. Due to the various

properties of the Subaru engine, it is common to encounter the detonation threshold before MBT when advancing ignition timing under boosted conditions. It is important to re-scale the load axis as necessary on the Primary Ignition and Dynamic Advance tables to ensure that you have suitable resolution for ignition timing adjustment when power levels greatly exceed that of the factory vehicle and load axis scaling.

	0.25	0.40	0.55	0.70	Reflash 0.85	1.00	1.15	1.30	1.45	1.60	1.75	1.90	2.11	2.31	2.57	2.83	3.08	3.34	3.60
00	0.00	0.00	0.00	0.00	0.00	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63
200	0.00	0.00	0.00	0.00	0.00	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63
600	0.00	0.00	0.00	0.00	0.00	1.05	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63
000	0.00	0.00	0.00	0.00	0.00	1.05	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63
400	0.00	0.00	0.00	0.00	0.00	1.05	3.52	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63
800	0.00	0.00	0.00	0.00	0.00	1.05	1.05	3.16	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63
200	0.00	0.00	0.00	0.00	0.00	1.05	1.05	1.05	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63
600	0.00	0.00	0.00	0.00	0.00	1.05	1.05	1.05	4.57	4.92	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.6
000	0.00	0.00	0.00	0.00	0.00	1.05	1.05	1.05	3.52	4.22	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63	5.63
400	0.00	0.00	0.00	0.00	0.00	1.05	1.05	1.05	2.11	3.52	4.57	4.92	4.57	5.63	5.63	5.63	5.63	5.63	5.6
800	0.00	0.00	0.00	0.00	0.00	1.05	1.05	1.05	1.05	2.46	3.52	4.22	4.22	5.63	5.63	5.63	5.63	5.63	5.6
200	0.00	0.00	0.00	0.00	0.00	1.05	1.05	1.05	1.05	1.76	2.11	3.52	4.22	5.27	5.63	5.63	5.63	5.63	5.6
600	0.00	0.00	0.00	0.00	0.00	1.05	1.05	1.05	1.05	1.05	1.05	2.46	4.92	4.92	4.92	4.92	4.92	4.92	4.9
000	0.00	0.00	0.00	0.00	0.00	1.05	1.05	1.05	1.05	1.05	1.05	1.76	4.57	4.57	4.57	4.57	4.57	4.57	4.5
400	0.00	0.00	0.00	0.00	0.00	1.05	1.05	1.05	1.05	1.05	1.05	1.05	3.87	3.87	3.87	3.87	3.87	3.87	3.8
800	0.00	0.00	0.00	0.00	0.00	1.05	1.05	1.05	1.05	1.05	1.05	1.05	3.16	3.16	3.16	3.16	3.16	3.16	3.1
200	0.00	0.00	0.00	0.00	0.00	1.05	1.05	1.05	1.05	1.05	1.05	1.05	3.16	3.16	3.16	3.16	3.16	3.16	3.1
600	0.00	0.00	0.00	0.00	0.00	1.05	1.05	1.05	1.05	1.05	1.05	1.05	3.16	3.16	3.16	3.16	3.16	3.16	3.1

	0.25	0.40	0.55	0.70	0.85	e/Refla 1.00	1.15	1.30	1.45	1.60	1.75	1.90	2.11	2.31	2.57	2.83	3.08	3.34	3.60
000	_							_		_									_
800	20.08	28.16	28.16	25.35	22.54	9.53	4.61	3.20	2.85	2.85	2.50	2.50	2.15	1.80	1.09	0.74	0.74	0.39	-0.66
1200	29.92	39.06	35.55	32.38	28.16	19.02	12.70	5.66	5.31	4.96	4.26	3.91	3.55	2.85	2.15	1.80	1.45	1.09	0.04
1600	34.84	39.06	39.06	39.06	36.60	30.98	19.73	13.05	6.37	5.31	4.96	4.96	4.61	4.26	3.55	3.20	3.20	2.85	1.80
2000	40.12	46.09	46.09	42.93	40.47	37.66	26.76	19.02	14.10	9.53	9.18	8.48	6.72	7.07	6.37	5.66	5.31	4.61	3.55
2400	49.26	49.26	49.26	49.26	47.15	42.93	35.20	25.70	20.43	13.05	11.64	9.18	8.83	8.48	7.42	7.07	6.37	5.66	4.61
2800	49.26	49.26	47.85	47.15	43.98	38.71	37.66	33.44	22.54	15.86	13.75	11.29	10.59	10.23	9.18	8.48	7.42	6.37	5.31
3200	49.26	49.26	49.26	47.85	43.98	40.12	36.25	34.49	24.65	18.32	14.45	11.99	11.29	10.59	9.88	9.18	8.48	7.42	6.37
3600	49.26	49.26	49.26	45.39	42.58	40.12	34.49	32.38	29.57	21.84	15.86	13.40	12.34	11.64	10.94	10.23	9.53	8.48	7.42
4000	49.26	49.26	49.26	46.45	41.52	38.71	38.71	37.66	28.16	23.95	17.62	14.10	13.05	12.70	11.99	10.94	10.23	9.18	7.77
4400	49.26	49.26	49.26	45.04	43.63	40.12	36.60	34.49	26.41	22.54	19.38	17.27	14.80	14.10	13.05	11.64	10.59	9.53	8.13
4800	49.26	49.26	49.26	45.39	42.93	40.12	38.01	34.49	33.44	24.65	21.13	20.43	16.56	15.51	14.10	12.34	11.29	9.88	8.48
5200	49.26	49.26	47.85	45.04	43.63	41.17	39.77	35.90	30.63	26.41	23.24	21.84	18.32	16.56	15.16	13.05	11.64	10.23	8.83
5600	49.26	49.26	49.26	46.09	42.58	39.77	36.60	35.20	33.44	28.52	25.00	23.24	19.02	17.97	16.56	14.80	13.05	11.64	9.88
6000	49.26	49.26	47.50	44.34	42.58	39.77	38.01	35.90	34.14	29.92	26.41	24.65	20.43	19.38	17.97	16.21	14.45	12.70	10.94
6400	49.26	49.26	47.15	43.63	42.93	40.47	39.77	37.66	35.90	34.14	29.22	25.35	22.54	21.13	19.38	17.97	16.56	15.16	13.75
6800	49.26	49.26	47.15	43.63	42.93	40.47	39.77	37.66	_	34.14	29.57	26.05	24.30	22.89	21.48	20.08	18.32	_	15.16
7200	49.26	49.26	47.15	43.63	42.93	40.47	39.77	37.66					24.65		21.84	20.43	18.67	17.27	15.51
7600			47.15																

Ex: Here are the Primary Dynamic Advance TGVs Open and Primary Ignition TGVs Open table from a typical Stage2 2013 STi running on 93 octane gasoline. Note that the load axis has been rescaled to a maximum value of 3.60; peak load values of ~3.35 were observed during dyno tuning (stock load scaling ends at 2.95 g/rev). This extra resolution allows for an appropriate change to ignition timing should post-tune load values exceed those observed during the tuning session.

Assuming a safe timing map and accurate fueling have been established, one common strategy for quickly developing a timing curve very close to either MBT or the knock threshold is to remove a set amount of timing – such as 2 degrees – over the entire Load/RPM range, perform a WOT test run, then repeat the run with the timing added back. Fortunately the Accesstuner software allows for tuning Primary Ignition timing in "Real-time" without requiring a lengthy reflash process between changes. This facilitates the results from timing adjustments to be observed immediately under repeatable dyno conditions. This capability facilitates far more accurate and rapid ignition timing calibration processes.

Anywhere that torque has noticeably increased demonstrates that the increase to timing was desirable in that range; anywhere that power is

unaffected is likely already at or above MBT and a reduction in timing should be considered. If both a power increase and new knock corrections are observed with the advance in timing, the entire tune must be considered for causes (excessive boost, lean air/fuel mixture, etc.). Raising boost then adjusting the new higher load columns/values in the same fashion will eventually shape a full timing table with accurate ignition timing at all boost levels.

Generally speaking, a turbo-charged Subaru motor will run the least amount of ignition advance near peak torque and ignition advance will generally rise as RPM rise in order to keep up with the increasing piston speed. This trend is normal for most internal combustion spark ignition motors; as VE (Volumetric Efficiency) increases the amount of ignition advance a motor needs will decrease. As VE increases at WOT, when the turbo is producing boost, ignition advance will go down to its lowest point by peak torque then it will slowly increase during the torque plateau. This is not due to decreasing VE but rather to keep up with the increasing piston speeds. Once torque begins to fall off at higher engine speeds, ignition advance will generally increase at higher rates. This is due to the decreasing VE and is also done in order to keep up with the increasing piston speeds: you have to start the burn earlier so that the pressure wave expansion occurs at the optimal time.

There are some known situations where it is very common to see timing corrections in response to perceived noise. In general, these events are not of concern and should not be particularly alarming unless the corrections are very large. The corrections made during these scenarios are often due to shifting or rapid movements within the drive train and not necessarily to harmful noises generated within the engine:

- · On from-stop takeoffs while clutching out
- During gear shifts (this can be exacerbated by "power shifting" or using FFS)
- · While attempting acceleration at a low RPM in a high gear
- Under cruising-type conditions at freeway speeds
- · After sharply pressing/depressing the accelerator pedal

Due to the various grades of fuel available throughout the US and abroad, ignition timing values can vary greatly depending on the relative geographic and environmental conditions under which the vehicle is being operated. By definition, octane rating is determined by the fuel's ability to resist uncontrolled ignition; it is quite literally referred to as the "anti-knock index" (AKI) and is an average of two different methods for determining the theoretical resistance to detonation/knock relative to a reference fuel or engine operation conditions. The methods are "RON" and "MON"; AKI is calculated as "(RON+MON)/2", which is the common marking on fuel dispensing pumps. "Higher octane ratings correlate to higher activation energies: This being the amount of applied energy required to initiate combustion. Since higher octane fuels have higher activation energy requirements, it is less likely that a given compression will cause uncontrolled ignition, otherwise known as auto ignition or detonation." "Octane Rating." Wikipedia. 29 Jun 2011. http://en.wikipedia.org/wiki/Octane_rating#Effects_of_octane_rating>. Thus, the octane rating of the fuel being used will have a direct impact on the engine's ability to resist detonation and knock. You should always use the "premium" pump fuel available in your area; we also suggest the exclusive use of fuels from Top Tier Retailers For more information, please visit: http://www.toptiergas.com, when possible. You will generally find that higher octane fuels have longer burn times or combustion duration and will require more spark advance in order to reach its MBT value. This is an important phenomenon to note when using leaded race gas or other very-high octane fuels as power loss can be observed if timing is not properly advanced. Energy released from combustion that is not used during the power stroke is wasted during the exhaust stroke, which causes EGT and

In short, any number of conditions or factors can induce detonation. The sources are highly variable but in general, increased cylinder pressures and/or temperatures or reductions in effective octane level are the common "causes". The factors that lead into those are again varied, but from a tuning perspective, leaving varying fuel quality out of the equation, detonation and knock occur:

- When the engine speed is low and the manifold absolute pressure (MAP) is high
- · When combustion duration is long
- When temperatures are high (ambient, coolant, combustion chamber surface)
- · When the charge dilution is low
- · With high carbon deposits
- When the spark advance (or injection timing) is high Atkins, Richard D. An Introduction to Engine Testing and Development. Warrendale, PA: SAE International, 2009. 197. Print.

As can be seen, the "big three" of boost, ignition timing and air-fuel can all play an integral part in causing or contributing to detonation/knock. While dyno tuning, it is advised that you begin with lower-than-optimal ignition timing value, then slowly work upwards while closely monitoring dyno output for torque changes and dyno logs for timing corrections in response to detonation events.

If attempting to calibrate ignition timing under road conditions, extra care must be taken to ensure that timing is not advanced beyond MBT; simply tuning to the knock threshold can lead to a calibration with excessive and unnecessary ignition advance under conditions when the knock threshold is above the MBT threshold. This most commonly occurs with high octane fuels such as leaded race gas and E85. There are some basic spreadsheets and log analysis tools available that can help estimate torque output from road logs that include time and vehicle speed. Other quantifiable metrics such as trap speed or acceleration rate can be used in lieu of accurate torque data, though a precise measure of power against RPM is always preferred.

For an engine with stock internal components and valve train, the factory knock detection system is very accurate. As internal components and valve train are upgraded, the factory knock system's accuracy can be degraded by the increased background mechanical noise levels. Under these circumstances, it can be extremely beneficial to utilize advanced knock monitoring hardware, such as auxiliary knock amplification and monitor headset – commonly referred to as "det. cans" to ensure the knock control system is able to appropriately discern knock from mechanical

noise. When running pump gas, tank-to-tank variability can play a large role in determining the detonation threshold, so it is very important that the knock control system be effective at mitigating detonation when it occurs.

Fuel Injection Control

As outlined in the introduction, mass air flow is used to determine the mass of fuel needed for every fuel injection event. This is done by calculating the targeted or desired air/fuel ratio (AFR), which is quite literally a ratio for a given mass of air against a required mass of fuel. The ECU determines the final fueling target as a Fuel/Air Equivalence Ratio (more below), then performs calculations using the various injector characterization tables, such as Latency and Scale, to determine a final driven or "on time" for the fuel injectors.

Under Closed Loop operation, the fuel target is primarily dictated by the Closed Loop Compensation (Load) tables, which are used as an adder against a normal stoichiometric value for gasoline of 14.7 AFR (more precisely, 1.0 lambda). In this case, the tables traditionally contain negative values to achieve the net result of targeted AFR values slightly richer than 14.7. OEM Subaru calibrators likely used values slightly richer than 14.7 to improve combustion quality (reduce misfiring) and control exhaust gas temperatures. Closed Loop fueling errors are corrected for via the A/F Correction #1 and A/F Learning #1 functions based on front O2 sensor feedback; some models use A/F Correction #3 and A/F Learning #3 feedback functions based on rear/secondary O2 sensor feedback. This phenomenon can be minimized or eliminated using tables under the Closed Loop submenu in order to reduce variability in final fueling.

Under Open Loop operation, the fuel target is determined by the Primary Open Loop Fuel tables, which are essentially enrichment percentage tables, displayed in AFR gasoline equivalents for ease of human interpretation. In general, the richer values will be observed at higher load (torque) values. While immediate fuel trims are not used during Open Loop operation, learned fuel trims can be applied via the A/F Learning function

It is important to note that while the Primary Open Loop Fuel table should be a reasonably close representation of final observed tailpipe AFR, variance is inevitable. The equations for determining injector on-time based on a theoretical desired AFR value depend on many assumptions and variables. One of the leading factors for this is overall fuel chemistry. The OEM calibration and fuel injector data assumes "E0" gasoline; many areas now exclusively sell fuel with 10% ethanol (E10), which alters the amount of injection time required to achieve the same fuel/air ratios as fuel that does not contain ethanol by roughly 3-5%. E85 and other alternative fuels are discussed in-depth later in this article.

Terminology Definitions

- Fuel Injector Latency: This is the injector latency (offset) based on battery voltage. This is also sometimes referred to as injector opening
 time or dwell.
- Fuel Injector Pulse Width Limit (Min): This is the minimum limit for injector pulse width when fueling is enabled. This limit is active except during higher RPM/load/throttle initial lift-throttle (tip-out) conditions.
- Fuel Injector Scale: This value is the injector pulse width (in microseconds) for stoichiometric fueling per gram of calculated load. This value is the basis for the base pulse width (fuel injector scale * calculated load), which is used as a base for all fueling calculations. Because this value is a direct multiplier in the final pulse width calculation, smaller numbers are used for larger injectors.
- Fuel Injector Trim (Small IPW) [ALL 2.5L MODELS]: This is the fuel injector pulse width compensation (%) based on the last calculated non-compensated injector pulse width. This compensation is applied when the corresponding maximum injector pulse width and RPM thresholds are not exceeded.
- Fuel Injector Trim (Small IPW)(Max. IPW) [ALL 2.5L MODELS]: This is the maximum injector pulse width (last calculated non-compensated) in which the "Fuel Injector Trim (Small IPW)" table will be applied. Corresponding RPM threshold must also not be exceeded.
- Fuel Injector Trim (Small IPW)(Max. RPM) [ALL 2.5L MODELS]: This is the maximum RPM in which the "Fuel Injector Trim (Small IPW)" table will be applied. Corresponding IPW threshold must also not be exceeded.
- Fuel Injector Latency Adder (Small IPW) [2.0L SD ONLY]: This is a compensation (raw mms) to the current injector latency based on the
 current injector pulse width. This can be useful to tune for the non-linearity of larger injectors at low injector pulse widths to improve
 idle/low load behavior. NOTE: No stock data is provided for this table as it has been custom-coded by COBB Tuning in the absence of
 proper factory compensation logic for non-linear pulse compensation.
- Fuel Injector Trim (Per Cylinder)(#1-#4)(Fuel Multiplier Offset) [04-05 FXT MT/AT, 05-06 LGT MT/AT, 04-06 STI]: This is the per injector fuel adder for the cylinder given based on the last calculated non-compensated injector pulse width.
- Fuel Injector Trim (Per Cylinder)(#1-#4)(IPW Compensation) [06-08 FXT MT/AT, 09-12 FXT, 07-09 LGT MT/AT, 10-12 LGT, 07-09 LGT spec, 07-12 STI, 06-08 WRX MT/AT, 09-10 2.5GT, 09-12 WRX]: This is the per injector fuel pulse width compensation for the cylinder given based on the last calculated non-compensated injector pulse width.
- Primary Open Loop Fueling: This is the desired primary fueling in open loop when the Dynamic Advance Multiplier (DAM) is greater than
 or equal to the threshold determined by the "Primary Open Loop Fueling (High Detonation) DAM Threshold" table and the minimum
 threshold, as determined by the "Primary Open Loop Fueling Min. Activation" table, is met. The minimum limits and compensation values,
 as determined by the "Primary Open Loop Fueling Min. Enrichment..." and "Primary Open Loop Fueling Compensation..." tables, are also
 applied to determine the final primary fueling.

- Closed Loop Compensation (Load): This is the compensation to the closed loop fueling target based on calculated load and RPM. This
 table's value is added to the target, along with other compensations, to determine the final target. Note: Positive compensations (i.e.
 leaner impact) in this table will potentially force open loop fueling during closed loop. As mentioned, this table usually contains negative
 values, which causes for a commanded fueling target richer than stoichiometric.
- Tip-In Enrichment: This table's values represent additional injector pulse width during throttle tip-in. This enrichment is dependent on the tip-in enrichment activation and duration tables. The tip-in enrichment compensation tables can also influence the final enrichment. This function is sometimes referred to as an "accelerator pump" as it serves a similar function to a component of a carburetor of the same name. Tip-In Enrichment is used to accommodate for a temporary lean condition that results from rapid throttle plate movement. Among other causes, this lean condition exists from a temporary time delay in mass air flow measurement as well as a "drying" of the post-injector intake tract and cylinder head ports when the throttle plate is opened quickly.

Note: Depending on model year, additional tables (such as A/B) may exist – please refer to the Table Guide document within the main help file for a complete listing of the tables available by exact model and year. It can be important to change all tables as desired, potentially setting both tables to identical values where necessary to eliminate variables during the calibration process.

Calculations and Equations

- Load _(grams/rev) = Final Mass Air Flow _(grams/second) ÷ Engine Speed _(revs/min) × 60 _(sacs/min)
 - Example: 300 / 6000 * 60 = 3.0 (grams/rev)
- A/F Correction #1 = short-term fuel trim multiplier
 - Example: 1.0 = no change, 0.95 = -5% change, 1.05 = 5% change
- A/F Learning #1 = long-term fuel trim offset to short-term multiplier
 - Example: 0 = no change, -0.05 = -5% change, 0.05 = 5% change
- Final Fuel Multiplier = Final Fuel-Air EQ Ratio
 - Example: 1.10 = 10% richer than stoic. 0.90 = 10% leaner than stoich.
- Base IPW Calculation (microseconds) = Final Fuel Multiplier x Fuel Injector Scale x Load x (A/F Corr. #1 + A/F Learn #1)
 - Example: 1.20 * 3150 * 3.0 *(.98 + .02) = 11340 (microseconds)
- Final IPW _(microseconds) = Final Fuel Multiplier × Fuel Injector Scale × Load × (A/F Corr. #1 + A/F Learn #1) × Per Cylinder IPW Comp. × Small IPW Comp.
 - Note: Earlier ECUs do not have per-cylinder IPW compensation, but rather per-cylinder fuel multiplier compensation.
- Estimated Conversion for Injector Scalar to E0 Gasoline Flow Rate = 2707090 ÷ Fuel Injector Scale
 - Example: 2707090 / 4813 = 562.45 ~(cc/min)

Injector Characterization

One of the most critical aspects of engine calibration is the data that characterizes the various properties of the fuel injectors, such as flow rate and offset. If these values are not precisely adjusted, other aspects of the calibration may be skewed to account for the variance, such as the MAF or Open Loop Fueling tables. This can lead to wildly variably fuel injector control (and thus, air/fuel ratios) as environmental and operational conditions change over time. High quality aftermarket fuel injectors will come with this data; we currently host a spreadsheet online that summarizes the data we currently have available in an Accesstuner-friendly format. Aftermarket injector providers should be closely scrutinized based on their ability to provide you with complete characterization data with which to begin the conversion and calibration process. The values

within the spreadsheet will be a very accurate starting place, erring to the slightly rich side (Injector Fuel Scale too high) to begin initial tuning.



Ex: COBB Tuning 1000cc injectors are provided in collaboration with Injector Dynamics, a close technical partner. These injectors utilize Bosch-provided cores and are sold in closely matched sets during that meet strict specifications following rigorous testing procedures. Outliers are discarded. Exact injector flow scaling, latency and small IPW trim data is available upon request.

When accurate injector data is not available, some basic guidelines can help determine reasonably correct values. Before attempting to "hand calibrate" unknown injectors, however, it is greatly advised to seek characterization services to determine flow rate and offset values. The small amount of vehicle downtime will be easily made up for by the resulting improved quality of the final calibration. Isolating the injectors under laboratory conditions provides unparalleled accuracy to that of on-car calibration using consumer-grade wideband measurement equipment.

To determine a starting Fuel Injector Scale value, this equation can be used: (Factory Injector Size in CC / New Injector Size in CC) * Factory Fuel Injector Scale. This essentially calculates the ratio of the stated injector size against current scaling within the ECU and then recalculates the new scaling value based on the change in stated injector size. To determine a starting latency value, it is suggested to start from OEM values then scale the entire table upwards or downwards by a multiplication factor to correct for any fueling error (trims) observed at idle and low pulse width values, assuming the Fuel Injector Scale and MAF scaling have been established and verified as correct. In general, Denso-based injectors that have been modified will exhibit much higher latency values than stock.

Tuning Guidelines - Fuel Injector Scale, Latency, etc.

During the calibration process, with specific regards to fueling, it is recommended practice to always log (at least) these monitors:

- 1. Injector Duty Cycle
- 2. Mass Air Flow (g/s)
- 3. Mass Air Flow (voltage)
- 4. Commanded Fuel Final
- 5. Wideband O2 AFR (typically a dyno attachment)
- 6. Engine Speed
- 7. Calculated Load
- 8. Closed/Open Loop Switch

In lieu of data from the manufacturer or as endorsed by COBB Tuning, input the calculated value as a starting Fuel Injector Scale value. When calibrating injectors without a known injector scale value, we suggest you install the stock intake system (with stock MAF calibration) and run with stock level fuel pressure levels. DO NOT attempt to tune for an aftermarket Intake and aftermarket injectors at the same time. Observe A/F Correction #1 and A/F Learning #1 within the Dashboard. While operating the engine in Closed Loop mode (see monitor) at full temperature (coolant temperature between 180-195 F and intake air temperature +/- 15 degrees F of ambient temperature), you can make adjustments to the Fuel Injector Scale value until the A/F Correction #1 + A/F Learning #1 are as close to zero as possible, +/- 5% is generally acceptable. The closer

you can get to 0% is ideal. Operate the engine through as much of the idle and cruising range as is feasible. If fueling is observed to be universally lean (positive trims), scalar should be increased to add fuel, and vise-versa.

Fuel Injector Latency can be adjusted by observing fuel trims at idle and very low pulse widths with the factory intake and MAF calibration in place. Again, factory intake hardware and factory fuel pressure values are critical to reducing variables and achieving accurate results. Changes to latency values will have the most impact where IPW is lowest. If fueling is observed to be universally lean (positive trims) at low pulse width values, latency should be increased to add fuel, and vise-versa. A common error is adjusting the MAF curve's lower range to account for fueling errors near idle, which are actually frequently caused by incorrect latency values.

The ratio value of the (Factory Injector Size / New Injector Size) portion of the calculation can be used as a universal starting multiplier for these other critical fuel/injector control tables: Tip-In Enrichment, Cranking Fuel Injector Pulsewidth Base, and Fuel Injector Pulsewidth Limit (Min) tables.

An aftermarket intake will affect your A/F Correction #1 and A/F Learning #1 values at idle and part throttle, making it nearly impossible to find accurate Injector Scale or Latency values. If you have an aftermarket intake, please use the above equation to establish your initial Fuel Injector Scale and Latency values then move forwards with the MAF recalibration as necessary.

Mass Air Flow Measurement, Load Calculation and Fuel Trims

Terminology Definitions

- MAF Calibration: This table determines the sensor calibration for the mass airflow sensor.
- MAF Compensation (Intake Temp): This is the compensation to mass airflow based on intake temperature and the current mass airflow.
- MAF Limit (Max) [ALL 2.5L MODELS]: This value is the maximum allowed airflow. The airflow value will be capped at this limit regardless.

Mass Air Flow - MAF Sensor

OEM calibrations for MAF sensors and their corresponding intake housings are developed using very precise airflow testing measurements – commonly referred to as a flow bench. This equipment allows for deriving a very precise calibration that the calibrator can trust while performing other calculations and on-car fueling adjustments. In the absence of flow testing hardware in the aftermarket tuning industry, it is important to be able to recalibrate for MAF housing changes using on-car testing and data from two primary sources. These are the factory front O2 sensor, which provides data for use during closed loop operation, and an aftermarket wideband O2 pickup, which provides data for use during open loop operation.

It is no coincidence that a significant number of factory EFI implementations rely on a mass air flow meter for airflow calculation. While contingent on certain factors, such as a sealed intake system free of leaks, using a mass air flow sensor allows for precise airflow measurement – and thus application of fuel – under virtually all conditions, both environmental and mechanical. It inherently accounts for many otherwise-critical factors, such as engine wear (leakdown) and ambient air temperature.

In general, it should only be necessary to adjust the MAF sensor calibration if the intake housing has been changed from stock. If the intake housing has not been changed, altering the MAF curve is usually an incorrect adjustment for an unrelated calibration error or mechanical issue with the vehicle. It is highly recommended to keep a new MAF sensor on hand for testing purposes, as their measurement accuracy will degrade over time. If this sensor's accuracy is measurably degraded, the calibrator may be inclined to incorrectly adjust the MAF curve, incorrectly assuming a simple vehicle-to-vehicle variance is the cause.

Overall performance of an aftermarket MAF housing will depend largely on its design, construction materials, location and air filter choice/location. In general, laminar flow (http://en.wikipedia.org/wiki/Laminar_flow) is desired across the MAF sensor, which will lead to a consistent and predictable airflow curve across the sensor's usable range. Some intakes, such as models offered by COBB Tuning and AEM, offer "air straightening" fins in order to smooth the airflow before it approaches the mass air sensor. Sharp bends, changes to diameters, boundary layer (ht tp://en.wikipedia.org/wiki/Boundary_layer) properties and numerous other factors can degrade the consistency of quality of the airflow across the sensor, hence the careful engineering and design of the factory airbox system. Intake housings made of thin metal materials, such as aluminum or stainless steel, can be prone to dimensional instability as the temperature of the housing itself changes and the internal diameter of the housing grows and shrinks. Pragmatically, many aftermarket intakes suffer from variable performance based on whether or not the radiator fans are running and blowing air across the air filter assembly. Careful consideration must be given to all aspects of aftermarket intake design and



Ex: COBB Tuning SF Intake and Airbox Combination system. The MAF housing is made of a composite material for dimensional stability with temperature changes and incorporates air straighteners to promote laminar flow. The complimentary airbox shields the intake from hot engine-bay air and wind from the radiator fans during their operation. A mounting bracket holds the housing and filter firmly in place and free of vibration.

Mass Air Flow - Speed Density

Speed Density allows for Mass Air Flow to be calculated, rather than measured, using manifold pressure, manifold air temperature and volumetric efficiency (or pumping efficiency) as the primary inputs. Our implementation also allows for compensation based upon engine coolant temperature and barometric pressure. Coolant temperature can impact how well fuel is atomized; barometric pressure can change relative exhaust back-pressure levels.

Extended calibration on a load-bearing dyno is a virtual requirement for completing a full Speed Density tune. Using a load-bearing dyno, the dyno operator can lock engine speed to precise values to allow for Volumetric Efficiency table adjustments under steady-state operations. Increasing throttle position while rotating speed is locked will increase manifold pressure and allow for calibration across the entire range of possible manifold pressures at a given rotational speed (RPM).

Please read our complete Speed Density tuning guides for a detailed overview of software usage, hardware requirements and calibration concerns

Limiters

It is important to note that the factory has limiters or ceiling values for both Mass Air Flow g/s and Load, usually 300.00 g/s and 4.0 g/rev, respectively. Setups that have airflow capabilities greatly exceeding stock may exceed these thresholds, which can cause a dangerous condition as Mass Air Flow or Load are artificially capped. The MAF limiter can be raised by adjusting the "MAF Limit (Max)" table as desired. For Load, earlier vehicles use a single table: raise the limit in the "Load Limit (Max) Primary" table as desired. For later vehicles, which use the "Load Limit (Max) Secondary" table, it is also necessary to modify the "Load Limit (Max) Secondary Compensation (Barometric)" or "...(Intake Temp)" tables. If you change either of these to contain +100% values, it will double the load limit present in the "Load Limit (Max) Secondary" table (ex. 4.0 g/rev = 8.0 g/rev limit, or 16.0 g/rev limit if both are set to 100%).

The 2002-2005 WRX "traditional" ECU is unfortunately saddled with some hard-coded limiters, (also 300.00 g/s and 4.0 g/rev) that *cannot* be raised beyond these values via simple tuning adjustment. We have addressed this issue in our 2002-2005 WRX Speed Density software with custom-code to raise these limiters beyond any practical limit for a 4 cylinder Subaru engine. These limiters are removed for both MAF and SD fueling operation modes when using the Speed Density ECU.

Disabling Learned Fuel Trims under Open Loop Operation

From the factory, all Subaru ECUs use four distinct learning ranges for learned long-term fuel trims (LTFT). These are known as "A/F Learning A/B/C/D" and can be logged or viewed in realtime while Live Connected to the ECU. The learned value being actively applied at any given time can be monitored by viewing the "A/F Learning #1" monitor. The three break-points given in the "A/F Learning #1" table will determine the thresholds between each range (A-B, B-C, C-D). The min for range A and max for range D are determined by "A/F Learning Modify Airflow Limit (Min)/(Max)" tables, respectively. Keep in mind that this is only the cap for when learning is active, the actual learned value will be applied at all times while above the C-D threshold value. This behavior can be problematic for aftermarket or performance tuning as minute MAF scaling errors under cruising conditions can have broad impact over the entire open loop range of operation.

Thus, we can disable learning in the D range by setting the "Max" table to just below the C-D threshold. This will still allow for the A, B and C ranges to be populated and used under various cruising conditions based on fueling errors between those breakpoints. For example, if the C-D breakpoint value is 50.00 g/s, setting "A/F Learning Modify Airflow Limit (Max)" to 49.99 g/s will disable the D range from being populated with learned values.


As the engine transitions through the various MAF g/s ranges for the A-D learned ranges, a smoothing factor ("A/F Learning #1 Range Smoothing Factor") is applied to blend between the two different learned values if the difference between the current A/F Learning #1 value and the current learned range is greater than the absolute value within the "A/F Learning #1 Range Smoothing Activation (Min. Abs. Change)". This is to help prevent immediate abrupt changes to the active A/F Learning #1 value being applied, such as if the previous range being referenced was +10% and the new range being referenced is -5%. This smoothing behavior can cause learned values from the "C" range to be carried into "D" range based on the smoothing factor, even if learning has been disabled for the "D" range. The activation threshold and smoothing factor are both adjustable, so you can change these behaviors based on specific tuning needs.

Tuning Guidelines - Mass Air Flow Calibration

To calibrate the MAF curve during Closed Loop fueling, adjust MAF g/s against MAF voltage up or down based on total observed fuel trims errors. If the summation of A/F Correction #1 and A/F Learning #1 is +6%, highlight the MAF Calibration cell for that particular MAF voltage and hit the "M" key. The correct multiplication value for this particular situation would be 1.06; this adjustment will now tell your ECU for that particular MAF voltage you now have a 6% greater MASS of air entering the motor so 6% more mass of fuel should be injected. After this adjustment is made your summed A/F Correction #1 and Learning #1 should be much closer to zero.

To calibrate the MAF curve during Open Loop fueling, adjust MAF g/s against MAF voltage up or down based on wideband air-fuel ratio measurement against the ECU's targeted AFR value, which can be observed by monitoring Commanded Fuel Final. If actual wideband AFR is observed to be 12.0 when Commanded Fuel Final is observed to be 11.0, increase MAF g/s over the range for which the error exists by ~+9% or multiply by 1.09 (12.0/11.0) After this adjustment is made, observed wideband readings should very closely match Commanded Fuel Final.

It is important to remember how Load is calculated – MAF / RPM * 60, so any changes to the MAF curve will cause a resulting change to the Load values observed for the same operating conditions, so it is important to finalize the Mass Air Flow calibration before wholesale changes are made to any tuning table that uses Load as an axis value.



Ex: Example Mass Air Flow sensor curve from the COBB Tuning SF Intake system for the 08+ WRX/STi. Note the smooth and predictable shape, indicating both quality hardware and accurate calibration. Peaks, valleys and other unnatural changes to the shape of the MAF curve can indicate a hardware issue or calibration error.

Tuning Guidelines - Speed Density Calibration

Calibrating the Volumetric Efficiency table during Closed Loop fueling is very similar to the aforementioned methodology for MAF-based tuning, however you will now be editing a much larger table. Row by row, column by column, the VE table must be adjusted to account for fueling errors in the same fashion as the normal MAF curve, using the factory fuel trims to adjust while in Closed Loop operation. For open loop, we again compare observed wideband data against Commanded Fuel Final.

Unlike a MAF calibration, it is not entirely uncommon to have incongruent peaks or valleys within the Volumetric Efficiency table, as this table represents the engine assembly's "final" operating efficiency for any given manifold pressure and RPM value, including all hardware from intake air filter to muffler tip. VE values between 50%-70% at idle and 90%-120% under full boost WOT operation are common, depending on camshafts, cylinder heads, turbocharger kit, intake and exhaust manifolds, etc. An increase in the Volumetric Efficiency value will cause an increase in fueling, as the mass of air entering the engine will be calculated to be higher, and vise-versa.

As with traditional MAF tuning, changes to the VE Table will cause a resulting change to the Load values observed for the same operating conditions, so it is important to finalize the Volumetric Efficiency calibration before wholesale changes are made to any tuning table that uses Load as an axis value.

	2.00	4.00	6.00	8.00	10.00	12.00	14.00	16.00	18.00	20.00	22.00	24.00	26.00	28.00	30.00	32.00	34.00	36.00	38.00	40.00	42.00	44.00
350	49.66	54.00	58.35	64.16	69.67	72.50	75.34	77.60	79.30	80.08	80.86	81.95	83.04	83.04	83.04	83.04	83.04	83.04	83.04	83.04	83.04	83.04
700	50.82	54.91	58.99	64.69	70.08	73.01	75.94	78.31	79.91	80.62	81.33	82 38	83.42	83.42	83.42	83.42	83.42	83.42	83.42	83.42	83.42	83.42
1050	52.49	56.31	60.13	65.58	71.22	73.98	76.74	79.01	80.52	81.16	81.80	82.80	83.80	83.80	83.80	83.80	83.80	83.80	83.80	83.80	83.80	83.80
1400	57.60	61.75	66.39	70.10	73.82	75.90	77.99	79.71	81.13	81.70	82.27	83.23	84.19	84.19	84.19	84.19	84.19	84.19	84.19	84.19	84.19	84.19
1750	62.91	67.39	72.85	75.16	76.40	77.81	79.23	80.41	81.74	82 24	82.74	83.65	84.57	84.57	84.57	84.57	84.57	84.57	84.57	84.57	84.57	84.57
2100	64.40	69.48	75.06	77.19	78.29	79.00	80.12	81.11	82.35	82.77	83.20	84.08	84.95	84.95	84.95	84.95	84.95	84.95	84.95	84.95	84.95	84.95
2450	65.09	70.78	76.48	78.43	79.37	80.19	81.20	82.02	83.16	83.52	83.88	84.71	85.55	85.55	85.55	85.55	85.55	85.55	85.55	85.55	85.55	85.55
2800	67.71	72.72	77.72	79.90	81.88	82.77	83.45	84.24	85.23	85.49	85.75	86.57	87.40	87.40	87.40	87.40	87.40	87.40	87.40	87.40	87.40	87.40
3150	68.55	72.58	76.61	80.92	83.00	84.48	85.77	86.66	87.44	87.53	87.62	88.34	89.07	89.07	89.07	89.07	89.07	89.07	89.07	89.07	89.07	89.07
3500	73.56	76.88	81.05	84.66	86.27	87.02	87.27	88.26	89.00	89.23	89.46	89.94	90.30	90.92	91.54	91.54	91.54	91.54	91.54	91.54	91.54	91.54
3850	77.03	80.13	84.06	88.21	88.82	88.80	88.77	89.86	90.55	91.32	91.63	91.93	91.93	92.97	94.02	94.02	94.02	94.02	94.02	94.02	94.02	94.02
4200	80.30	83.18	86.26	90.65	90.88	90.29	89.69	90.24	92.37	94.37	95.43	96.49	96.49	96.49	96.49	96.49	96.49	96.49	96.49	96.49	96.49	96.49
4550	83.69	86.91	90.12	92.82	93.21	92.51	91.81	92.28	94.24	96.53	97.85	99.17	99.17	99.17	99.17	99.17	99.17	99.17	99.17	99.17	99.17	99.17
4900	87.08	89.10	91.12	93.52	93.89	93.14	92.38	92.80	94.68	96.82	98.37	99.92	99.92	99.92	99.92	99.92	99.92	99.92	99.92	99.92	99.92	99.92
5250	89.69	90.90	92.11	94.22	94.56	93.76	92.96	93.34	95.17	97.01	98.59	100.17	100.17	100.17	100.17	100.17	100.17	100.17	100.17	100.17	100.17	100.1
5600	90.80	91.68	92.55	94.69	95.09	94.34	93.58	94.01	95.69	97.37	98.80	100.23	100.23	100.23	100.23	100.23	100.23	100.23	100.23	100.23	100.23	100.2
5950	89.24	90.18	91.11	93.21	93.55	92.76	91.96	92.33	94.30	96.27	97.79	99.31	99.31	99.31	99.31	99.31	99.31	99.31	99.31	99.31	99.31	99.31
6300	87.68	88.68	89.68	91.72	92.02	91.13	90.23	90.49	92.52	94.56	96.04	97.52	97.52	97.52	97.52	97.52	97.52	97.52	97.52	97.52	97.52	97.52
6650	86.12	87.18	88.24	90.24	90.49	89.56	88.62	88.82	90.87	92.92	94.07	95.22	95.22	95.22	95.22	95.22	95.22	95.22	95.22	95,22	95.22	95.22
7000	84.56	85.68	86.81	88.75	88.95	87.98	87.01	87.15	89.43	91.71	92.94	93.96	93.97	93.97	93.97	93.97	93.97	93.97	93.97	93.97	93.97	93.97
7350	84.56	85.88	86.81	88.75	88.95	87.98	87.01	87.15	89.24	91.34	92.37	93.20	93.21	93.21	93.21	93.21	93.21	93.21	93.21	93.21	93.21	93.21
7700	84.56 e Spee	85.88	86.81	88.75		86.87	87.01	87.15	89.24	91.34	92.37	93.20	93.21	93.21	93.21	93.21	93.21	93.21	93.21	93.21	93.21	93.21

Ex: Example Volumetric Efficiency table from a 2005 STi utilizing a Blouch Dom3.0 turbocharger, built shortblock with stock heads and camshafts and front-mount intercooler. Note the smooth shape and predictable increases in VE as manifold inlet pressures rise. Engines with upgraded cylinder head and camshaft packages will display increased VE at higher RPM.

Open Loop Fuel Control

Terminology Definitions

- Commanded Fuel Final: Final commanded fueling before the injector pulse width is calculated. This includes all corrections to fueling, including Manifold Wall Wetting Compensations.
- Primary Open Loop Fueling [04-08 FXT MT/AT, 09-13 FXT, 05-09 LGT MT/AT, 07-09 LGT spec.B, 04-07 STI, 12-14 STI, 02-05 WRX, 06-08 WRX MT/AT, 09-10 2.5GT, 09-14 WRX]: This is the desired primary fueling in open loop when the Dynamic Advance Multiplier (DAM) is greater than or equal to the threshold determined by the "Primary Open Loop Fueling (High Detonation) DAM Threshold" table and the minimum threshold, as determined by the "Primary Open Loop Fueling Min. Activation" table, is met. The minimum limits and compensation values, as determined by the "Primary Open Loop Fueling Min. Enrichment..." and "Primary Open Loop Fueling Compensation..." tables, are also applied to determine the final primary fueling.
- Primary Open Loop Fueling Min. Activation [ALL 2.5L MODELS]: This value is the minimum enrichment for activation of primary open loop fueling. If enrichment, as determined by the "Primary Open Loop Fueling..." table look-up and compensated by the "Primary Open Loop Fueling Compensation (Ign. Timing)" table, is greater than or equal to this value, primary open loop fueling will be enabled. If enrichment is less than this value, the primary fuel map is disabled.
- Primary Open Loop Fueling Min. Activation [02-05 WRX]: This value is the minimum enrichment for activation of primary open loop fueling. If enrichment, as determined by the "Primary Open Loop Fueling..." table lookup, is greater than or equal to this value, primary open loop fueling will be enabled. If enrichment is less than this value, the primary fuel map is disabled.
- Primary Open Loop Fueling Min. Enrichment (Accelerator) [09-13 FXT, 07-09 LGT MT/AT, 10-12 LGT, 07-09 LGT spec.B, 07-14 STI, 08 WRX MT/AT, 09-10 2.5GT, 09-14 WRX]: This is the minimum enrichment limit for primary open loop fueling (if active) based on accelerator pedal position. This minimum is also applied before any of the primary fueling compensations is applied (except for "Primary Open Loop Fueling Compensation (Ign. Timing)").
- Primary Open Loop Fueling Min. Enrichment (TPS) [02-05 WRX]: This is the minimum enrichment limit for primary open loop fueling (if
 active) based on throttle position. This minimum is also applied before any of the primary fueling compensations is applied.
- Primary Open Loop Fueling Min. Enrichment (TPS) [ALL 2.5L MODELS]: This is the minimum enrichment limit for primary open loop fueling (if active) based on throttle position. This minimum is also applied before any of the primary fueling compensations is applied (except for "Primary Open Loop Fueling Compensation (Ign. Timing)").

<u>Tuning Guidelines – Primary Open Loop Fueling</u>

Properly adjusting the Primary Open Loop Fueling table, assuming all hardware has been properly characterized, is a straightforward process. In general, the values observed from the wideband O2 should reasonable approximate the values shown within the Primary Open Loop Fueling table, or more accurately, the values logged by the Commanded Fuel Final monitor while in Open Loop operation. If they do not, this could be an indicator that there is a mechanical issue with the vehicle or that further calibration of the fuel injectors or MAF housing is required in order to correct for the error. Adding advanced information-gathering tools, such as a portable fuel pressure gauge, can help quickly hone in on potential causes when fueling anomalies are observed.

However, as long as the values are reasonably close, do not be overly concerned about a small variance. The Primary Open Loop Fueling table is often most-easily edited by multiplying the table values by the difference between the actual wideband air-fuel ratio observed and your desired air-fuel ratio. For example, if wideband air-fuel ratio indicates 11.5, and you'd like to achieve 11.2 under those same conditions, select the appropriate part of the table and multiply that section by .97 (11.2/11.5).


	0.40	0.55	oad (g/ 0.70	0.85		1.15	1.30	1.45	1.60	1.75	1.90	2.11	2.31	2.52	2.73	2.94	3.14	3.35	3.56
300	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70
1200	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70
1600	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70
2000	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	13.34	12.54	12.30	12.14	11.98	11.98	11.98	11.98	11.98	11.98	11.91
2400	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	12.80	12.14	12.06	11.91	11.91	11.83	11.83	11.76	11.69	11.69	11.69
2800	14.70	14.70	14.70	14.70	14.70	14.70	14.70	14.70	12.80	12.14	12.06	11.91	11.91	11.83	11.83	11.76	11.69	11.69	11.69
3200	14.70	14.70	14.70	14.70	14.70	14.70	14.70	13.84	12.71	12.06	11.98	11.91	11.91	11.83	11.83	11.76	11.69	11.61	11.61
3600	14.70	14.70	14.70	14.70	14.70	14.70	12.80	12.80	12.71	12.06	11.91	11.91	11.83	11.83	11.76	11.61	11.47	11.40	11.40
4000	14.70	14.70	14.70	14.70	14.70	13.94	12.80	12.80	12.63	12.06	11.76	11.76	11.76	11.69	11.61	11.47	11.33	11.27	11.20
4400	14.70	14.70	14.70	14.70	14.04	13.84	12.80	12.80	12.63	12.06	11.76	11.76	11.69	11.54	11.54	11.40	11.27	11.20	11.13
4800	14.70	14.70	14.25	13.63	13.44	13.16	13.07	12.98	12.54	12.06	11.76	11.76	11.69	11.54	11.54	11.40	11.27	11.20	11.13
5200	14.70	14.70	13.84	13.63	13.44	12.80	12.80	12.80	12.54	12.06	11.76	11.76	11.69	11.54	11.54	11.40	11.27	11.20	11.13
5600	14.70	14.15	13.54	13.16	12.98	12.71	12.63	12.54	12.46	12.06	11.76	11.61	11.47	11.40	11.33	11.20	11.13	11.07	11.00
6000	13.84	13.44	13.16	12.80	12.54	12.46	12.46	12.38	12.14	11.69	11.40	11.33	11.27	11.20	11.20	11.07	11.00	10.94	10.88
6400	13.73	12.89	12.63	12.22	11.98	11.76	11.76	11.76	11.69	11.54	11.27	11.20	11.13	11.07	11.07	11.00	10.94	10.88	10.81
800	13.73	12.89	12.63	12.22	11.98	11.76	11.76	11.76	11.69	11.54	11.27	11.13	11.07	11.00	11.00	11.00	10.94	10.81	10.75
7200	13.73	12.89	12.63	12.22	11.98	11.76	11.76	11.76	11.69	11.54	11.27	11.13	11.00	10.94	10.94	10.94	10.88	10.81	10.75
7600	13.73	12.89	12.63	12.22	11.98	11.76	11.76	11.76	11.69	11.54	11.27	11.13	11.00	10.94	10.94	10.94	10.88	10.75	10.69

Ex: Primary Open Loop Fueling table from a 2011 STi using Injector Dynamics ID1000 injectors and COBB Tuning SF Intake system. Thanks to accurate characterization data for the injector and intake hardware changes, the Open Loop Fueling table is a close representation of actual air-fuel ratio and allows for open loop fueling be easily adjusted as the calibrator desires.

The turbo EJ engine tends to require a richer air-fuel ratio than other common turbocharged engines in order to control detonation and temperatures. On 91-93 octane fuels, air fuel ratios ranging from 10.8-11.5, respectively, tend to provide the best blend of combustion efficiency and detonation resistance. Outside of this range, it is uncommon to observe significant power gains with leaner mixtures, and rich misfiring can occur with richer mixtures. Always begin with an overly rich air-fuel ratio, and then slowly remove fueling until the desired fueling is achieved. This process will also help identify the point at which power is measurably increased as the mixture is made leaner, or when power is unaffected from a leaner mixture. Close observation must be paid to all knock monitors as outlined in previous sections when adjusting air-fuel ratio on pump gas as the threshold for detonation on pump gas can be abrupt and bear harsh repercussions.

For Stage1 and Stage2 vehicles operating near sea level, close attention should be paid to overall injector duty cycle. The factory injectors "go static", meaning the injector coil no longer has adequate time to discharge between cycles, at approximately 95% IDC. If mechanical boost creep

forces the fuel system beyond its limits, an alternate solution to reduce boost or increase fuel system capability must be found in order for a consistent and safe calibration to be completed.



Ex: This Stage2 2011 STi is demonstrating signs that its stock injectors are being pushed beyond their controllable limits. The highlighted enrichment at higher RPM is not due to a tuning choice, but rather the lack of coil discharge time between cycles at IDC is pushed beyond 95%. While enough fuel is available to achieve suitable AFR under these conditions, if fueling demand is further increased under other circumstances, such as cooler weather or much higher boost levels, a dangerous lean condition will result.

STi-Specific Concerns

Previous rounds of ECU discovery revealed that the 2008-2011 STI actually uses two Primary Open Loop Fueling tables. These tables are named "Primary Open Loop Fueling (Dyn. Adv. Adder B High)" and "Primary Open Loop Fueling (Dyn. Adv. Adder B Low)". Depending on the year of the vehicle, one (but only one) of these two tables will be Realtime tunable (as indicated by the red "R"). Complex logic determines a sliding scale to apply between these two tables and it cannot be guaranteed which of the two will more heavily affect the current fuel target at any given time. As such, when custom tuning, we recommend setting these two tables to the same values to ensure consistent fueling and that any changes made will immediately be observed. This can be easily done using the copy and paste functionality (Ctrl-C and Ctrl-V, respectively) within Accesstuner then reflashing the new map. This has been "fixed" within our definitions for the 2012-2014 STI and for all 2008-2014 STI "Speed Density" ECUs.

Boost Control

Terminology Definitions

- Boost Targets [ALL MODELS]: These are the desired boost targets. The underlying value is in absolute pressure and the final target is
 impacted by the "Boost Targets Compensation..." tables. If you are tuning in climates with low barometric pressure, it is important to note
 that this table is actually in absolute pressure but has been converted by a static value of 14.7psi, or sea-level atmospheric pressure, for
 relative pressure (boost) display.
- Boost Control Disable (Fuel Cut Active)(Min. Boost) [ALL 2.5L MODELS]: When the fuel cut (rev limiter) is active and boost control is disabled (as governed by these tables) and boost drops to or below this value, boost control will be re-enabled. When fuel cut is active and boost is greater than this value and the related load and RPM thresholds are also met, boost control will be disabled. This table can cause boost control to be disabled following the use of LC or FFS if boost does not fall below the threshold during this launch or shift.

- Manifold Rel. Pressure [ALL MODELS]: This monitor represents the ECU's final calculated Manifold Relative Pressure (boost) value, which is actual Manifold Absolute Pressure – Barometric Pressure.
- Rev Limit (Fuel Cut) Primary Fuel Resume (Max. Boost) [ALL 2.5L MODELS]: When the rev limit fuel cut is enabled and RPM drops
 below the threshold necessary to resume fuel, fueling will not resume until boost also drops below this table's threshold. When using LC
 and FFS, this limiter can cause delay the re-enabling of normal engine operation during or following the launch or shift.
- Turbo Dynamics Boost Error [ALL MODELS]: This is the monitor for displaying the current boost target vs. boost actual error value.
 Positive values represent "underboost"; negative values represent "overboost". It can be helpful to always target a small amount of positive Turbo Dynamics Boost Error to prevent boost control oscillations as the ECU attempts to reduce boost during an overboost condition.
- Turbo Dynamics Burst [02-05 WRX]: This is the absolute correction to wastegate duty based on boost error (boost target actual boost) when boost error swings rapidly from negative to positive or vice versa as determined by the "Turbo Dynamics Burst Activation (Boost Error)(Neg Below/Pos Above)" table thresholds.
- Turbo Dynamics Continuous [02-05 WRX]: This is the absolute correction to wastegate duty based on boost error (boost target actual boost) when boost error meets the thresholds defined in the "Turbo Dynamics Continuous Activation (Boost Error)(Active Below/Active Above)" table.
- Turbo Dynamics Integral Negative [ALL 2.5L MODELS]: This is the integral component of absolute correction to wastegate duty based on boost error. This correction can accumulate over a short period of time within the limits defined by the "Turbo Dynamics Integral Cumulative Limits (Min/Max)" table. This correction is active when the thresholds determined by the following tables are exceeded: "Turbo Dynamics Integral/Proportional Activation (Min. RPM)", "Turbo Dynamics Integral/Proportional Activation (Min. Boost Target)", and "Turbo Dynamics Integral Activation Boost Error..."
- Turbo Dynamics Integral Positive [ALL 2.5L MODELS]: This is the integral component of absolute correction to wastegate duty based on boost error. This correction can accumulate over a short period of time within the limits defined by the "Turbo Dynamics Integral Cumulative Limits (Min/Max)" table. This correction is active when the thresholds determined by the following tables are exceeded: "Turbo Dynamics Integral/Proportional Activation (Min. RPM)", "Turbo Dynamics Integral/Proportional Activation (Min. Boost Target)", and "Turbo Dynamics Integral Activation Boost Error..."
- Wastegate Duty Cycles (High) [ALL MODELS]: These are the maximum values for wastegate duty after all "Wastegate Duty Cycles Compensation..." tables are applied.
- Wastegate Duty Cycles (Low) [ALL 2.5L MODELS]: This is the starting values for wastegate duty after all Wastegate Duty Cycles Compensation..." tables are applied.
- Wastegate Duty Cycles (Low)(Off-Idle) [02-05 WRX]: Wastegate duty is initially set to this value when leaving idle mode. Idle mode is
 determined by throttle position. The "Wastegate Duty Cycles Compensation..." tables do NOT impact this value.


Mechanical Concerns - Boost Creep

From the factory, most all Subaru factory turbochargers are equipped with 7-10psi wastegate actuators, meaning the mechanical minimum for boost pressure is 7-10psi when input energy is enough to create that much (or more) boost. While this is also a minimum, it is expected to also set the cap for maximum boost levels generated when the boost control system is disabled. The internal wastegate port area of the turbocharger is engineered to provide adequate flow with stock exhaust systems at stock power levels while keeping spool-up quick and predictable. A significant limitation of this wastegate area is encountered with the greatly increased coldside and hotside airflow capabilities through the turbocharger that are created by upgraded downpipes, catback exhausts, intake systems, etc. By definition, mechanical boost creep is the forceful overrunning of the turbocharger due to the wastegate's inability to relieve exhaust gases from the turbine housing – without a complimentary increase in airflow through the wastegate area, it is unable to relieve/bypass enough exhaust gasses to keep boost levels limited to the actuator's spring pressure.

This phenomenon is most prevalent on stock turbocharger vehicles with upgraded turboback exhaust and intake components, especially those that remove normal "restrictions", such as those that delete all catalysts or muffling devices. "Favorable" environmental conditions, such as low ambient temperatures and high barometric pressures, worsen the situation – in the US, boost creep is most problematic in the low-lying cool coastal Northwest and Northeast regions. Periods of high exhaust gas temperature and heavy load will tend to exacerbates the situation, such as when going WOT in 5th or 6th gear or while climbing a long hill under power.

If this condition is observed during tuning, the calibrator must determine if the creep levels can be controlled to an acceptable level. When boost levels rise uncontrollably, the fuel system can be pushed beyond its useful limits, the detonation threshold can potentially be raised above a safe level, etc. Road verification of proper boost control on vehicles demonstrating significant creep is important. Without going into further detail, the possible solutions or workarounds for these situations include:

- Installation of an external wastegate system
- Removal of aftermarket parts such as intake or downpipe
- · Porting and polishing of the internal wastegate area of the turbine housing
- · Throttle position tuning to limit boost at higher RPM
- Fuel system upgrades to ensure adequate fueling under creep conditions
- Increase octane to raise detonation threshold (race gas, E85, etc.)



Ex: This Stage2 STi demonstrated a significant amount of boost creep during dyno tuning conditions. Boost in PSI is the Y-axis, RPM is the X-Axis. This datalog was taken with the boost control system disabled; the red line has been added to demonstrate the boost curve expected if the wastegate system was working correctly. This vehicle's boost control system was completely ineffective past 4000 RPM, with boost levels peaking at ~15.5psi at ~5600 RPM. Should conditions change and the detonation threshold become greatly reduced, this vehicle will have no mechanical authority to reduce boost to keep knock under control. The possible result? Boom.

For more information regarding boost creep and potential solutions, please refer to this COBB Tuning document, published by Christian Krahenbuhl: How To Determine If You Have Mechanical Boost Creep.

Relevant Monitors

During the calibration process, with specific regards to boost control, it is recommended practice to always log (at least) these monitors:

- 1. Manifold Rel. Pressure
- 2. Wastegate Duty Cycle
- 3. Turbo Dynamics Boost Error
- 4. Throttle Position (or Requested Torque for applicable models)
- 5. Engine Speed

Tuning Guidelines - Boost Targets

Adjusting the Boost Targets table is a straight-forward procedure. From the factory, the target values scale from lowest (left columns) to highest (right columns), a style that can easily be mimicked while performance tuning. Using the interpolation functions (vertical and horizontal) facilitates shaping a linear targets table from lower to higher throttle positions and across the practical RPM range of the engine. In general, it is

recommended to review the factory and OTS mapping Boost Targets tables for your particular application, and then reshape the higher throttle areas of the table as necessary. Boost Targets tuning at low throttle positions will have negligible/zero impact on actual boost response and control.

	0.0	11.9	23.8	35.7	59.5	71.4	83.3	95.2
1800	-6.34	-4.02	-1.31	-0.54	3.33	3.33	3.42	3.42
2000	-6.34	-4.51	-0.54	0.04	4.58	4.49	4.58	4.68
2200	-6.34	-5.28	0.43	7.12	9.38	10.60	12.49	12.49
2400	-6.34	-5.96	1.97	9.48	12.63	14.21	15.78	17.36
2600	-6.34	-6.34	2.94	11.81	14.15	15.33	16.49	17.67
3200	-13.01	-6.92	4.29	12.49	14.56	15.60	16.63	17.67
3600	-13.01	-8.28	2.46	12.49	14.56	15.60	16.63	17.67
4400	-13.01	-8.28	-3.25	12.49	14.44	15.41	16.40	17.36
5200	-13.01	-8.28	-3.25	12.49	14.44	15.41	16.40	17.36
6000	-13.01	-8.28	-3.35	12.49	13.69	14.31	14.91	15.51
6400	-13.01	-8.28	-3.35	12.49	13.09	13.40	13.69	14.00
6800	-13.01	-8.28	-3.35	12.49	12.49	12.49	12.49	12.49

Ex: Target boost table for a Stage2 2006 STi. Note that Boost Targets are similar to stock at lower throttle positions and use higher boost targets at higher throttle positions. Boost Targets are kept low (12.49psi) at higher RPM to account for the turbocharger's naturally decreasing boost output (it cannot hold flat boost to redline) and help alleviate the burden carried by stock fuel injectors that are at their power limits. "Actual" boost was observed to be 17.5psi peak, tapering to 12psi at redline, during a WOT dyno run.

The Boost Targets table should be a relatively close approximation of the tuner's desired boost targets combined with the natural limits of the turbocharger, fuel system, detonation threshold, etc. When injector size precludes running excessive boost at higher RPM, it is important for the Boost Targets table to closely reflect this in order for the ECU to command the boost control changes necessary to achieve a proper and safe boost curve. Logging "Turbo Dynamics Boost Error" will show the calibrator where target vs. actual boost errors are occurring and allow for either refinement of the wastegate duty cycle or Boost Targets table so that Boost Error is minimized as desired. As mentioned above, it can be helpful to always maintain a small positive Turbo Dynamics Boost Error value in order to help reduce boost oscillations when the ECU uses Turbo Dynamics to correct for an overboost condition.

Tuning Guidelines - Wastegate Duty Cycle

Adjusting the wastegate duty cycle tables is a straightforward process with a bit of experience and background information. Final WGDC is primarily controlled via the "High" table; the initial reference value for the closed-loop portion of the control comes from the "Low" table, where applicable. In general, the WGDC table should scale from low to high with throttle position in the same general shape as the Boost Targets table. The horizontal interpolation function is extremely helpful when shaping WGDC tables during a custom tuning session. For 2.5L vehicles, it is important to keep a distinct but small gap between the "High" and "Low" tables. One common method for setting up the Low table is to copy the values from the High table, then reduce them downwards by a relative factor of 15-25%.

Generally accepted tuning practice suggests always beginning with each table set to full zeros in order to determine the mechanical minimum boost level, as well as potentially identify any anomalies with the boost control system, such as uncontrollable mechanical boost creep or a failing wastegate door actuator. This will also facilitate a constant and repeatable boost curve while working on other areas of the tune, such as ignition advance and open loop fueling.

It can sometimes be helpful to use very large WGDC values at low RPM where full boost cannot be achieved. This will help reduce spool-up times, though only by a small margin.

	Throt	tle Posi	tion (%) - Real	time/Re	eflash		
	20.0	30.0	40.0	50.0	60.0	70.0	80.0	90.0
2400	0.00	7.14	14.29	21.43	28.57	35.71	42.86	50.00
3029	0.00	3.21	6.42	9.63	12.84	16.05	19.26	22.47
3657	0.00	3.21	6.42	9.63	12.84	16.05	19.26	22.47
4286	0.00	3.09	6.19	9.29	12.38	15.47	18.57	21.66
4914	0.00	2.93	5.86	8.80	11.73	14.66	17.59	20.52
5543	0.00	3.04	6.09	9.13	12.18	15.22	18.26	21.30
6171	0.00	3.21	6.42	9.63	12.84	16.05	19.27	22.48
6800	0.00	3.21	6.42	9.63	12.84	16.05	19.27	22.48
ngin	e Spee	d (RPN) - Real	time/Re	eflash			

	20.0	30.0	40.0	50.0	60.0	70.0	80.0	90.0
0	0.00	5.36	10.72	16.07	21.43	26.79	32.15	37.50
600	0.00	5.36	10.72	16.07	21.43	26.79	32.15	37.50
1200	0.00	5.36	10.72	16.07	21.43	26.79	32.15	37.50
1800	0.00	5.36	10.72	16.07	21.43	26.79	32.15	37.50
2400	0.00	5.36	10.72	16.07	21.43	26.79	32.15	37.50
3029	0.00	2.41	4.82	7.22	9.63	12.04	14.45	16.85
3657	0.00	2.41	4.82	7.22	9.63	12.04	14.45	16.85
4286	0.00	2.32	4.64	6.97	9.29	11.60	13.93	16.25
4914	0.00	2.20	4.39	6.60	8.80	11.00	13.19	15.39
5543	0.00	2.28	4.57	6.85	9.14	11.41	13.70	15.98
6171	0.00	2.41	4.82	7.22	9.63	12.04	14.45	16.86
6800	0.00	2.41	4.82	7.22	9.63	12.04	14.45	16.86

Ex: Wastegate Duty Cycles (High) and (Low) tables from 2006 STi equipped with 18G turbocharger, external wastegate and 3-port boost control solenoid. Note that the values used to achieve targeted boost levels are much smaller than the factory, which is a result of the large hardware changes to the boost control system. This WGDC resulted in a flat ~18psi boost curve (14.5psi default spring pressure).

Boost Control is one system where road tuning can often shine compared to a dyno tuning session. It is always suggested to verify dyno-generated WGDC tables on the street or track to verify the mechanical loads placed on the vehicle during the dyno session were suitable for boost control tuning of the vehicle's real-world performance. If the simulated loads were much lower or higher than the "average" encountered, the vehicle may be prone to underboosting or overboosting under its normal load conditions in the wild.

<u>Tuning Guidelines – Turbo Dynamics</u>

The Turbo Dynamics system is an elaborate but elegant system for controlling wastegate duty cycle in order to achieve the targeted boost values when mechanical conditions allow for it. Practically speaking, the system is the Proportional and Integral (P+I) components of a full "PID" http://en. wikipedia.org/wiki/PID_controller system, meaning it features multiple levels of feedback controls and response sizes but does not utilize a predictive component. Adjustments to the Turbo Dynamics tables are primarily spurred by mechanical changes to the boost control system, such as to the boost control solenoid or when an external wastegate system has been fitted to the vehicle.

Without going into significant detail, basic guidelines can be used for the vast majority of Turbo Dynamics adjustment. It is common practice to leave these tables stock on vehicles that still use the factory turbocharger and boost control system, as the factory calibration values usually work

quite well. If the system is found to be too sensitive – IE, overboosting results in oscillations from using correction values that are too large – the tables can be reduced by a factor, such as 10%, and retested. The inverse is true for a system that is found to be too insensitive – IE, severe underboosting or overboosting is not quickly mitigated.

One general guideline is to wait to adjust Turbo Dynamics until the Boost Targets and WGDC tables have been refined. For example, if the newly-tuned WGDC High table uses peak values of 40% to achieve full boost, and the factory vehicle's calibration used peak values of 80% to achieve full boost, reducing the factory Turbo Dynamics values by half will result in a very good approximation of the values needed for the new boost control system.