

DataStream Report

The Report is created by **LAUNCH** X-431

Vehicle Information



Year:2011

Make:TOYOTA

Model:Tacoma

VIN:5TFUU4EN2BX005907

Engine Size:1GR-FE 4.0L 6 Dual Overhead Cam (DOHC)

Vehicle Software Version:V51.50

Diagnostic Application Version:V8.00.031

Diagnostic path:Automatic Search > Europe and Other > Tacoma > 2011.09- > ABS (Anti-lock Braking System)/VSC (Vehicle Stability Control)/TRC (Traction Control System)

Repair Shop

Shop Name:

Address:

Zip Code:

Telephone:

Email:

SN:989347712041

Test Time:2025-10-22 20:10:28



Data Stream 【Pre-Repair】

Name	Value	Unit
ABS Solenoid (SFLH)	OFF	
ABS Solenoid (SFLR)	OFF	
ABS Solenoid (SFRH)	OFF	
ABS Solenoid (SFRR)	OFF	
ABS Solenoid (SRLH)	OFF	
ABS Solenoid (SRLR)	OFF	
ABS Solenoid (SRRH)	OFF	
ABS Solenoid (SRRR)	OFF	
ABS Warning Light	OFF	
Accelerator Opening Angle%	0	%
Auto LSD Indicator Light	OFF	

Automatic Disconnect Diff Switch	OFF	
BA Ctrl Status	OFF	
Brake Warning Light	ON	
Buzzer	OFF	
Deceleration Open	Normal	
Deceleration Sensor	0	ft/s^2
Deceleration Sensor2	0.469	ft/s^2
ECB Motor Relay	OFF	
EFI Communication Invalid	Normal	
EFI Communication Open	Normal	
Engine Revolutions	711	rpm
Fail Safe Motor Relay	ON	
FL Speed Open	Normal	
FL Speed Sensor Voltage Open	Normal	
FL Wheel ABS Ctrl Status	OFF	
FL Wheel Acceleration	0	ft/s^2
FL Wheel Direction	Forward	
FL Wheel Speed	0	mph
FL Wheel VSC Ctrl Status	OFF	
Forward and Rearward G	-0.643	ft/s^2
FR Speed Open	Normal	
FR Speed Sensor Voltage Open	Normal	
FR Wheel ABS Ctrl Status	OFF	
FR Wheel Acceleration	0	ft/s^2
FR Wheel Direction	Forward	
FR Wheel Speed	0	mph
FR Wheel VSC Ctrl Status	OFF	
Gear Position	P,N	
IG Voltage Value Decreased	Normal	
IG Voltage Value Increased	Normal	
IG1 Voltage Value	13.804	V
Inspection Mode	Other	
L4 Switch	OFF	

Lateral G	0	ft/s^2
M/C Pressure Sensor Noise	Normal	
Main Idle Switch/System Start	ON	
Master Cylinder Open	Normal	
Master Cylinder Sensor	0.49	V
MT Voltage Value	0	V
Number of DTC	0	
Number of IG ON(Inspection)	255	
Parking Brake Switch	ON	
Real Engine Torque	-6.436	lb-ft
Rear Diff Lock Switch	OFF	
RL Speed Open	Normal	
RL Speed Sensor Voltage Open	Normal	
RL Wheel ABS Ctrl Status	OFF	
RL Wheel Acceleration	0	ft/s^2
RL Wheel Direction	Forward	
RL Wheel EBD Ctrl Status	OFF	
RL Wheel Speed	0	mph
RL Wheel VSC Ctrl Status	OFF	
RR Speed Open	Normal	
RR Speed Sensor Voltage Open	Normal	
RR Wheel ABS Ctrl Status	OFF	
RR Wheel Acceleration	0	ft/s^2
RR Wheel Direction	Forward	
RR Wheel EBD Ctrl Status	OFF	
RR Wheel Speed	0	mph
RR Wheel VSC Ctrl Status	OFF	
Shift Information	OFF	
Shift Lever Position	P,N	
Slip Indicator Light	OFF	
Solenoid Relay	ON	
Steering Angle Sensor	22.500	deg
Steering Angle Value	22.500	deg

Steering Open	Normal	
Stop Light Switch	OFF	
TR(A)C/VSC Solenoid(SM1)	OFF	
TR(A)C/VSC Solenoid(SM2)	OFF	
TRC(TRAC)Brake Ctrl Status	OFF	
TRC(TRAC)Ctrl Status	OFF	
TRC(TRAC)Engine/EV Ctrl Status	OFF	
TRC/VSC Off Mode	Normal	
Vehicle Speed	0	mph
Yaw Rate Open	Normal	
Yaw Rate Sensor	0	degree/s
Yaw Rate Sensor Voltage Open	Normal	
Yaw Rate Sensor2	0	degree/s
Yaw Rate Value	0	degree/s
Zero Point of Decele	0	ft/s^2
Zero Point of Decele2	0	ft/s^2
Zero Point of M/C	0	psi
Zero Point of Steering Angle	0	deg
Zero Point of Yaw Rate	0	deg
Zero Point of Yaw Rate2	0	degree/s

.....

Disclaimer

This test report is for reference only for vehicle test and maintenance. The vehicle operating data provided in this report are all static data. The detailed dynamic diagnostic data can be read by professional maintenance device, and LAUNCH will not be liable for any accidents and failures arising therefrom!