

DataStream Report

The Report is created by **LAUNCH** X-431

Vehicle Information



Year:2011

Make:TOYOTA

Model:Tacoma

VIN:5TFUU4EN2BX005907

Engine Size:1GR-FE 4.0L 6 Dual Overhead Cam (DOHC)

Vehicle Software Version:V51.50

Diagnostic Application Version:V8.00.031

Diagnostic path:Automatic Search > Europe and Other > Tacoma > 2011.09- > ECMECT (Engine and ECT)

Repair Shop

Shop Name:

Address:

Zip Code:

Telephone:

Email:

SN:989347712041

Test Time:2025-10-24 16:41:24



Data Stream 【Pre-Repair】

Name	Value	Unit
# Codes(Include History)	N/A	
+BM Voltage	N/A	V
2nd Air Monitor	N/A	
2nd Air Monitor	N/A	
2nd Air Monitor CMPL	N/A	
2nd Air Monitor ENA	N/A	
4WD Switch	N/A	
A/C Monitor	N/A	
A/C Monitor	N/A	
A/C Monitor CMPL	N/A	
A/C Monitor ENA	N/A	

A/C Signal	N/A	
A/F Heater Duty B1S1	N/A	%
A/F Heater Duty B2S1	N/A	%
A/T Oil Temperature 1	N/A	degree C
A/T Oil Temperature 2	N/A	degree C
Accel Fully Close Learn #1	N/A	deg
Accel Fully Close Learn #2	N/A	deg
Accel Sens. No.1 Volt %	N/A	%
Accel Sens. No.2 Volt %	N/A	%
Accel Sensor Out No.1	N/A	V
Accel Sensor Out No.2	N/A	V
Accelerator Idle Position	N/A	
Accelerator Position	N/A	%
ACIS VSV	N/A	
ACT VSV	N/A	
Actuator Power Supply	N/A	
AF Lambda B1S1	N/A	
AF Lambda B2S1	N/A	
AFS Current B1S1	N/A	mA
AFS Current B2S1	N/A	mA
AFS Voltage B1S1	N/A	V
AFS Voltage B2S1	N/A	V
All Cylinders Misfire Count	N/A	
Atmosphere Pressure	N/A	kPa
Av Engine Speed of All Cyl	N/A	rpm
Battery Voltage	N/A	V
Calculate Load	N/A	%
Cancel Switch	N/A	
Cat OT MF F/C Cylinder#1	N/A	
Cat OT MF F/C Cylinder#2	N/A	
Cat OT MF F/C Cylinder#3	N/A	
Cat OT MF F/C Cylinder#4	N/A	
Cat OT MF F/C Cylinder#5	N/A	

Cat OT MF F/C Cylinder#6	N/A	
Cat OT MF F/C History	N/A	
Catalyst Monitor	N/A	
Catalyst Monitor	N/A	
Catalyst Monitor CMPL	N/A	
Catalyst Monitor ENA	N/A	
Catalyst OT MF F/C	N/A	
Catalyst Temp B1S1	N/A	degree C
Catalyst Temp B1S2	N/A	degree C
Catalyst Temp B2S1	N/A	degree C
Catalyst Temp B2S2	N/A	degree C
Closed Throttle Position Switch	N/A	
Complete Parts Monitor	N/A	
Component Monitor CMPL	N/A	
Component Monitor ENA	N/A	
Coolant Temp	N/A	degree C
Cylinder #1 Misfire Count	N/A	
Cylinder #2 Misfire Count	N/A	
Cylinder #3 Misfire Count	N/A	
Cylinder #4 Misfire Count	N/A	
Cylinder #5 Misfire Count	N/A	
Cylinder #6 Misfire Count	N/A	
Cylinder Number	N/A	
Destination	N/A	
Dist Batt Cable Disconnect	N/A	km
Distance from DTC Cleared	N/A	km
EGR/VVT Monitor	N/A	
EGR/VVT Monitor	N/A	
EGR/VVT Monitor CMPL	N/A	
EGR/VVT Monitor ENA	N/A	
Electrical Load Signal 1	N/A	
Electrical Load Signal 2	N/A	
Engine Run Time	N/A	s

Engine Speed	N/A	rpm
Engine Speed of Cyl #1	N/A	rpm
Engine Speed of Cyl #2	N/A	rpm
Engine Speed of Cyl #3	N/A	rpm
Engine Speed of Cyl #4	N/A	rpm
Engine Speed of Cyl #5	N/A	rpm
Engine Speed of Cyl #6	N/A	rpm
Engine Type	N/A	
EVAP (Purge) VSV	N/A	%
EVAP Monitor	N/A	
EVAP Monitor	N/A	
EVAP Monitor CMPL	N/A	
EVAP Monitor ENA	N/A	
Evap Purge Flow	N/A	%
EVAP Purge VSV	N/A	
EVAP System Vent Valve	N/A	
FC TAU	N/A	
Fuel Cut Condition	N/A	
Fuel Pump Speed Control	N/A	
Fuel Pump/Speed Status	N/A	
Fuel System Monitor	N/A	
Fuel System Monitor CMPL	N/A	
Fuel System Monitor ENA	N/A	
Fuel System Monitor Result	N/A	
Fuel System Status #1	N/A	
Fuel System Status #2	N/A	
Heated Cat Monitor CMPL	N/A	
Heated Cat Monitor ENA	N/A	
Heated Catalyst Monitor	N/A	
Heated Catalyst Monitor	N/A	
Heater Monitor CMPL	N/A	
Heater Monitor ENA	N/A	
Idle Fuel Cut	N/A	

IG OFF Elapsed Time	N/A	min
IGN Advance	N/A	deg
Ignition Trig. Count	N/A	
Immobiliser Communication	N/A	
Initial Engine Coolant Temp	N/A	degree C
Initial Intake Air Temp	N/A	degree C
Injection Volum (Cylinder1)	N/A	ml
Injector(Port)	N/A	us
Intake Air	N/A	degree C
Knock Correct Learn Value	N/A	degree CA
Knock Feedback Value	N/A	degree CA
Lock Up	N/A	
Long FT B1S1	N/A	%
Long FT B2S1	N/A	%
MAF	N/A	gm/s
MIL	N/A	
MIL on Run Distance	N/A	km
MISFIRE LOAD	N/A	g/rev
Misfire Margin	N/A	%
Misfire Monitor	N/A	
Misfire Monitor CMPL	N/A	
Misfire Monitor ENA	N/A	
MISFIRE RPM	N/A	rpm
Model Code	N/A	
Model Year	N/A	
Neutral Position Switch Signal	N/A	
Number Of Emission DTC	N/A	
O2 Heater B1S2	N/A	
O2 Heater B2S2	N/A	
O2 Heater Curr Val B1S2	N/A	A
O2 Heater Curr Val B2S2	N/A	A
O2S B1S2	N/A	V
O2S B2S2	N/A	V

O2S Impedance B1S2	N/A	ohm
O2S Impedance B2S2	N/A	ohm
O2S(A/FS) Heater Monitor	N/A	
O2S(A/FS) Heater Monitor	N/A	
O2S(A/FS) Monitor	N/A	
O2S(A/FS) Monitor	N/A	
O2S(A/FS) Monitor CMPL	N/A	
O2S(A/FS) Monitor ENA	N/A	
OBD Requirements	N/A	
Open Side Malfunction	N/A	
Power Steering Signal	N/A	
Purge Cut VSV Duty	N/A	%
Purge Density Learn Value	N/A	
RES/ACC Switch	N/A	
Running Time from MIL ON	N/A	min
SET/COAST Switch	N/A	
Shift Status	N/A	
Shift Switch Status (2 Range)	N/A	
Shift Switch Status (3 Range)	N/A	
Shift Switch Status (D Range)	N/A	
Shift Switch Status (L Range)	N/A	
Shift Switch Status (R Range)	N/A	
Shift Switch Status(4 Range)	N/A	
Short FT B1S1	N/A	%
Short FT B2S1	N/A	%
SLT Solenoid Status	N/A	
SLU Solenoid Status	N/A	
SPD (NT)	N/A	rpm
SPD (SP2)	N/A	km/h
ST1	N/A	
Starter Signal	N/A	
Stop Light Switch	N/A	
System Guard	N/A	

System Identification	N/A	
Target Air-Fuel Ratio	N/A	
TC and TE1	N/A	
TC Terminal	N/A	
Throttle Fully Close Learn	N/A	V
Throttle Idle Position	N/A	
Throttle Motor Current	N/A	A
Throttle Motor DUTY	N/A	%
Throttle Motor Duty (Close)	N/A	%
Throttle Motor Duty (Open)	N/A	%
Throttle Position Command	N/A	V
Throttle Position No.1	N/A	V
Throttle Position No.2	N/A	V
Throttle Require Position	N/A	V
Throttle Sens Open Pos #1	N/A	V
Throttle Sens Open Pos #2	N/A	V
Throttle Sensor #2 Volt %	N/A	%
Throttle Sensor Position	N/A	%
Throttle Sensor Volt %	N/A	%
Time after DTC Cleared	N/A	min
TOTAL FT #1	N/A	
TOTAL FT #2	N/A	
Transfer L4	N/A	
Transmission Type	N/A	
Transmission Type2	N/A	
Vacuum Pump	N/A	
Vapor Pressure (Calculated)	N/A	kPa
Vapor Pressure Pump	N/A	kPa
Vehicle Load	N/A	%
Vehicle Speed	N/A	km/h
VN Turbo Type	N/A	
VVT Aim Angle #1	N/A	%
VVT Aim Angle #2	N/A	%

VVT Change Angle #1	N/A	degree FR
VVT Change Angle #2	N/A	degree FR
VVT Control Status #1	N/A	
VVT Control Status #2	N/A	
VVT OCV Duty #1	N/A	%
VVT OCV Duty #2	N/A	%
Warmup Cycle Cleared DTC	N/A	

.....

Disclaimer

This test report is for reference only for vehicle test and maintenance. The vehicle operating data provided in this report are all static data. The detailed dynamic diagnostic data can be read by professional maintenance device, and LAUNCH will not be liable for any accidents and failures arising therefrom!