DI0ES-04

DTC□	23[]	Vehicle[\$peed[\$ignal[Abnormal
------	------	---------------------------------

CIRCUIT DESCRIPTION

SeepageDI-691.

DTC[No.	Detection[]tem	Trouble[<u>A</u> rea
23	Volsials Physical Phy	
	Vehicle[speed[sensor[pulse[]s[abnormal.	Cruise@ontrolECU

WIRING DIAGRAM

SeepageDI-691.

INSPECTION PROCEDURE

1 Check[vehicle[speed[sensor[See[page[BE-78]]].

NG

Replace vehicle speed sensor.

ΟK

 $\label{lem:check_and_replace_cruise_control} \begin{tabular}{ll} CU & Cutoff & Cut$