## HOW[TO]TROUBLESHOOT[ECU]CONTROLLED[\$YSTEMS

## **GENERAL** INFORMATION

| System    | Page |
|-----------|------|
| 1. Engine | DI-1 |

The troubleshooting procedure and how to make use of it are described on the following pages.