DIAZL-01

CRUISE[MAIN[Indicator[Light[Circuit

CIRCUIT DESCRIPTION

When the cruise control main witch sturned N, CRUISE MAIN indicator gight ght Lip.

INSPECTION PROCEDURE

1[]

Perform Active Test of hand-held tester.

PREPARATION:

Connect[]he[]hand-held[]ester[]o[]he[]DLC3.

CHECK:

Check the cruise indicator of the combination meter using Active Test.

OK:

Description	Tester[display	Check[condition
CRUISE[[ndicator[]]ght	CRUISE[]NDIC	ON/OFF



Proceed_to_next_circuit_inspection_shown_on problem_symptom_table_(See_page_DI-865).

NG

Check and replace combination meter. (See page N-38).