DIAWK-01

18. Panel Switch Does Not Function (A/C control only)

INSPECTION PROCEDURE Display check mode Panel Switch Check screen). 1 NG□ Replace the multidisplay. OK Check["AVC-LAN communication circuit" (See page DI-1215)[] 2□ Replace or repair AVC-LAN circuit. NG□ OK 3∏ Check[] Gateway [ECU[[AVC-LAN [adopter)] circuit" [[See [page [DI-1221]]. NG Repair or replace wire harness and connector. OK

Check and replace A/C amplifier (Center ECU).