## AUTOMATIC TRANSMISSION (A750F for 1HD-FTE) HOW TO PROCEED WITH TROUBLESHOOTING

DIAV7\_0

When using hand-held tester, troubleshoot in accordance with the procedure on the following pages. Vehicle Brought to Workshop Items inside are titles of pages in this manual, with the page number indicated in the bottom portion. See the indicated pages for detailed explanations. Customer Problem Analysis, P.⊓DII-101 Connect the hand-held tester to DLC3 If the display shows "UNABLE TO CONNECT TO VEHICLE" when you have connected the hand-held[tester, inspect[DLC3[P.[DI-102]] Check DTC and Freeze Frame Data (Precheck) Record[or[Print[DTC[and[Freeze[Frame[Data[P[DI-102 Clear DTC and Freeze Frame Data P. DI-102 5 // Visual Inspection// Setting@herCheck@ode@biagnosis@p.@l-102 Symptom does not occur Symptom Simulation 7 // Problem Symptom Confirmation // P∏N-27 Symptom occur 11 **OK Code** DTC Check Basic nspection NG P.⊓D∏-102∏ P[D]-102 OK NG DTC Chart Mechanical System Test P.∏D∏-102 13 OK NG OK Manual Shifting Test P. DII-102 14 Problem Symptoms Table - P. DI-119 Chapter 3 Chapter 1 NG Chapter 2 OK OK (Off-Vehicle) (Electronic) (On-Vehicle) P.∏0∏-119 P. DI-119 NG NG 16 Parts Inspection 15 Neutral Start Switch Circuit Check Circuit A/T.P. Indicator Circuit Check Inspection P.TDIT-156ftofDI-180 ĮЦ

Repair

Confirmation Test

Identification of Problem

When using hand-held tester, troubleshoot in accordance with the procedure on the following pages.

