POWER STEERING GEAR (Independent Front Suspension) COMPONENTS

Intermediate Shaft Assembly 120 (1,250, 89) 34 (350, 25) ◆ Cotter Pin 72 (730, 53) 圙 72 (730, 53) 42 (430, 31) PS Gear Assembly Return Tube 44 (450, 32) *40 (409, 29) ◆ O–Ring Clip 18 (184, 13) Gasket Tube Clamp Pressure Feed Tube 18 (180, 13) **Bracket Engine Oil Filter Assembly** No. 2 Engine Under Cover ₫ x 6 **₽** x 7 No. 1 Engine Under Cover N·m (kgf·cm, ft·lbf) : Specified torque ◆ Non-reusable part N* For use with SST F06125



