REASSEMBLY

TR03U-02

Coat all of the sliding and rotating surfaces with gear oil before reassembly.