46 LAND CRUISER (LHD) Power Source Winch I26 Ignition SW B-G IG1 NO. 1 Relay F37(A), F38(B) Fusible Link Block Battery B-R Winch Control SW Front Left Side of Fender Apron

OVERALL

ELE

CTRICAL WIRING

DIAGRAM