HOW[TO[TROUBLESHOOT[ECU[CONTROLLED[SYSTEMS

GENERAL INFORMATION

IN01J-07

Allarge@umber@fleCU@ontrolled@systems@are@sed@n@hell_AND@RUISER.@n@eneral,@helleCU@ontrolled system@s@onsidered@olbe@very@ntricate@system@equiring@migh@evel@flechnical@nowledge@and@xpert skill@flroubleshoot.@however,@helfact@flhat@flyouproceed@olpspect@he@ircuits@ne@by@ne,@roubleshooting@flhese@systems@smot@omplex.@flyoupave@adequate@nderstanding@flhe@system@and@basic@nowledge@flectricity,@ccurate@iagnosis@and@ecessary@epair@an@eperformed@olpcate@and@x@helproblem. This@manual@s@esigned@hrough@mphasis@fl@he@bove@standpoint@olpelp@ervice@echnicians@erform@ccurate and effective troubleshooting, and is compiled for the following major ECU controlled systems:

System	Page
Engine	DI-1

The troubleshooting procedure and how to make use of it are described on the following pages.

FOR USING HAND-HELD TESTER

- Before using the hand-held tester, the hand-held tester's operator manual should be read throughly.
- If the hand-held tester cannot communicate with ECU controlled systems when you have connected
 the cable of the hand-held tester to DLC3, turned the ignition switch ON and operated the scan tool,
 there is a problem on the vehicle side or tool side.
 - (1) If communication is normal when the tool is connected to another vehicle, inspect the diagnosis data link line (Bus ⊕ line) or ECU power circuit of the vehicle.
 - (2) If communication is still not possible when the tool is connected to another vehicle, the problem is probably in the tool itself, so perform the Self Test procedures outlined in the Tester Operator's Manual.