DI88V-06

## 7. Navigation screen not stabilized (Synchronous error).

## **INSPECTION PROCEDURE**

1 Check[the[havigation[ECU[power[source[circuit[see[page[DI-256].

NG

Replace or repair wire harness or connector.

OK

2 | Check[the[display[\$ignal[circuit[see[page[DI-259]].

NG

Replace or repair wire harness or connector.

OK

Replace the multi-display.