DI3CZ-02


DTC	RrDEF, FOOT	Front Evaporator Temperature Sensor circuit
-----	-------------	---

CIRCUIT DESCRIPTION

This sensor detects the temperature inside the cooling unit and sends the appropriate signals to the A/C amplifier.

Blinking light	Detection Item	Trouble Area
RrDEF FOOT	Open or short in front evaporator temperature sensor circuit.	 Front evaporator temperature sensor. Harness or connector between front evaporator temperature sensor and A/C amplifier. A/C amplifier.


WIRING DIAGRAM



INSPECTION PROCEDURE

1∏

Check_voltage_between_terminals_FrTE_and_FrSG_of_A/C_amplifier_connector.



PREPARATION:

Remove A/C amplifier with connectors still connected.

CHECK:

- (a) ☐ Turn ignition switch ON.
- (b) Measure voltage between rminals FrTE and FrSG of A/C amplifier connector at each removature.

<u>OK:</u>

Voltage[] at[0°C[(32°F)]]2.0 -[2.4[V at 15°C[(59°F)]] 1.4 - 1.8[V

HINT:


As the temperature increases, the voltage decreases.



ΟK

Proceed@pinext@ircuit@nspectionshown@nproblemsymptoms@able@SeepageDI-859).[However, if RrDEF and FOOT is light up, check and replace A/C amplifier.

2 Check[front[evaporator[temperature[sensor.



PREPARATION:

Remove[]ront[evaporator[]emperature[sensor (See[page[AC-37).

CHECK:

Measure[resistance[between[reminals]] [and[2]bf[evaporator temperature[sensor[connector[at[each[remperature].

OK:

Resistance: at 0° C 32° F) 4.5 - 5.2 k Ω at 15° C 59° F) 2.0 - 2.7 k Ω

HINT:

As [the [temperature increases, [the [tesistance idecreases.

NG□

Replace[front[evaporator[temperature[sensor.

OK

3∏

Check[harness[and]connector[between]A/C[amplifier[and]front]evaporator[temperature]sensor[See[page]N-35).

NG

Repair or replace harness or connector.

ΟK

Check and replace A/C amplifier.