REASSEMBLY

BO1UC–01

Reassembly is in the reverse order of disassembly (See page BO–43).