

- B 10 Buckle SW LH
- B 11 Buckle SW RH
- L 4 Lumbar Support Control SW (Driver's Seat)
- P 23 Power Seat Control SW (Driver's Seat)
- P 24 Power Seat Control SW (Front Passenger's Seat)
- P 27 Power Seat Motor (Driver's Seat Front Vertical Control)
- P 28 Power Seat Motor (Driver's Seat Lumbar Support Control)
- P 29 Power Seat Motor (Driver's Seat Rear Vertical Control)
- P 30 Power Seat Motor (Driver's Seat Reclining Control)
- P 31 Power Seat Motor (Driver's Seat Slide Control)
- P 32 Power Seat Motor (Front Passenger's Seat Front Vertical Control)
- P 33 Power Seat Motor (Front Passenger's Seat Rear Vertical Control)
- P 34 Power Seat Motor (Front Passenger's Seat Reclining Control)
- P 35 Power Seat Motor (Front Passenger's Seat Slide Control)
- S 17 Seat Belt Warning Occupant Detection Sensor
- S 18 Seat Heater (Driver's Seat)
- S 19 Seat Heater (Front Passenger's Seat)
- S 27 Seat Heater (Driver's Seat Cushion)
- S 28 Seat Heater (Front Passenger's Seat Cushion)
- S 29 Seat Position Sensor
- S 30 Side Airbag Squib LH
- S 31 Side Airbag Squib RH

