### REMOVAL

#### **DISCHARGE REFRIGERANT FROM REFRIGERATION SYSTEM**

HINT:

At the time of installation, please refer to the following item.

Evacuate air from refrigeration system.

Charge system with refrigerant and inspect for leakage of refrigerant.

**Specified amount** 

Single A/C (\*1 RFS Condenser Models):

 $650 \pm 50 \text{ g} (22.93 \pm 1.76 \text{ oz.})$ 

Single A/C (\*2 IFS Condenser Models):

 $800 \pm 50 \text{ g} (28.22 \pm 1.76 \text{ oz.})$ 

Single A/C w/ Cool Box (\*1 RFS Condenser Models):

 $800 \pm 50 \text{ g } (28.22 \pm 1.76 \text{ oz.})$ 

Single A/C w/ Cool Box (\*2 IFS Condenser Models):

 $950 \pm 50 \text{ g} (33.51 \pm 1.76 \text{ oz.})$ 

Dual A/C (w/o Cool Box):


 $1,050 \pm 50 \text{ g } (37.03 \pm 1.76 \text{ oz.})$ 

Dual A/C (w/ Cool Box):

 $1,150 \pm 50 \text{ g} (40.56 \pm 1.76 \text{ oz.})$ 

\*1: Condenser Part No.: 88460-60280


\*2: Condenser Part No.: 88460-60260




#### **DISCONNECT LIQUID AND SUCTION TUBES** 2.

Using SST, remove the 2 piping clamps. (a)

> SST 09870-00015 (Suction tube) 09870-00025 (Liquid tube)






(1) Insert SST Topiping clamp.

#### HINT:

Confirm the direction of the piping clamp claw and \$ST using the lustration showing on the caution abel.



(2) Push down \$ST and release the clamp lock.

#### NOTICE:

#### Be careful not to deform the tubes, when pushing \$ST.

- (3) Pull \$ST slightly and push the release lever, then remove the piping clamp with \$ST.
- (4) ☐ Remove[the[piping[clamp[from[\$ST.
- (b) ☐ Disconnect The Toth Tubes.

#### **NOTICE:**


# Cap[]he[open[]ittings[]mmediately[]o[keep[]noisture[or[]dirtout[]of[]the[]system.

#### HINT:

At the time of installation, please refer to the following items.


- Lubricate [4] new [O-rings [with [compressor [pil and [nstall them [to [the [tubes.]
- After connection, check the fitting for claw of the piping clamp.
- 3. REMOVE INSTRUMENT PANEL AND REINFORCE-MENT

(See page BO-127)



#### 4. REMOVE ANTENNA RELAY

- (a) Disconnect the connector.
- (b) Remove the 2 screws and relay.



## 5. REMOVE COOLING UNIT

- (a) Disconnect the connector.
- (b) Remove the 4 screws, 2 nuts and cooling unit.

