51 LAND CRUISER (LHD) Power Source Radio and Player (w/o Stereo Component Amplifier) 2 C 6 CD Automatic Changer SGND CDR-CDR+ CDL-CDL+ 5 IG1 ACC (2UZ-FE) SB 4 (1B) Ignition SW 2 lg2 39 (2E) 2(2Q) B (Except 2UZ-FE) 4 IV1 SB AMP 7. 5A AM1 7. 5A ACC 1 (3C) ACC +B ACC MUTE R 2(A), R 3(B), R 4(C) Radio and Player Short Pin (A) RR-GND ACC CUT 2(A) 6(A) 1**(**A) 5(A) 2**(**C) 6(C) 3**(**C) 7**(**A) Relay 37 ID5 38 ID5 1 (1C) IQ3 36 IQ3 1 (2C) 40 (2E) 52(3Q) 51 (3Q) 1 If2 2 If2 4 If2 (§ 88 (*9 *11) Engine Control and Fuel Tank Changeover System 41 le1 (*5) 36 lQ3 (*6) 33 IQ3 34 IQ3 <8-2> 3 IV1 120A F38(B), Link Bb, 1 IW3 2 IW3 J/B NO. 3 MAIN NO. 2 (*1, *2) F39(C) (*8) 2 BE3 B-R 31 IQ3 32 IQ3 (*7) * 1 : 2 Speaker * 2 : 4 Speaker * 3 : 6 Speaker * 4 : Except 1HZ * 5 : Bench Seat (*3) (Diesel) 37 ID5 38 ID5 * 6 : Separate Seat * 7 : 2UZ-FE A/T * 8 : 2UZ-FE M/T F23 Front Door Tweeter LH Speaker LH * 9 : w/ Cellular Mobile Telephone *10 : w/o Cellular Mobile Telephone BB3 F24 Front Door T20 Tweeter RH R25 Rear Door (*1, *2) *11 : 4, 6 Speaker Speaker RH Speaker RH Set Bolt of Rear Side Under the BL (*1, *2) Cowl Side J/B LH R24 Rear Door Speaker LH