

## CONDENSER FAN RELAY INSPECTION

VC3U1 U

- 1. REMOVE ENGINE ROOM J/B
- 2. INSPECT CONDENSER FAN RELAY CONTINUITY

Condition	Tester connection	Specified condition
Constant	115 – 124	Continuity
Apply B+ between terminals 115 and 124.	12 – 125	Continuity

If continuity is not as specified, replace the engine room J/B.

3. INSTALL ENGINE ROOM J/B