DI88X-0

9. Black screen appears when "MAP", "Menu" or "DESTINATION" switch pressed.

