TRANSFER (Part-Time 4WD Type)

SST (Special Service Tools)

PP21I-01

09309-60010	Extension Pipe	Front extension housing
09316-20011	Transfer Bearing Replacer	Front extension housing Output shaft, Transfer assembly
09316-60011	Transmission & Transfer Bearing Replacer	
(09316-00011)	Replacer Pipe	Front extension housing Output shaft, Transfer assembly
(09316-00031)	Replacer "B"	Front extension housing Transfer assembly
(09316-00061)	Replacer "E"	Front extension housing
(09316-00071)	Replacer "F"	Front extension housing
09330-00021	Companion Flange Holding Tool	Transfer assembly
09517-12010	Rear Axle Shaft Oil Seal Replacer	Transfer assembly
09631-20081	Seal Ring Tool	Transfer assembly
09649-17010	Steering Knuckle Tool	Front extension housing
09950-00020	Bearing Remover	Output shaft

			1
	09950-40011	Puller B Set	
	(09951-04020)	Hanger 200	Front extension housing Transfer assembly
	(09952-04010)	Slide Arm	Front extension housing Transfer assembly
5.1	(09953-04030)	Center Bolt 200	Front extension housing Transfer assembly
	(09954-04010)	Arm 25	Front extension housing Transfer assembly
	(09955-04021)	Claw No.2	Front extension housing Transfer assembly
	(09955-04051)	Claw No.5	Front extension housing
	(09955-04061)	Claw No.6	Transfer assembly
8	(09957-04010)	Attachment	Transfer assembly Front extension housing
	(09958-04011)	Holder	Transfer assembly
Sessesses (09950-60010	Replacer Set	
9	(09951-00270)	Replacer 27	Transfer assembly
9	(09951-00290)	Replacer 29	Transfer assembly
·			

9	(09951-00320)	Replacer 32	Transfer assembly
9	(09951-00400)	Replacer 40	Transfer assembly
0000 0000 00001	09950-60020	Replacer Set No.2	
6	(09951-00790)	Replacer 79	Transfer assembly
6	(09951-00890)	Replacer 89	Transfer assembly
	09950-70010	Handle Set	
a	(09951-07150)	Handle 150	Transfer assembly