DI3T8-01

DTC	P1566/55□	Engine@and@ECT@ECU@ircuit	
-----	-----------	---------------------------	--

CIRCUIT DESCRIPTION

DTC[No.	Detection[]tem	Trouble[A rea
P1566/[\$5	•Engine@andECTECU@abnormal.	•Engine@and@ECT@ECU

INSPECTION PROCEDURE

Check and replace \mathbb{E} ngine and \mathbb{E} CT \mathbb{E} CU (See page $\mathbb{N}-35$).