48 LAND CRUISER (LHD) Power Source Multi-Display * 1 : 2UZ-FE A/T * 2 : 2UZ-FE M/T * 3 : Except 2UZ–FE * 4 : Europe Except 1HD–FTE * 5 : 1HD–FTE Europe * 4 : Except *5 I26 Ignition SW (*1, *2) ACC (*3) L-B J 6(A), J 7(B) Junction Connector 21 2D 37 **2E** 39 (2E) 16 (2D) 10A ECU-IG1 7. 5A ECU-B1 ACC SECURITY A/C TEMP IG1 NO. 2 Relay ACC Relay M 4 Multi-Display UART+ UART-GND TC (° ± B G (% 4) ₹ 120A J/B NO. F38(B), F39(C) Fusible Link Block 40 (2E) 3 IV1 Engine Control and Fuel Tank Changeov System<8-2> (*3) B-R (*1, *2) 140A ALT J 7 Junction Connectes Connector **†** Set Bolt of Cowl Side J/B RH 7 Set Bolt of Cowl Side J/B LH