3. Layout of Component

Front Airbag Sensor

Front Airbag Sensor

SRS Warning Light

Front Passenger
Airbag Assembly

Driver Airbag
Assembly

Side Airbag
Assembly

Side Airbag
Sensor

Seat Belt
Pretensioner

DLC3

Airbag Sensor
Assembly

Seat Belt Buckle Switch

Side Airbag Assembly

Seat Belt Buckle Switch

Seat Position Sensor

Side Airbag Sensor

Seat Belt Pretensioner

228AV13