Ш

İП

CTRICAL WIRING

DIAGRAM

216

4 LAND CRUISER (LHD) Ignition (2UZ-FE) Power Source Y ST2 J14 Junction Connector I26 Ignition SW Engine ECU Engine and ECT ECU<8-13><8-14> W-B W-B W-B W-B W-B W-B W-B B-W F37 Fusible Link Block 120A MAIN Engine ECU Engine and ECT ECU<8-14> Rear Bank of Right Cylinder Head Rear Bank of Left Cylinder Head