POWER TILT AND POWER TELESCOPIC STEERING COLUMN

HOW[TO[PROCEED[WITH[TROUBLESHOOTING]

Perform troubleshooting in accordance with the procedure on the following page.

