## AUTOMATIC TRANSMISSION (A750F for 1HD-FTE) HOW TO PROCEED WITH TROUBLESHOOTING

DIAV7\_0

When using hand-held tester, troubleshoot in accordance with the procedure on the following pages. Vehicle Brought to Workshop Items inside are titles of pages in this manual, with the page number indicated in the bottom portion. See the indicated pages for detailed explanations. Customer Problem Analysis, P.⊓0∏-32 Connect the hand-held tester to DLC3 If the display shows "UNABLE TO CONNECT TO VEHICLE" when you have connected the hand-held[tester, [inspect]DLC3[P.[DI-33] Check DTC and Freeze Frame Data (Precheck) Record or Print DTC and Freeze Frame Data P. DI-33 Clear DTC and Freeze Frame Data P. DI-33 ★: Refer LAND CRUISER Chassis and Body Repair 5 // Visual Inspection// Manual Supplement (Pub. No. RM970E). Setting@herCheck@ode@biagnosis@p.@l-33 Symptom does not occur Symptom Simulation 7 // Problem Symptom Confirmation // P.∏N-27 Symptom occur 11 **OK Code** DTC Check Basic nspection NG P.⊓DII-33∏ P.∏∏-33 OK NG DTC Chart Mechanical System Test P.∏∏-33 13 OK NG OK Manual Shifting Test P.∏∏-33 14 Problem Symptoms Table-★ Chapter 3 Chapter 1 NG Chapter 2 OK OK (Off-Vehicle) (Electronic) (On-Vehicle) NG NG 15 Parts Inspection/ Neutral Start Switch Circuit Check Circuit A/T.P. Indicator Circuit Check Inspection ĮЦ Identification of Problem Repair Confirmation Test

When using hand-held tester, froubleshoot in accordance with the procedure on the following pages.

