
SR0Q6-01

INSTALLATION

1. INSTALL SUCTION PORT UNION

- (a) Coat hew D-ring with hower steering fluid and install it to the lunion.
- (b) Torque the 2 bolts.


Torque:[7.8[N·m[80[kgf·cm,[69[in.·lbf)



2. INSTALL [PS[VANE [PUMP [ASSEMBLY]

- (a) Coatahew D-ring with power steering fluid and install to the vane pump assembly.
- (b) Torque the 2 huts.

Torque: 36[N·m[370[kgf·cm, 27[ft·lbf)



3. CONNECT SUCTION PORT UNION

Torque[the[bolt.

Torque: 18[N·m[[185[kgf·cm, 13[ft·lbf]

4. CONNECT PRESSURE FEED TUBE

Install_hew_gaskets_bn_each_side_bf_the_tube_and_torque_the union_bolt.

Torque: \$6[N·m[575[kgf·cm,42[ft·lbf)]

5. CONNECT RETURN HOSE

Install the clip.

6. BLEED POWER STEERING SYSTEM

(See page \$R-4)